Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SICOTAS SC125-LT-2

SICOTAS 68" W Rattan Sideboard Buffet Cabinet with Storage (Model: SC125-LT-2)

Instruction Manual

Introduction **Safety Information** **Package Contents** **Assembly Instructions** **Operating Instructions** **Maintenance** **Troubleshooting** **Specifications** **Warranty & Support**

1. Introduction

Thank you for choosing the SICOTAS 68" W Rattan Sideboard Buffet Cabinet. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read it thoroughly before beginning assembly and retain it for future reference.
This set includes two versatile cabinets, featuring a charming arch rattan design and a reclaimed light oak finish. Designed for various rooms, it offers ample storage with adjustable shelves and soft-closing doors.

2. Safety Information

WARNING: Failure to follow these safety instructions may result in injury or damage to the product.

- Always secure the cabinet to the wall using the anti-tip kits provided to prevent tip-overs and potential injuries.
- Do not place heavy items on the top shelf to avoid overloading and tipping. The maximum weight limit for the top surface is 77 pounds.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Keep small parts and assembly hardware away from children during assembly to prevent choking hazards.
- Assemble the product on a soft, clean surface to prevent scratches.

3. Package Contents

Before beginning assembly, ensure all parts and hardware are present and undamaged. Refer to the included assembly instructions for a detailed list of numbered parts and lettered hardware components.



Figure 3.1: Exploded view of cabinet components and hardware.

4. Assembly Instructions

Assembly is straightforward with clear instructions and labeled parts. A screwdriver is required (not included). It is recommended to have two people for assembly.

4.1. Step-by-Step Assembly Guide

1. **Prepare the Top Panel:** Attach the cam bolts (A) to the top panel (1). Ensure they are screwed in straight and flush.
2. **Attach Anti-Tip Brackets:** Secure the anti-tip brackets (P) to the top panel (1) using screws (N).
3. **Install Magnetic Catches:** Attach the magnetic catches (J) to the top panel (1) using screws (H).
4. **Prepare Side Panels:** Attach cam bolts (A) to the side panels (2 and 3).
5. **Prepare Bottom Panel:** Attach cam bolts (A) to the bottom panel (5) and the back support bar (11).
6. **Install Magnetic Catches (Bottom):** Attach magnetic catches (J) to the bottom panel (5) using screws (H).
7. **Attach Dowels:** Insert wooden dowels (I) into the pre-drilled holes on the side panels (2 and 3) and the back support bars (11 and 12).
8. **Connect Bottom and Side Panels:** Connect the bottom panel (5) to the side panels (2 and 3) using cam locks (B).
9. **Attach Adjustable Feet:** Screw in the adjustable feet (Q) to the bottom of the side panels.
10. **Install Back Panels:** Slide the back panels (7 and 8) into the grooves on the side and bottom panels.
11. **Attach Top Panel:** Connect the assembled top panel (1) to the side panels (2 and 3) using cam locks (B).
12. **Install Shelf Supports:** Insert shelf supports (M) into the desired holes on the inner sides of the cabinet.
13. **Place Shelves:** Place the adjustable shelves (4) onto the shelf supports.
14. **Attach Hinges to Doors:** Attach hinges (L) to the cabinet doors (9 and 10) using screws (K).
15. **Attach Door Plates:** Attach door plates (C) to the cabinet doors (9 and 10) using screws (D) and the wooden blocks (F).
16. **Mount Doors:** Attach the doors (9 and 10) to the cabinet frame by screwing the hinges (L) into the pre-drilled holes. Adjust hinges for proper door alignment.
17. **Secure Back Panels:** Secure the back panels (7 and 8) to the cabinet frame using screws (H) and plastic clips (G).
18. **Install Wall Anchors:** Drill holes in the wall, insert wall anchors (E), and secure the anti-tip brackets (P) to the wall using screws (O).

4.2. Assembly Video Guide

▶ **Watch video online**
How to Assemble the Rattan Sideboard with Arch Doors

Video 4.1: Detailed assembly instructions for the SICOTAS Rattan Sideboard.

5. Operating Instructions

5.1. Adjustable Shelves

Your SICOTAS sideboard features four adjustable shelves, allowing you to customize the storage space according to your needs. To adjust a shelf:

1. Remove all items from the shelf you wish to adjust.
2. Carefully lift the shelf and remove the shelf supports (M) from their current holes.
3. Re-insert the shelf supports into the desired new holes, ensuring they are level and securely placed.
4. Place the shelf back onto the supports.



Figure 5.1: The cabinet features adjustable shelves for flexible storage.

5.2. Soft-Closing Doors

The cabinet doors are equipped with soft-closing hinges to prevent slamming and ensure quiet operation. Simply push the door gently to close, and the mechanism will engage for a smooth, silent closure.

▶ **Watch video online**
SICOTAS Rattan Sideboard

Video 5.1: Demonstration of the soft-closing doors and interior storage.

6. Maintenance

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Dusting:** Regularly dust with a dry, soft cloth to prevent buildup.
- **Spills:** Clean spills immediately to prevent staining, especially on the wood finish.
- **Sunlight Exposure:** Avoid prolonged direct sunlight exposure to prevent fading or discoloration of the wood and rattan.
- **Humidity:** Maintain a stable humidity level in the room to prevent warping or cracking of the wood.
- **Hardware:** Periodically check all screws and fasteners to ensure they are tight. Re-tighten as needed.

7. Troubleshooting

Problem	Possible Cause	Solution
Cabinet feels wobbly or unstable.	Loose fasteners or uneven floor.	Ensure all assembly screws are tightened. Adjust the leveling feet (Q) on the bottom of the cabinet to stabilize it on uneven surfaces. Verify anti-tip kit is installed correctly.
Doors do not align or close properly.	Hinges are not adjusted correctly or loose.	Adjust the screws on the hinges (L) to align the doors. Refer to the assembly video for hinge adjustment guidance. Tighten any loose hinge screws.
Shelves are not level.	Shelf supports are not inserted correctly.	Ensure all four shelf supports (M) are fully inserted into corresponding holes at the same height.
Rattan appears damaged or loose.	Manufacturing defect or accidental damage.	Contact customer support for assistance.

8. Specifications

Brand: SICOTAS

Model Name: Rattan Sideboard

Model Number: SC125-LT-2

Color: Reclaimed Light Oak

Product Dimensions: 13.9"D x 68.4"W x 35.4"H (for the set of 2)

Material: Engineered Wood, Rattan

Number of Pieces: 2

Number of Shelves: 4 (adjustable)

Weight Limit (Top): 77 Pounds

Weight Limit (Per Shelf): 33 Pounds

Assembly Required: Yes

Special Feature: 4 Adjustable Shelves, Arched Door Style, Soft-Closing Doors

Room Type: Dining Room, Entryway, Home Office, Kitchen, Living Room

Mounting Type: Floor Mount (with anti-tip wall anchor option)

Included Components: Instructions and Assembly Tools (excluding screwdriver)

9. Warranty & Customer Support

SICOTAS products are designed for quality and durability. For specific warranty details, please refer to the documentation included with your purchase or visit the official SICOTAS website. Our dedicated customer service team is available to assist with any issues or questions you may have regarding your product.

Contact Information: Please refer to your purchase receipt or the SICOTAS brand store on Amazon for the most up-to-date customer support contact details.

© 2026 SICOTAS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F43YF4MM

More documents and user manuals: **https://manuals.plus/**