Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

IBELL WHISK280

iBELL WHISK280 Hand Mixer User Manual

Model: WHISK280

1. Introduction

Thank you for purchasing the iBELL WHISK280 Hand Mixer. This appliance is designed to make your baking and cooking tasks easier and more efficient. With its powerful 280-watt motor, 7-speed control, and turbo function, it is suitable for a variety of mixing, whisking, and blending needs. Please read this manual carefully before using the appliance to ensure safe and optimal performance. Keep this manual for future reference.

2. Important Safety Instructions

WARNING: To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions.

- Read all instructions before using the appliance.
- Do not immerse the motor unit, cord, or plug in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Keep hands and utensils away from the mixing bowl while operating to prevent injury to persons or damage to the mixer.
- Always ensure the appliance is switched off and unplugged before changing accessories.

3. Product Overview

The iBELL WHISK280 Hand Mixer is designed for versatility and ease of use. It comes with essential attachments for various culinary tasks.

Components:

- Hand Mixer Unit (Motor Housing)
- Beaters (Stainless Steel)
- Dough Hooks (Stainless Steel)



Image 1: The iBELL WHISK280 Hand Mixer, showcasing its design and the 2-year warranty badge.

Key Features:

- **Powerful 280W Copper Motor:** Ensures efficient blending and whisking for various ingredients.
- **7 Speed Control + Turbo:** Allows precise adjustment of mixing speed for optimal results.
- **Food-Grade Stainless Steel Attachments:** Durable and easy to clean beaters and dough hooks.
- **Anti-Shake Protection:** Keeps the mixer stable during operation, especially when using dough hooks.



Image 2: Illustration of the iBELL WHISK280 Hand Mixer's pure copper motor and 280W power.

4. Setup and Assembly

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for storage or future transport.
2. **Clean Attachments:** Before first use, wash the beaters and dough hooks in warm, soapy water, then rinse and dry thoroughly. Wipe the main mixer unit with a damp cloth.
3. **Attach Beaters/Dough Hooks:**
    - Insert the beaters or dough hooks into the openings on the underside of the mixer unit. Push firmly until they click into place.
    - For dough hooks, ensure the hook with the anti-shake protection ring is inserted into the left-side opening. This prevents dough mixing failures and ensures stability.
4. **Power Connection:** Ensure the mixer is switched off (speed selector at '0') before plugging it into a suitable power outlet (220V AC).



Image 3: Proper insertion of the dough hook with anti-shake protection into the iBELL WHISK280 Hand Mixer.

5. Operating Instructions

1. **Prepare Ingredients:** Place your ingredients in a suitable mixing bowl.
2. **Attach Accessories:** Ensure the desired beaters or dough hooks are securely attached.
3. **Plug In:** Plug the mixer into a power outlet.
4. **Select Speed:** Start with a low speed (1-3) and gradually increase as needed. The iBELL WHISK280 offers 7 speed settings plus a Turbo function for maximum power.
5. **Mixing Guide:**
    - **Speeds 1-3 (Original Mixing Speed):** Ideal for dry mixed items such as flour, butter, and pudding.
    - **Speeds 4-6 (Medium Mixing Speed):** Suitable for jam, baby food, batter, and potato mash.
    - **Speed 7 - Turbo (High Mixing Speed):** Use for milkshakes, salads, beating eggs, and gas-foaming with milk.
6. **Mix:** Guide the mixer through the ingredients, ensuring even mixing.

7. **Finish:** Once mixing is complete, set the speed selector to '0' and unplug the mixer from the outlet.
8. **Eject Attachments:** Press the eject button to release the beaters or dough hooks.



Image 4: Visual guide for the 7 speed settings and Turbo function on the iBELL WHISK280 Hand Mixer.



Image 5: The iBELL WHISK280 Hand Mixer in use, demonstrating its ergonomic design.

6. Maintenance and Cleaning

Always unplug the hand mixer from the power outlet before cleaning.

- **Mixer Unit:** Wipe the exterior of the motor unit with a soft, damp cloth. Do not use abrasive cleaners or immerse the unit in water.
- **Attachments (Beaters & Dough Hooks):** Wash the stainless steel beaters and dough hooks in warm, soapy water. Rinse thoroughly and dry immediately to prevent water spots or corrosion.
- **Dishwasher Safety:** The attachments are **NOT dishwasher safe**. Hand wash only.
- **Storage:** Store the cleaned and dried mixer and its attachments in a dry place, away from direct sunlight and out of reach of children.

7. Troubleshooting

If you encounter any issues with your iBELL WHISK280 Hand Mixer, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Mixer does not turn on.	Not plugged in; power outlet malfunction; speed selector not at '0' before turning on.	Ensure the mixer is securely plugged into a working outlet. Check if the speed selector is at '0' before selecting a speed.
Attachments do not fit or eject.	Incorrect insertion; debris in slots; eject button not fully pressed.	Ensure attachments are inserted correctly and fully. Check for any obstructions in the slots. Press the eject button firmly.
Mixer overheats during use.	Prolonged use; mixing very thick ingredients; blocked ventilation.	Allow the mixer to cool down. Avoid continuous operation for extended periods. Ensure ventilation slots are clear. Reduce load for very thick mixtures.

If the problem persists after trying these solutions, please contact customer support.

8. Specifications

Feature	Detail
Brand	IBELL
Model Name	WHISK280
Colour	WHITE
Product Dimensions (D x W x H)	18D x 7W x 12.5H Centimeters
Material	Stainless Steel (Attachments)
Special Features	Adjustable Speed Control, Anti-Shake protection, Turbo Boost
Voltage	220 Volts (AC)
Wattage	280 Watts
Controls Type	Push Button
Item Weight	600 Grams
Number Of Speeds	7
Included Components	Dough Hook, Beaters
Country of Origin	China



Image 6: Dimensions of the iBELL WHISK280 Hand Mixer.

9. Warranty and Support

Warranty Information:

The iBELL WHISK280 Hand Mixer comes with a**2-year warranty**, which includes a 1-year Standard Warranty plus an additional 1-year Warranty upon registration. Registration must be completed within 30 days from the date of purchase to avail the extended warranty.

Customer Support:

For any queries, service requests, or support, please contact Innovative Technologies:

- **Manufacturer/Importer:** Innovative Technologies, iBELL Fida's Building, Thottumugham P.O, Aluva, Kerala - 683105
- **Phone:** 1800 2020 260

- **Email:** connect@ibellstore.com

10. Product Videos

No official product videos with 'Seller' as creator type were found in the provided product data to embed in this manual.

© 2026 IBELL. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F5M3N998

More documents and user manuals: **https://manuals.plus/**