Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Erivess HA101L

Erivess Compact Mini Twin Tub Washing Machine

Model: HA101L

1. Introduction

Thank you for choosing the Erivess Compact Mini Twin Tub Washing Machine. This semi-automatic appliance is designed for convenience and efficiency, ideal for small living spaces such as dorms, apartments, RVs, and camping. It features separate tubs for washing and spinning, allowing for simultaneous operation to save time and effort. With an 11 lbs washing capacity and a 7 lbs spinning capacity, it offers a practical solution for your laundry needs while being energy and water efficient.



Figure 1: Erivess Compact Mini Twin Tub Washing Machine.

2. Safety Instructions

- **Electrical Safety:** Ensure the machine is plugged into a grounded outlet with the correct voltage (120V AC). Do not use extension cords. Keep the power cord away from water.
- **Water Safety:** Do not submerge the machine in water. Ensure the drain hose is properly positioned to prevent water damage.
- **Placement:** Place the machine on a firm, flat, and stable surface to prevent tipping or excessive vibration.
- **Loading:** Do not overload the machine beyond its specified capacity (11 lbs wash, 7 lbs spin) to prevent damage and ensure efficient operation.
- **Children and Pets:** Keep children and pets away from the machine during operation.
- **Overheating Protection:** The motor and drain pump are equipped with overheating protection. If they overheat, restart them after 30-60 minutes of cooling.

3. Package Contents

Verify that all components are present in the package:

- Erivess Compact Mini Twin Tub Washing Machine (Model HA101L)
- Drain Hose
- Spin Cap (for spinner tub)
- Inlet Hose
- User Manual

4. Product Overview

Familiarize yourself with the main components and control panel of your washing machine.



Figure 2: Control Panel.

- **Wash Timer:** Sets the duration of the wash cycle (up to 15 minutes).
- **Wash Selector:** Selects the wash mode (Soft, Standard) or Drain function.
- **Spin Timer:** Sets the duration of the spin cycle (up to 5 minutes).
- **Water Inlet:** Port for connecting the inlet hose to fill the wash tub.
- **Wash Tub:** Main compartment for washing clothes (11 lbs capacity).
- **Spin Tub:** Smaller compartment for spinning clothes dry (7 lbs capacity).
- **Drain Hose:** For expelling dirty water.

5. Setup

Follow these steps to set up your washing machine:

1. **Placement:** Position the washing machine on a flat, stable surface near a water source (faucet) and a drain (sink, bathtub, or floor drain).
2. **Connect Water Inlet:** Attach the inlet hose to the Water Inlet port on the left side of the control panel. Connect the other end of the inlet hose to a suitable faucet. Alternatively, you can fill the wash tub directly

using a bucket or shower head.



Figure 3: Water Inlet.

3. **Position Drain Hose:** Ensure the drain hose is positioned downwards into a sink, bathtub, or floor drain to allow for proper water drainage. The drain hose should not be submerged in water to prevent drain issues or siphoning.



Figure 4: Drain Hose.

4. **Power Connection:** Plug the machine into a suitable electrical outlet.

6. Operating Instructions

This section guides you through the washing and spinning process.

Washing Cycle:

1. **Load Clothes:** Open the wash tub lid and place clothes inside. Do not exceed the 11 lbs capacity.
2. **Add Water:** Fill the wash tub with water to your desired level. You can use the inlet hose or pour water directly.
3. **Add Detergent:** Add the appropriate amount of laundry detergent. If using fabric softener liquid, add it during the rinse cycle.
4. **Set Wash Timer:** Turn the Wash Timer knob to the desired wash time (up to 15 minutes).
5. **Select Wash Mode:** Turn the Wash Selector knob to 'Soft' for delicate items or 'Standard' for regular clothes. The machine will begin agitating.

   ▶ **Watch video online**

   Video 1: Erivess Portable Mini Twin Tub Washing Machine in action.

6. **Draining:** Once the wash cycle is complete, turn the Wash Selector knob to 'Drain' to empty the dirty water.

Spinning Cycle:

1. **Transfer Clothes:** Move the washed clothes from the wash tub to the spin tub. Do not exceed the 7 lbs capacity.
2. **Balance Load:** Distribute clothes evenly in the spin tub to prevent excessive vibration.
3. **Place Spin Cap:** Firmly press the white spin cap onto the clothes in the spin tub to prevent small items from spinning out.
4. **Set Spin Timer:** Turn the Spin Timer knob to the desired spin time (up to 5 minutes). The machine will begin spinning.

   ▶ **Watch video online**
   No bs review,Here's the truth!

   Video 2: Demonstration of the spin cycle.
5. **Repeat Rinse (Optional):** For a thorough rinse, you can add clean water to the spin tub and run a short spin cycle again.
6. **Remove Clothes:** Once the spin cycle is complete, remove the clothes. They will be approximately 70-80% dry and can be air-dried.

7. Maintenance

Proper maintenance ensures the longevity and optimal performance of your washing machine.

- **Cleaning the Exterior:** Wipe the exterior of the machine with a soft, damp cloth. Do not use abrasive cleaners.
- **Cleaning the Lint Filter:** Regularly remove and clean the lint filter located inside the wash tub to prevent lint buildup and ensure efficient washing.
- **Draining After Use:** Always ensure all water is drained from both tubs after each use.
- **Storage:** Store the machine in a dry, well-ventilated area when not in use. Avoid direct sunlight or extreme temperatures.

8. Troubleshooting

Refer to this section for solutions to common issues:

- **Machine Not Starting:** Check if the power cord is securely plugged in. Ensure the Wash Timer or Spin Timer is set.
- **Water Not Draining:** Verify that the drain hose is positioned correctly and not kinked or blocked. Ensure the Wash Selector is set to 'Drain'.
- **Excessive Vibration During Spin:** This usually indicates an unbalanced load. Redistribute the clothes evenly in the spin tub and ensure the spin cap is firmly in place.
- **Motor/Pump Overheating:** If the machine stops due to overheating, allow it to cool down for 30-60 minutes before restarting.

9. Specifications

Brand	Erivess
Model Info	HA101L
Product Dimensions	15 x 23.5 x 26.6 inches

Capacity (Wash)	11 lbs
Capacity (Spin)	7 lbs
Installation Type	Freestanding
Special Features	Portable, Semi-automatic, Compact, Light Weight
Color	Blue
Control Console	Knob (Manual)
Access Location	Top Load
Voltage	120 Volts (AC)

10. Warranty and Support

Your Erivess Compact Mini Twin Tub Washing Machine comes with a manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions. For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact Erivess customer service through the retailer where you purchased the product.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F5W2FCYM

More documents and user manuals: **https://manuals.plus/**