Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MERACH MR-E32

MERACH Under Desk Elliptical E32-Standard User Manual

Model: MR-E32

Introduction Components Setup Operation Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

Thank you for choosing the MERACH Under Desk Elliptical E32-Standard. This device is designed to provide a low-impact, effective leg workout for users of various ages and mobility levels, including seniors and office workers. Its compact and quiet design allows for convenient use at home or in the office. This manual provides essential information for safe and efficient operation, maintenance, and troubleshooting.

2. Package Contents

Upon unboxing, please verify that all components listed below are present and undamaged:

- MERACH Under Desk Elliptical Machine (MR-E32) x1
- Remote Controller x1
- AAA Batteries x2 (for remote controller)
- Power Cord x1
- User Manual x1



Figure 2.1: Included components of the MERACH Under Desk Elliptical E32-Standard. The image displays the elliptical machine, remote control, power cord, and two AAA batteries.

3. Setup Instructions

The MERACH Under Desk Elliptical E32-Standard comes fully assembled, requiring minimal setup before first use.

1. **Placement:** Choose a flat, stable surface for the elliptical. For optimal stability and floor protection, place the included non-slip mat (if provided, or a similar mat) underneath the unit. Ensure there is sufficient space around the unit for comfortable use and to avoid obstructions.
2. **Power Connection:** Connect the power cord to the elliptical's power input port and then plug it into a standard electrical outlet.
3. **Remote Control Setup:** Open the battery compartment on the back of the remote control and insert the two AAA batteries, ensuring correct polarity (+/-). Close the compartment securely.
4. **Initial Power On:** Press the power button on the elliptical or the remote control to turn on the device. The LED display should illuminate.



Figure 3.1: The MERACH Under Desk Elliptical E32-Standard, showcasing its compact design, foot pedals, integrated LED display, and the accompanying remote control.

4. Operating Instructions

The MERACH E32-Standard offers both automatic and manual modes, controlled via the touch screen or remote.

4.1 Control Panel and Remote Control

The elliptical can be operated using the integrated touch screen panel or the provided remote control. Both offer similar functionalities for adjusting settings.



Figure 4.1: Detailed view of the elliptical's control panel, showing buttons for Direction, Mode, Function, Start/Stop, and speed adjustment (+/-), along with the LED display.



Figure 4.2: Illustration of the dual control options: the remote control for convenient adjustments and the integrated touch panel on the elliptical.

4.2 Modes of Operation

- **Manual Mode (HR Mode):**

  This mode allows you to manually select from 12 speed levels. Use the "+" and "-" buttons on the control panel or remote to adjust the speed. This mode is ideal for users who prefer direct control over their workout intensity.

- **Auto Mode (P1-P12):**

  The elliptical features 12 pre-programmed auto modes (P1 through P12). Each program automatically adjusts speed and direction over a 15-minute cycle, providing varied workout routines. Select an auto mode using the "MODE" button.



Figure 4.3: Visual representation of the two workout modes: HR Mode (Manual) with 12 adjustable speeds and Auto Mode (P1-P12) with programmed speed and direction adjustments.

4.3 Pedaling Direction

The elliptical supports both forward and reverse pedaling. Use the "DIRECTION" button to switch between these. Each direction engages different muscle groups:

- **Forward Pedaling:** Primarily targets ankles, knees, and buttocks.
- **Reverse Pedaling:** Primarily targets ankles, knees, and waist.



Figure 4.4: Illustration demonstrating the forward and reverse elliptical motion, highlighting the specific muscle groups activated by each direction.

4.4 LED Display Functions

The LED display provides real-time workout data:

- **SCAN:** Cycles through all metrics automatically.
- **TIME:** Displays the duration of your current workout session.
- **DISTANCE:** Shows the distance covered (in meters).

- **SPEED:** Indicates the current pedaling speed.
- **COUNTER:** Tracks the total number of pedal rotations.
- **CALORIE:** Estimates the calories burned during the workout.

4.5 Quiet Operation

The MERACH E32-Standard is designed for quiet operation, producing less than 15dB of noise. This allows for discreet use in various environments without disturbing others.



Figure 4.5: The elliptical in use, demonstrating its quiet operation suitable for office or home environments, allowing users to work or relax

without disturbance.

5. Maintenance

Regular maintenance ensures the longevity and optimal performance of your MERACH Under Desk Elliptical.

- **Cleaning:** Wipe down the unit with a soft, damp cloth after each use to remove dust and sweat. Avoid using abrasive cleaners or solvents that could damage the finish or electronic components.
- **Lubrication:** If you notice any creaking noises or increased friction in the pedal mechanism, apply a small amount of silicone-based lubricant to the moving parts. Refer to the specific lubrication points indicated in the detailed user manual (if provided separately) or contact customer support for guidance.
- **Storage:** Store the elliptical in a cool, dry place away from direct sunlight and extreme temperatures when not in use for extended periods.
- **Battery Replacement:** Replace the AAA batteries in the remote control when the display becomes dim or the remote's responsiveness decreases.

6. Troubleshooting

If you encounter any issues with your MERACH Under Desk Elliptical, please refer to the following common solutions:

Problem	Possible Cause	Solution
Unit does not power on.	Power cord not properly connected; power outlet issue.	Ensure the power cord is securely plugged into both the elliptical and a working electrical outlet. Try a different outlet.
Remote control is unresponsive.	Dead batteries; remote not aimed correctly.	Replace the AAA batteries in the remote control. Ensure the remote is pointed directly at the elliptical's sensor.
Unusual noise during operation.	Lack of lubrication; loose components.	Apply lubricant to moving parts as described in the Maintenance section. Check for any loose screws or connections and tighten them.
Pedals feel stiff or inconsistent.	Accumulated dirt; need for lubrication.	Clean the pedal mechanism and apply lubricant.

If the problem persists after attempting these solutions, please contact MERACH customer support for further assistance.

7. Product Specifications

Feature	Detail
Model Number	MR-E32
Brand	MERACH
Product Dimensions	39.6 x 37.8 x 18.9 cm (15.6 x 14.9 x 7.4 inches)
Item Weight	5.05 kg (11.13 lbs)

Feature	Detail
Colour	Black
Material	Alloy Steel
Resistance Mechanism	Magnetic
Number of Resistance Levels	12 (Manual Mode)
Workout Modes	12 Manual Speed Levels, 12 Auto Modes (P1-P12)
Maximum Weight Recommendation	250 Pounds
Noise Level	Less than 15dB
Control Options	Touch Screen, Remote Control

8. Warranty & Customer Support

Your MERACH Under Desk Elliptical E32-Standard is covered by a **12-month warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the product meets quality standards.

For any inquiries, technical assistance, or warranty claims, please contact MERACH customer service. Our team is available **24 hours a day** to provide support via email or phone. Please have your order number and product model (MR-E32) ready when contacting support to expedite the process.

Contact information can typically be found on the MERACH official website or through your purchase platform.

© 2025 MERACH. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F631XQYW

More documents and user manuals: **https://manuals.plus/**