Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun MQ50202M

Braun MQ50202M MultiQuick Vario 5 Handheld Blender Instruction Manual

Introduction

Welcome to your Braun MQ50202M MultiQuick Vario 5 Handheld Blender. This manual provides essential information for safe operation, maintenance, and optimal performance of your appliance. Please read all instructions carefully before first use and retain for future reference.

Important Safety Information

Always exercise caution when operating electrical appliances. Keep hands and utensils out of the container while blending to prevent injury. Blades are sharp; handle with care. Ensure the appliance is unplugged before assembling, disassembling, or cleaning. Do not immerse the motor unit in water. This appliance is not intended for use by children.

Package Contents

Your Braun MQ50202M MultiQuick Vario 5 Handheld Blender package includes the following components:

- Motor Body (Handheld Unit)
- PowerBell VPlus Blending Wand (Stainless Steel)
- Whisk Attachment
- Mini Chopper (1.5-cup capacity)
- Plastic Beaker (600ml/20 fl. oz.)
- Instruction Manual



Image showing the Braun MultiQuick Vario 5 Handheld Blender motor body, PowerBell blending wand, whisk attachment, mini chopper, and plastic beaker.

Setup

1. **Unpacking**: Carefully remove all components from the packaging.
2. **Cleaning**: Before first use, clean all parts that will come into contact with food. The blending shaft, whisk, chopper bowl, and beaker are dishwasher safe (top rack only) or can be washed by hand with warm soapy water. Wipe the motor body with a damp cloth.
3. **Assembly**:
    - **Attaching Blending Wand**: Align the blending wand with the motor body and twist until it clicks securely into place. To detach, press the release buttons on the sides of the motor body and twist.
    - **Attaching Whisk**: Insert the whisk into the whisk gear box, then align the gear box with the motor body and twist until it clicks securely into place.

- **Attaching Chopper**: Place the chopper blade onto the central pin in the chopper bowl. Secure the chopper lid onto the bowl, then align the motor body with the lid and twist until it clicks securely into place.

▶ **Watch video online**
MultiQuick 5 by Braun

Video demonstrating the assembly and disassembly of the Braun MultiQuick 5 Handheld Blender with its various attachments.

Operating Instructions

The Braun MultiQuick Vario 5 features VarioSpeed Technology, allowing precise control with one hand.

Variable Speed Control

The appliance offers 21 speeds, adjustable via the speed wheel on the top of the motor body. Rotate the wheel from 'min' to 'max' to select your desired speed.

Power Button and Turbo Boost

Press and hold the main power button to operate the blender at the selected speed. For an extra burst of concentrated power, press the TurboBoost button. Release the button to stop operation.

Using the PowerBell VPlus Blending Wand

The unique bell-shaped blending shaft with ultra-hard stainless steel blades and 6 inner ribs ensures more food-to-blade contact for smoother results and significantly reduces splashing (SplashControl Technology).

- For best results, immerse the blending wand into the ingredients before starting the appliance.
- Move the blending wand up and down gently to ensure all ingredients are processed evenly.
- Ideal for blending soups, sauces, smoothies, and baby food directly in pots, bowls, or the included beaker.



Close-up image of the Braun MultiQuick Vario 5 PowerBell VPlus blending wand, highlighting its unique bell shape and stainless steel blades.

▶ **Watch video online**

From squash to soup - Braun does it best!

Video showcasing the Braun MultiQuick 5 Handheld Blender in action, blending various ingredients like squash for soup, demonstrating its versatility.

Using the Whisk Attachment

The whisk attachment is perfect for whipping cream, beating egg whites, and mixing light batters.

- Use the whisk in a bowl or the beaker.
- Start at a lower speed and gradually increase as needed.

Using the Mini Chopper

The mini chopper is suitable for chopping herbs, nuts, cheese, and small quantities of vegetables.

- Ensure the chopper blade is correctly seated before attaching the motor unit.
- Do not overfill the chopper bowl.

- Use short pulses for coarse chopping, or hold longer for finer results.



Image showing the Braun MultiQuick Vario 5 Handheld Blender with the mini chopper attachment, processing ingredients.

Cleaning and Maintenance

Proper cleaning ensures the longevity and hygiene of your Braun MultiQuick Vario 5.

- **Motor Body**: Always unplug the appliance before cleaning. Wipe the motor body with a damp cloth. Do not immerse it in water or other liquids.
- **Blending Wand, Whisk, Chopper, and Beaker**: These parts are dishwasher safe (top rack only) or can be washed by hand using warm water and dish soap.
- **Blades**: Handle the blending and chopper blades with extreme care as they are very sharp.
- **Storage**: Store the appliance and its attachments in a dry place.

▶ **Watch video online**

A Powerful Hand Blender w/ Attachments

Video demonstrating the ease of cleaning the Braun MultiQuick 5 Handheld Blender attachments after use.

Troubleshooting

If you encounter any issues with your appliance, please refer to the following common solutions:

Problem	Possible Cause	Solution
Appliance does not start	Not plugged in or improperly assembled.	Ensure the power cord is securely plugged into an outlet and all attachments are correctly clicked into place.
Poor blending results	Too much food or insufficient liquid.	Reduce the amount of ingredients or add more liquid. Ensure the blending wand is fully immersed and moved up and down.
Motor stops during operation	Overheating due to prolonged use or overloading.	Unplug the appliance and let it cool down for at least 15-20 minutes. Reduce the load before restarting.

Specifications

Feature	Detail
Brand	Braun
Model Number	MQ50202M
Power	500 Watts
Speeds	21 Variable Speeds + Turbo Boost
Blade Material	Stainless Steel
Color	Black
Product Dimensions	2.7"D x 2.5"W x 15.8"H
Included Components	Motor Body, Blending Stick, Whisk Attachment, Chopper, Beaker
Material Type Free	BPA Free

Warranty and Support

Your Braun MQ50202M MultiQuick Vario 5 Handheld Blender comes with a 3-Year Limited Warranty. For warranty claims, technical support, or further assistance, please contact Braun customer service or visit the official Braun website.

Please retain your proof of purchase for warranty validation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F6BZQDPS

More documents and user manuals: **https://manuals.plus/**