Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Samsung Galaxy Tab A9+

Samsung Galaxy Tab A9+ User Manual

Model: Galaxy Tab A9+

Introduction

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your Samsung Galaxy Tab A9+ tablet. Please read this manual carefully before using your device to ensure proper functionality and to maximize your user experience.
The Samsung Galaxy Tab A9+ is a versatile Android tablet designed for entertainment, productivity, and family use. It features an 11-inch display, an upgraded chipset for smooth performance, and multi-window display capabilities.

What's in the Box

Upon unboxing your Samsung Galaxy Tab A9+, please verify that all components are present:

- Samsung Galaxy A9+ Tablet
- HEXbundle 2-in-1 Stylus Pen
- Cleaning Cloth
- USB-C Charging Cable
- Quick Start Guide



Image: The Samsung Galaxy Tab A9+ tablet in Graphite color, accompanied by a HEXbundle 2-in-1 Stylus Pen and a cleaning cloth. The tablet features an 11-inch display.

Setup Guide

1. Initial Charging

Before first use, it is recommended to fully charge your Galaxy Tab A9+. Connect the USB-C charging cable to the tablet's USB-C port and the other end to a compatible power adapter (not included) or a computer's USB port.

2. Powering On and Off

- **To Power On:** Press and hold the Power button located on the side of the tablet until the Samsung logo appears.
- **To Power Off:** Press and hold the Power button, then select "Power off" from the options that appear on the screen.
- **To Restart:** Press and hold the Power button, then select "Restart" from the options.

3. Initial Setup Wizard

Upon first power-on, the tablet will guide you through an initial setup wizard. Follow the on-screen prompts to:

- Select your language.
- Connect to a Wi-Fi network.
- Sign in with your Google account or create a new one.
- Set up screen lock (PIN, pattern, password).
- Review and accept terms and conditions.

4. Inserting a microSD Card (Optional)

The Galaxy Tab A9+ supports expandable memory via a microSD card. Locate the SIM/microSD card tray on the side of the tablet. Use the provided ejection tool (if applicable) to open the tray, insert the microSD card with the gold contacts facing down, and close the tray securely.

Operating Instructions

Navigation and Gestures

- **Tap:** Touch the screen briefly to select an item or open an app.
- **Touch and Hold:** Press and hold an item to access additional options or move it.
- **Swipe:** Drag your finger across the screen to scroll or navigate between pages.
- **Pinch-to-Zoom:** Place two fingers on the screen and spread them apart to zoom in, or pinch them together to zoom out.

Multi-Window Display

The Galaxy Tab A9+ supports multi-window functionality, allowing you to run multiple apps simultaneously. To activate:

1. Open the first app.
2. Swipe up from the bottom of the screen and hold to access recent apps.
3. Tap the app icon at the top of the app's preview, then select "Open in split screen view" or "Open in pop-up view".
4. Choose a second app for split screen, or resize the pop-up window as desired.

Audio and Dolby Atmos

Experience rich sound with the tablet's quad speakers powered by Dolby Atmos. To enable or adjust Dolby Atmos settings, navigate to *Settings > Sound & vibration > Sound quality and effects > Dolby Atmos*

Samsung Kids App

The preloaded Samsung Kids app provides a safe and engaging digital environment for children. Access it from the Quick Panel or the Apps screen. Parents can set screen time limits, control content access, and monitor activity within the app.

Quick Share

Quick Share allows for easy and fast file sharing between compatible devices, including Android and iOS. To use Quick Share, select the file you wish to share, tap the share icon, and choose Quick Share. The tablet will then search for nearby compatible devices.

Maintenance and Care

Cleaning the Device

To clean your Galaxy Tab A9+, use the provided cleaning cloth or a soft, lint-free cloth. Gently wipe the screen and body. Avoid using harsh chemicals, abrasive cleaners, or aerosol sprays, as these can damage the device's finish and screen coating.

Battery Care

- Avoid exposing the tablet to extreme temperatures (hot or cold).
- Do not leave the tablet charging for extended periods after it has reached 100%.
- Use only Samsung-approved chargers and cables.

Software Updates

Regularly check for and install software updates to ensure optimal performance, security, and access to new features. Navigate to *Settings > Software update > Download and install*

Storage Management

To maintain smooth performance, periodically manage your tablet's storage. Delete unnecessary files, uninstall unused apps, and move large media files to a microSD card or cloud storage. You can check storage usage in *Settings > Battery and device care > Storage*.

Troubleshooting

Problem	Possible Solution
Tablet does not power on.	Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on again. If unresponsive, perform a forced restart by holding the Power button and Volume Down button simultaneously for about 7-10 seconds.
Screen is unresponsive or frozen.	Perform a forced restart (hold Power button and Volume Down button for 7-10 seconds). If the issue persists, consider a factory reset (*Note: This will erase all data. Back up important files first*).
Wi-Fi connection issues.	Restart your Wi-Fi router. On the tablet, turn Wi-Fi off and then on again. Forget the network and reconnect. Ensure you are within range of the Wi-Fi signal.
Apps are crashing or running slowly.	Close background apps. Clear app cache (*Settings > Apps > [App Name] > Storage > Clear cache*). Ensure sufficient storage space is available. Restart the tablet.
Battery drains quickly.	Reduce screen brightness. Disable unused features like Bluetooth or GPS. Close background apps. Check battery usage in *Settings > Battery and device care > Battery* to identify power-consuming apps.

Technical Specifications



Image: Detailed dimensions of the Samsung Galaxy Tab A9+, illustrating its width, height, and thickness, along with the 11.0-inch screen diagonal measurement.

Feature	Detail
Model Name	Samsung Galaxy Tab A9+
Display Size	11 Inches LCD
Screen Resolution	1920 x 1200 pixels (WUXGA)
Refresh Rate	Up to 90Hz
Processor	Qualcomm Snapdragon 695 (SM6375) @ 2.2 GHz
RAM	8 GB
Internal Storage	256 GB
Expandable Memory	microSD compatible
Operating System	Android 13
Battery Capacity	7040 milliampere hours
Front Camera	5 megapixels
Rear Camera	8 megapixels
Wireless Connectivity	Bluetooth, Wi-Fi (802.11g)

Feature	Detail
USB Ports	1 x USB-C
Dimensions (LxWxH)	10.12 x 6.64 x 0.27 inches
Product Weight	16.96 ounces
Color	Graphite

Warranty Information

Samsung products typically come with a limited manufacturer's warranty covering defects in materials and workmanship under normal use. The specific terms and duration of your warranty may vary by region and product. Please refer to the warranty card included with your product or visit the official Samsung support website for detailed warranty information.
Keep your proof of purchase (receipt or invoice) as it will be required for any warranty claims.

Customer Support

For further assistance, technical support, or service inquiries, please contact Samsung Customer Service through one of the following methods:

- **Online Support:** Visit the official Samsung support website for FAQs, troubleshooting guides, and software downloads. www.samsung.com/us/support/
- **Phone Support:** Refer to your product documentation or the Samsung support website for regional contact numbers.
- **Service Center:** Locate an authorized Samsung service center near you for in-person assistance.

When contacting support, please have your product model number (Galaxy Tab A9+) and serial number ready. The serial number can usually be found on the product packaging or in the tablet's settings (*Settings > About tablet > Status > Serial number*).

© 2025 Samsung. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

My Samsung Galaxy Tab A9+ home screen only shows 10 apps, but it used to show a library with all my apps including the camera. How do I get my old home screen layout back?

It sounds like your Samsung Galaxy Tab A9+ may have been switched to "Home screen only" mode, which removes the separate Apps screen (library) and places all apps on the home screen, or you...

Read full answer

Open the live page

https://manuals.plus/asin/B0F6LBSR1Y

More documents and user manuals: **https://manuals.plus/**