Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Motorola Motorola Edge 60 Pro

Motorola Edge 60 Pro User Manual

Model: Motorola Edge 60 Pro

1. Introduction

This manual provides comprehensive instructions for the safe and efficient use of your Motorola Edge 60 Pro smartphone. Please read this manual thoroughly before using your device to ensure proper operation and to maximize its features.

The Motorola Edge 60 Pro is a high-performance 5G smartphone featuring a powerful Octa-core processor, ample storage, and a high-resolution display. It is designed for international use with extensive network compatibility.



Figure 1.1: Front and back view of the Motorola Edge 60 Pro smartphone, showcasing its sleek design and camera array.

2. What's in the Box

Upon unboxing your Motorola Edge 60 Pro, verify that all components are present:

- Motorola Edge 60 Pro Smartphone
- USB Cable
- Quick Start Guide (not included in this manual)
- SIM Ejector Tool (may vary by region)

3. Setup

3.1. Inserting SIM Cards and eSIM

The Motorola Edge 60 Pro supports Dual-SIM functionality and eSIM. Ensure the device is powered off before inserting or removing physical SIM cards.

1. Locate the SIM tray on the side of your device.
2. Insert the SIM ejector tool into the small hole on the SIM tray and gently push until the tray pops out.
3. Place your Nano-SIM cards into the designated slots on the tray, ensuring the gold contacts face downwards.
4. Carefully reinsert the SIM tray into the device.
5. For eSIM activation, navigate to *Settings > Network & internet > SIMs* and follow the on-screen instructions provided by your network carrier.

Important Note:

This smartphone is not compatible with CDMA networks (e.g., Verizon, Sprint, US Cellular). Please verify network compatibility with your provider before use.



Figure 3.1: Front view of the Motorola Edge 60 Pro, highlighting the display and front camera.

3.2. Initial Power On and Configuration

1. Press and hold the Power button until the Motorola logo appears.
2. Follow the on-screen prompts to select your language, connect to a Wi-Fi network, and set up your Google account.
3. Configure security settings such as fingerprint unlock, face unlock, or a PIN/pattern/password.

4. Operating Your Device

4.1. Basic Navigation

- **Home Screen:** Swipe left or right to access app pages. Swipe down from the top for notifications and quick settings.
- **App Drawer:** Swipe up from the bottom of the home screen to view all installed applications.
- **Multitasking:** Swipe up from the bottom and hold to view recent apps.
- **Back:** Swipe from the left or right edge of the screen.

4.2. Camera Usage

The Motorola Edge 60 Pro features a versatile camera system, including a 50 MP main camera.

1. Open the Camera application.
2. Select your desired mode (Photo, Portrait, Video, etc.).
3. Tap the shutter button to capture an image or start/stop video recording.
4. Utilize the zoom function by pinching the screen or using the zoom slider.



Figure 4.1: Back view of the Motorola Edge 60 Pro, showing the camera module and Motorola logo.

4.3. Connectivity

Your device supports various connectivity options:

- **Wi-Fi:** Connect to wireless networks via *Settings > Network & internet > Internet*
- **Bluetooth:** Pair with other Bluetooth devices via *Settings > Connected devices > Connection preferences > Bluetooth*.
- **5G/4G/3G/2G Mobile Data:** Ensure your SIM is active and mobile data is enabled in Quick Settings or *Settings > Network & internet > SIMs*.
- **GPS:** Location services are enabled by default. Manage them in *Settings > Location*.

5. Maintenance

5.1. Software Updates

Regularly check for software updates to ensure optimal performance and security. Go to *Settings > System > System updates*.

5.2. Battery Care

The Motorola Edge 60 Pro is equipped with a 6000 mAh non-removable battery.

- Avoid extreme temperatures.
- Use only the provided USB cable or certified chargers.
- Do not fully discharge the battery frequently.

5.3. Cleaning Your Device

Use a soft, lint-free cloth to clean the screen and body of the phone. Avoid abrasive materials or harsh chemicals.

6. Troubleshooting

Problem	Possible Solution
Device not powering on	Ensure the battery is charged. Connect to a charger for at least 15 minutes. If unresponsive, perform a force restart by holding the Power button for 10-15 seconds.
Poor network signal	Check SIM card insertion. Ensure you are within network coverage. Try restarting the device. Verify network compatibility with your carrier.
Apps crashing or freezing	Clear the app's cache (*Settings > Apps > [App Name] > Storage & cache > Clear cache*). Update the app from the Google Play Store. If the issue persists, uninstall and reinstall the app.
Battery draining quickly	Reduce screen brightness. Close unused apps running in the background. Disable unnecessary features like GPS, Bluetooth, or Wi-Fi when not in use. Check battery usage in *Settings > Battery* to identify power-hungry apps.

7. Specifications

Feature	Detail
Model Name	Motorola Edge 60 Pro
Operating System	Android 15
Processor	Mediatek Dimensity 8350 Extreme (4 nm), Octa-core (1x3.35 GHz Cortex-A715 & 3x3.20 GHz Cortex-A715 & 4x2.20 GHz Cortex-A510)
RAM	12 GB
Internal Storage	512 GB (non-expandable)
Display	6.7 inches, P-OLED, 1220 x 2712 pixels
Main Camera	50 MP, f/1.8, 24mm (wide), 1/1.56", 1.0µm, multi-directional PDAF
Battery Capacity	6000 mAh, non-removable
Connectivity	5G, 4G LTE, 3G, 2G, Wi-Fi, Bluetooth, GPS
SIM Type	Dual-SIM (Nano-SIM) + eSIM
Color	Pantone Dazzling Blue
Weight	1.1 pounds (0.5 Kilograms)
Included in Box	USB Cable

8. Warranty and Support

For warranty information and detailed support, please refer to the official Motorola website or contact Motorola customer service. Keep your proof of purchase for warranty claims.
Online Support: www.motorola.com/support
Manufacturer: Motorola

© 2025 Motorola. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F6MW3D8J

More documents and user manuals: **https://manuals.plus/**