Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Garmin 010-02812-00

Garmin GPSMAP 67i Rugged Hiking GPS Handheld User Manual

Premium inReach Satellite Technology for Outdoor Adventures

Introduction

The Garmin GPSMAP 67i is a robust and versatile GPS handheld device designed for hiking, camping, and various outdoor activities. It integrates advanced navigation capabilities with inReach satellite communication technology, ensuring connectivity and safety in remote areas. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device.

Bundle Contents:

- Garmin GPSMAP 67i Rugged GPS Handheld with inReach Satellite Technology
- USB Charging Adapters Cube
- Microfiber Cleaning Cloth
- P-Bank Battery
- microSDHC Ultra 32GB Memory Card with Adapter



Figure 1: Garmin GPSMAP 67i and included accessories.

Setup

1. Initial Charging

Before first use, fully charge the GPSMAP 67i using the provided USB charging adapter and cable. Connect the USB cable to the device's charging port and the adapter to a power outlet. The device's battery indicator will show charging progress.

2. Powering On/Off

- To power on: Press and hold the **Power** button until the screen illuminates.
- To power off: Press and hold the **Power** button, then select **Power Off** on the screen.

3. Garmin Explore App Integration

For enhanced functionality, download the Garmin Explore app on your compatible smartphone. This app allows for trip planning, waypoint syncing, route management, and seamless communication with your GPSMAP 67i via Bluetooth and Wi-Fi.

- Download the Garmin Explore app from your smartphone's app store.
- Create a Garmin account or log in.
- Follow the on-screen instructions in the app to pair your GPSMAP 67i device.

4. inReach Activation and Subscription

To utilize the inReach satellite communication features (two-way messaging, SOS alerts, location tracking), an active satellite subscription is required. Visit the Garmin inReach website to activate your device and choose a suitable subscription plan.

- Go to explore.garmin.com on a computer.
- Follow the instructions to create an account and activate your inReach device.
- Select an inReach subscription plan that fits your needs.

Operating the Device

Basic Navigation and Interface

The GPSMAP 67i features a sunlight-readable color display and intuitive button controls. Use the directional pad and **ENTER** button for menu navigation and selection. The **PAGE** button cycles through main pages, and **MENU** provides context-sensitive options.

Two-Way Messaging

The inReach technology allows you to send and receive text messages with any cell phone number or email address, even when outside cellular coverage. Messages are transmitted via the global Iridium satellite network.

- Navigate to the **Messages** page.
- Select **New Message** and choose a contact or enter a new recipient.
- Type your message using the on-screen keyboard and select **Send**.



Figure 2: Two-way messaging on the GPSMAP 67i.

Interactive SOS Alerts

In case of emergency, you can trigger an interactive SOS alert to the Garmin ResponseSM center, a 24/7 staffed professional emergency response coordination center. This feature is crucial for safety in remote locations.

- To initiate SOS: Lift the protective cap over the **SOS** button on the side of the device.
- Press and hold the **SOS** button for several seconds until the countdown appears.
- Confirm the SOS alert. You can then exchange messages with the Garmin Response center.
- To cancel SOS: Select **Cancel SOS** on the screen and confirm.



Figure 3: Interactive SOS alert interface.

Location Sharing and Tracking

Share your real-time location with friends and family, allowing them to track your progress. You can also ping your device for your GPS location. The device uses multi-band GNSS support for improved position accuracy.

- From the main menu, navigate to**Tracking**.
- Enable tracking and configure your tracking interval.
- Send a message with your location to pre-selected contacts.



Figure 4: Location sharing and tracking on the GPSMAP 67i.

Mapping Features

The device comes preloaded with detailed TopoActive maps. You can download high-resolution satellite imagery via Wi-Fi and access additional premium mapping content with an Outdoor Maps+ subscription.

- Navigate to the **Map** page to view your current location and surrounding terrain.
- Use the zoom in/out buttons to adjust map detail.
- Connect to Wi-Fi to download additional map data or satellite imagery.

Optional inReach Weather

Request detailed weather forecasts for your current location, waypoints, or destinations directly on your GPSMAP 67i handheld using inReach connectivity. This helps you stay informed about changing conditions.



Figure 5: Requesting weather updates via inReach.

Built-in LED Flashlight

The GPSMAP 67i includes a built-in LED flashlight, useful for low-light conditions or as a beacon to signal for help. It is located on the top rear of the device.

- To activate: Press and hold the **Power** button briefly, then select the flashlight icon from the quick menu.
- Cycle through brightness levels or SOS strobe mode.



Figure 6: LED Flashlight feature.

Maintenance

Cleaning the Device

Regular cleaning helps maintain the device's performance and appearance. Use the provided microfiber cleaning cloth or a soft, lint-free cloth dampened with water. Avoid harsh chemicals or abrasive cleaners.

- Wipe the screen and device body gently.
- Ensure the charging port cover is securely closed to prevent dust and water ingress.

Battery Care

The GPSMAP 67i features a long-lasting battery. To maximize battery life and longevity:

- Avoid extreme temperatures when storing or operating the device.

- Charge the device regularly, but avoid leaving it fully discharged for extended periods.
- For long-term storage, charge the battery to approximately 50%.

Software Updates

Garmin periodically releases software updates to improve performance and add new features. Connect your device to Wi-Fi or use the Garmin Express application on your computer to check for and install updates.

- Connect the device to a Wi-Fi network via the settings menu.
- Navigate to **Settings** > **System** > **Software Update** to check for available updates.

Troubleshooting

Device Not Powering On

- Ensure the device is fully charged. Connect it to a power source for at least 30 minutes.
- Perform a soft reset by holding the **Power** button for 15 seconds.

No GPS Signal / Inaccurate Position

- Ensure you are in an open area with a clear view of the sky.
- Allow the device sufficient time to acquire satellite signals (may take longer after long periods of inactivity or significant travel).
- Check that Multi-Band GNSS is enabled in settings for improved accuracy.

inReach Messaging Issues

- Verify that you have an active inReach satellite subscription.
- Ensure the device has a clear line of sight to the sky for satellite communication.
- Check for any service outages on the Garmin inReach website.

Garmin Explore App Connectivity Problems

- Ensure Bluetooth is enabled on both your GPSMAP 67i and smartphone.
- Restart both the device and the smartphone.
- Try unpairing and re-pairing the devices in the Garmin Explore app.

Specifications

Feature	Detail
Model Number	010-02812-00
Display Size	3 Inches
Battery Life	Up to 425 Hours (in 10-minute tracking mode)
Connectivity	Bluetooth, USB, Wi-Fi, Iridium Satellite Network
GPS/GNSS	Multi-Band GNSS (GPS, Galileo, QZSS)
Mapping	Preloaded TopoActive Maps, Downloadable Satellite Imagery

Feature	Detail
Sensors	Altimeter, Barometer, 3-axis Electronic Compass
Durability	MIL-STD-810 (Thermal, Shock, Water Performance)
Dimensions	3 x 7 x 2 inches
Weight	1.52 Pounds
Memory Storage	32 GB (microSDHC Ultra included)

Warranty and Support

Limited Warranty

The Garmin GPSMAP 67i is covered by a limited warranty against defects in materials and workmanship for one year from the date of purchase. For full warranty terms and conditions, please refer to the warranty information included with your product or visit the official Garmin website.

Customer Support

For technical assistance, product registration, or additional support, please contact Garmin Customer Support through their official channels:

- **Garmin Support Website:** Visit support.garmin.com for FAQs, manuals, software updates, and contact options.
- **Phone Support:** Refer to the Garmin website for regional phone numbers and operating hours.

When contacting support, please have your device's serial number and proof of purchase available.

© 2025 Garmin Ltd. All rights reserved. Garmin and the Garmin logo are trademarks of Garmin Ltd. or its subsidiaries, registered in the USA and other countries. GPSMAP and inReach are trademarks of Garmin Ltd. or its subsidiaries.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F75H96V6

More documents and user manuals: **https://manuals.plus/**