Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PHLEX PRO B0F7LP98Y7

PHLEX PRO 15 Amp Electric Wood Chipper Shredder User Manual

Model: B0F7LP98Y7

1. Important Safety Instructions

Read all safety warnings and instructions before operating this wood chipper shredder. Failure to follow these instructions may result in electric shock, fire, and/or serious injury.

General Safety

- Always wear appropriate personal protective equipment (PPE), including safety goggles, gloves, and ear protection, during operation.
- Ensure the work area is clear of bystanders, children, and pets.
- Operate the machine on a firm, level surface.
- Do not operate the machine in wet conditions or rain.
- Keep hands, feet, and clothing away from all moving parts.
- Never feed material larger than the specified maximum cutting diameter (1.8 inches).
- Use the provided pusher tool to feed material, never your hands.
- Ensure the collection bin is correctly installed and the safety locking knob is engaged before starting the machine.
- In case of a jam or blockage, immediately turn off the power and unplug the machine before attempting to clear the obstruction.
- The machine is equipped with overload protection. If it stops unexpectedly, check for blockages and allow the motor to cool before restarting.



Figure 1: Safety Locking Knob and Overload Protection

This image illustrates the safety locking knob and the overload protection switch, which are crucial for preventing accidents and damage to the unit during operation.

2. Assembly and Setup

The PHLEX PRO Electric Wood Chipper Shredder requires minimal assembly. All necessary accessories are included in the package.

Included Components:

- Main Shredder Unit
- Collection Bin (50L / 10 Gallon)
- Wheels and Axle
- Support Legs
- Pusher Tool

- Safety Goggles
- Gloves
- Phillips Screwdriver
- Wrench
- Earplugs
- Apron
- Cleaning Cloths

Assembly Steps:

1. Attach the support legs and wheels to the main unit using the provided hardware and tools (screwdriver, wrench).
2. Ensure all connections are secure.
3. Slide the collection bin into its designated position beneath the shredder unit until it locks securely.
4. Verify that the safety locking knob is functional and properly engages the collection bin.



Figure 2: Product Parameters and Included Accessories

This diagram provides an overview of the product's dimensions and lists all components included in the package, facilitating easy identification during assembly.

3. Operating Instructions

Follow these steps for safe and effective operation of your PHLEX PRO Electric Wood Chipper Shredder.

Preparation:

- Place the shredder on a stable, level surface.
- Ensure the collection bin is empty and properly secured.
- Wear all recommended PPE (safety goggles, gloves, ear protection, apron).
- Connect the power cord to a suitable 120V~60Hz outlet.

Shredding Process:

1. Turn on the machine using the power switch.
2. Carefully feed branches, leaves, or other yard waste into the feeding chute. Do not force material.
3. For thicker branches (up to 1.8 inches), feed them slowly and steadily. Use the pusher tool to guide material into the blades, keeping hands clear of the opening.
4. The machine will shred material into fine mulch, which collects in the 50L bin.
5. Monitor the collection bin and empty it when full to prevent blockages and maintain optimal performance.



Figure 3: Shredding Branches up to 1.8 Inches

This image shows the proper technique for feeding branches into the shredder, highlighting its capacity for materials up to 1.8 inches in diameter.



Figure 4: Multiple Shredding Purposes

This visual guide illustrates the various types of organic material the shredder can process, including branches, leaves, shrubs, and straw.



Figure 5: Material Reduction Ratio

This image visually represents the shredder's efficiency, converting a large volume of garden waste into a significantly smaller amount of nutrient-rich mulch.

Official Product Video:

▶ **Watch video online**
Garden Wood Chipper

Video 1: Garden Wood Chipper in Operation

This video, provided by PHLEX PRO, demonstrates the wood chipper shredder in action, showcasing its performance and ease of use for various garden waste materials.

4. Maintenance

Regular maintenance ensures the longevity and optimal performance of your wood chipper shredder.

Cleaning:

- Always unplug the machine before cleaning.
- Use the provided cleaning cloths to wipe down the exterior of the machine.
- Clear any debris from the feeding chute and discharge area.
- Empty and clean the collection bin after each use.



Figure 6: Easy-to-Clean Collection Bin

This image highlights the removable 10-gallon collection bin, designed for convenient emptying and cleaning after use.

Blade Inspection:

- Periodically inspect the shredder blades for wear or damage.
- Dull or damaged blades can reduce efficiency and increase motor strain. Refer to a qualified service technician for blade replacement or sharpening.

Storage:

- Store the wood chipper shredder in a dry, secure location, away from moisture and extreme temperatures.
- Keep it out of reach of children.

5. Troubleshooting

This section addresses common issues you might encounter during operation.

Problem	Possible Cause	Solution
Machine does not start	No power supply; Overload protection activated; Safety locking knob not engaged	Check power connection; Reset overload protection (allow motor to cool); Ensure collection bin is correctly seated and locked.
Machine stops during operation	Overload protection activated; Material jam	Turn off and unplug. Clear any jammed material. Allow motor to cool before restarting. Reduce feeding rate.
Poor shredding performance	Dull blades; Incorrect material feeding	Inspect blades for wear (contact service for replacement); Feed material slowly and steadily.
Smoking or sparking from motor	Overload; Internal fault	Immediately turn off and unplug the machine. Do not attempt to operate. Contact customer support or a qualified technician.

6. Specifications

Key technical details of the PHLEX PRO Electric Wood Chipper Shredder.

Feature	Detail
Model	B0F7LP98Y7
Power Source	Corded Electric
Motor	15 Amp, 1800W
No-Load Speed	4500 RPM
Max. Cutting Diameter	1.8 inches (45mm)
Collection Bin Capacity	10 Gallons (50 Liters)
Item Dimensions (D x W x H)	22" x 18" x 32"
Item Weight	26 pounds
Enclosure Material	Plastic
Special Features	Portable, Eco-Friendly Design, Safety Features (Safety Locking Knob, Overload Protection)



Figure 7: 15-Amp Brushless Motor

This image provides a detailed view of the powerful 15-Amp brushless motor, a core component of the shredder's performance.

7. Warranty Information

For detailed warranty information, please refer to the documentation included with your purchase or contact PHLEX PRO customer support. Protection plans may be available for extended coverage.

8. Customer Support

If you have any questions, require assistance, or need to report an issue, please contact PHLEX PRO customer support through the retailer where the product was purchased or visit the official PHLEX PRO store online.
PHLEX PRO Store: Visit PHLEX PRO Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F7LP98Y7

More documents and user manuals: **https://manuals.plus/**