Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LEXiBOOK SD50D

Lexibook Disney Stitch Electronic Diary SD50D Instruction Manual

Model: SD50D

1. Safety Information

WARNING! Not suitable for children under 3 years. Choking hazard due to small parts.

2. What's in the Box

- 1 Electronic Diary
- 1 Pen
- 1 Instruction manual

3. Setup

1. Remove the diary from its packaging.
2. Insert the included pen and notebook into the diary.
3. Set a customizable 4-digit password to protect your secrets.
4. Insert a photo into the built-in photo frame to personalize the diary.



Figure 1: Electronic Diary, pen, and notebook as packaged.

The diary comes with a pen and a notebook. Ensure these are properly placed within the diary's compartments. The photo frame allows for personalization by inserting a preferred image.

4. Operating Instructions

4.1. Setting and Using the Password

The diary is protected by a customizable 4-digit code. To set or change the password, refer to the specific instructions provided in the included manual. Once set, enter the 4-digit code to open the diary.



Figure 2: The diary's keypad for password entry and interactive functions.

4.2. Writing in the Notebook

Use the provided pen to write in the included notebook. The notebook can be replaced when full, ensuring continuous use of the diary.



Figure 3: A child using the diary to write in the notebook.

4.3. Interactive Features

- **Melodies:** The diary includes 10 pre-programmed melodies.
- **Voice Recorder:** Record and playback voice messages.
- **Voice Modifier:** Alter recorded voice messages for entertainment.

These features are accessed via the buttons located on the side panel of the diary.



Figure 4: Detail of the interactive buttons on the diary.

5. Maintenance

- Keep the diary clean by wiping it with a soft, dry cloth.
- Avoid exposing the diary to extreme temperatures or direct sunlight.
- Ensure the battery compartment is securely closed to prevent dust or moisture ingress.
- Replace batteries when the device's performance diminishes.

6. Troubleshooting

6.1. Password Issues

If the password is forgotten or not working, locate the reset button (usually a small pinhole) on the back of the device. Use a paperclip or similar thin object to press and hold the reset button for a few seconds. This will typically reset the password to a default setting (e.g., "0000") or allow you to set a new one. Refer to the specific instructions for your

model for exact reset procedures.

6.2. Device Not Responding

If the diary is unresponsive, check the batteries. Ensure they are correctly inserted and have sufficient charge. Replace with new batteries if necessary. If the issue persists, perform a reset as described in section 6.1.

6.3. Sound or Recording Problems

Check the volume settings. Ensure the microphone is not obstructed during recording. If issues persist, a device reset may resolve the problem.

7. Specifications

Feature	Detail
Product Dimensions	4.63 x 7.93 x 1.46 inches
Item Weight	12.7 ounces
Model Number	SD50D
Manufacturer Recommended Age	6 years and up
Release Date	May 14, 2025
Manufacturer	Lexibook

8. Warranty and Support

For warranty information and customer support, please refer to the manufacturer's official website or contact their customer service department. Details are typically provided in the product packaging or on the manufacturer's website.

9. Product Videos

Lexibook, Disney Stitch, Stitch Electronic Diary SD50D

Your browser does not support the video tag.

This video provides an overview of the Lexibook Disney Stitch Electronic Diary, highlighting its key features and design, including the password protection and interactive elements.

© 2025 Lexibook. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F7QTVLKQ

More documents and user manuals: **https://manuals.plus/**