Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MERACH W50 TrekPad

MERACH W50 TrekPad Walking Pad Treadmill User Manual

Model: W50 TrekPad | Brand: MERACH

1. Introduction

Thank you for choosing the MERACH W50 TrekPad Walking Pad Treadmill. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your new fitness equipment. Please read this manual thoroughly before use and retain it for future reference.



Figure 1.1: MERACH W50 TrekPad Walking Pad Treadmill

2. Important Safety Information

To reduce the risk of serious injury, read all important precautions and instructions in this manual before using the treadmill. MERACH assumes no responsibility for personal injury or property damage sustained by or through the use of this product.

- Always place the treadmill on a level, stable surface.
- Keep children and pets away from the treadmill during operation.
- Wear appropriate athletic footwear and clothing.
- Do not operate the treadmill if it has a damaged cord or plug, or if it is not working properly.
- Consult a physician before beginning any exercise program.
- Do not use the treadmill outdoors or in damp areas.
- Ensure the safety key is properly attached before starting the treadmill.

3. Package Contents

Verify that all components are present in the package:

- User Manual
- Power Cord
- Remote Control
- Tool Kit

4. Product Features

The MERACH W50 TrekPad is engineered with advanced features for an optimal home workout experience:

- **400 lbs Heavy-Duty Support:** Industrial-grade steel frame and a 16.5-inch professional running belt ensure supreme stability and durability, supporting users up to 400 lbs.
- **3.5 HP Brushless Motor:** Experience ultra-low noise (25 dB) and zero overheating with a commercial-grade brushless motor, allowing for up to 10 hours of nonstop operation.
- **12% Auto-Incline:** Remote-controlled incline adjustments (0-12%) allow for varied workouts, burning up to 30% more calories and reducing knee strain.
- **Multi-Zone Cushioning:** A professional cushioning frame and 6-layer shock-absorbing non-slip belt significantly reduce joint pressure and protect knees/ankles.
- **Anti-Fold Design + Transport Wheels:** Certified and sturdier than foldable models, with industrial-grade wheels for easy mobility and storage.

Detailed Feature Overview



Figure 4.1: Robust internal structure supporting 400 lbs and featuring a 3.5HP motor.



Figure 4.2: The 12% auto-incline feature enhances calorie burn and provides knee protection.



Figure 4.3: The 16.5-inch wide running belt offers a spacious and comfortable workout surface.



Figure 4.4: Multi-layer cushioning technology reduces ankle stress by 30% for cloud-like comfort.



Figure 4.5: The compact design (2.9 sq ft cover area) and whisper-quiet operation (<25dB) make it ideal for home use.

Product Videos

▶ **Watch video online**

Before&After Using MERACH W50 cr.Sierra2fit

Video 4.1: Demonstrates the transformation and benefits of using the MERACH W50 TrekPad for fitness.

▶ **Watch video online**

MERACH W50-Heavy Duty Performance 400lbs--cr.Sierra2fit

Video 4.2: Highlights the heavy-duty performance and 400 lbs capacity of the MERACH W50 TrekPad.

5. Specifications

Attribute	Value
Brand	MERACH
Model Name	W50 TrekPad
Product Dimensions	50.2"D x 22.2"W x 6.1"H
Item Weight	69.2 Pounds
Material	Alloy Steel
Maximum Speed	4 Miles per Hour
Minimum Speed	0.6 Miles per Hour
Maximum Horsepower	3.5 Horsepower
Maximum Incline Percentage	12%
Maximum Weight Recommendation	400 Pounds
Noise Level	<25 dB
Running Belt Width	16.5 inches
Assembly Required	No

6. Setup Instructions

1. **Unboxing:** Carefully remove the treadmill and all components from the packaging.
2. **Placement:** Choose a flat, stable surface for the treadmill, ensuring adequate clearance around the unit (at least 2 feet on all sides).
3. **Power Connection:** Plug the power cord into the treadmill's power input, then into a grounded electrical outlet.
4. **Safety Key:** Ensure the safety key is properly placed in its designated slot on the treadmill. The treadmill will not operate without the safety key.

7. Operating Instructions

Your MERACH W50 TrekPad is designed for ease of use with its remote control and integrated display.

1. **Power On:** Ensure the treadmill is plugged in and the safety key is in place. Press the power button on the treadmill or remote control to turn it on.
2. **Start/Stop:** Press the START/STOP button on the remote to begin or end your workout.
3. **Adjust Speed:** Use the '+' and '-' buttons on the remote control to increase or decrease the walking speed. The speed range is 0.6 to 4.0 MPH.
4. **Adjust Incline:** Use the incline '+' and '-' buttons on the remote control to adjust the incline level from 0% to 12%.

5. **Monitoring Progress:** The integrated LED display shows key metrics such as speed, incline, calories burned, time, and distance.
6. **App Integration:** For full workout insights, download the MERACH APP and sync it with your treadmill. The app also supports integration with Google Fit and Apple Health.



Figure 7.1: Track and treasure every move with the HD LED display and dedicated app sync.

8. Maintenance

Regular maintenance ensures the longevity and optimal performance of your treadmill.

- **Cleaning:** Wipe down the treadmill with a damp cloth after each use to remove sweat and dust. Do not use abrasive cleaners.
- **Belt Lubrication:** Periodically check the running belt for proper lubrication. Refer to the specific instructions in your included user manual for lubrication frequency and procedure.
- **Belt Tension:** Ensure the running belt is properly tensioned and centered. Adjust if necessary according to the detailed instructions in your manual.
- **Storage:** When not in use, store the treadmill in a dry, clean area. Utilize the transport wheels for easy relocation.

9. Troubleshooting

If you encounter issues with your treadmill, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Treadmill does not power on	Power cord not connected; Safety key not in place; Power outlet issue	Check power cord connection; Ensure safety key is fully inserted; Test outlet with another device
Running belt slips or stops	Belt too loose; Insufficient lubrication	Adjust belt tension; Lubricate the running belt

Unusual noise during operation	Loose parts; Motor issue; Belt misalignment	Check for loose screws and tighten; Contact customer support if motor noise persists; Adjust belt alignment
Remote control not working	Dead batteries; Interference	Replace batteries; Ensure no obstructions between remote and treadmill

If the problem persists after attempting these solutions, please contact MERACH customer support.

10. Warranty and Support

The MERACH W50 TrekPad Walking Pad Treadmill comes with a**1-Year Warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use.
For warranty claims, technical assistance, or any questions regarding your product, please contact MERACH customer support through the official MERACH website or your purchase platform. Please have your model number and proof of purchase ready when contacting support.

© 2025 MERACH. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F7RLHCCQ

More documents and user manuals: **https://manuals.plus/**