Manuals+
Q & A | Deep Search | Upload

Paladone 14451

Paladone Hello Kitty Digital Alarm Clock with Night Light

Model: 14451

Introduction

This manual provides instructions for the setup, operation, and maintenance of your Paladone Hello Kitty Digital Alarm Clock with Night Light. Please read this manual thoroughly before using the product to ensure proper function and longevity.

Image: The Paladone Hello Kitty Digital Alarm Clock with Night Light, featuring a pink base with a digital display and a Hello Kitty figure on top.

Setup

Battery Installation

The alarm clock requires 3 AA batteries (not included) for operation. No external power cables are needed.

1. Locate the battery compartment on the underside of the alarm clock.
2. Open the battery compartment cover.
3. Insert 3 new AA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Close the battery compartment cover securely.

Note: Always use fresh batteries and replace all three batteries at the same time. Do not mix old and new batteries or different types of batteries.

Operating Instructions

Controls Overview

The control buttons are located on the front panel below the digital display:

- **Time Icon Button:** Used to set the current time.
- **Alarm Icon Button:** Used to set the alarm time.
- **Minus (-) Button:** Decreases values during setting.
- **Plus (+) Button:** Increases values during setting.

Setting the Time

1. Press and hold the **Time Icon Button** until the hour digits begin to flash.
2. Use the **Plus (+)** or **Minus (-) Buttons** to adjust the hour.
3. Press the **Time Icon Button** again to move to the minute digits.
4. Use the **Plus (+)** or **Minus (-) Buttons** to adjust the minutes.
5. Press the **Time Icon Button** one more time to confirm and exit time setting mode.

Setting the Alarm

1. Press and hold the **Alarm Icon Button** until the alarm hour digits begin to flash.
2. Use the **Plus (+)** or **Minus (-) Buttons** to adjust the alarm hour.
3. Press the **Alarm Icon Button** again to move to the alarm minute digits.
4. Use the **Plus (+)** or **Minus (-) Buttons** to adjust the alarm minutes.
5. Press the **Alarm Icon Button** one more time to confirm and exit alarm setting mode.
6. To activate or deactivate the alarm, briefly press the**Alarm Icon Button**. An alarm icon will appear or disappear on the display.

Using the Night Light and Snooze Function

Image: The Hello Kitty figure on the alarm clock glowing as a night light.

- **Night Light:** To activate the soft night light, gently press down on the head of the Hello Kitty figure. Press again to turn it off.
- **Snooze Function:** When the alarm sounds, pressing down on the Hello Kitty figure's head will activate the snooze function, temporarily silencing the alarm for a short period before it sounds again.

Video Demonstration

Your browser does not support the video tag.

Video: A demonstration of the Paladone Hello Kitty Alarm Clock and Night Light features, including time setting and night light activation.

Features

- **Digital Display:** Clear and easy-to-read digital time display.
- **Musical Alarm:** Wakes you up with a pleasant musical tone.
- **Night Light Function:** Hello Kitty figure illuminates to provide a soft, calming light.
- **Snooze Function:** Tap Hello Kitty's head to temporarily pause the alarm.

- **Battery Operated:** Cordless design for flexible placement (requires 3 AA batteries, not included).

Maintenance

- **Cleaning:** Wipe the clock with a soft, dry cloth. Do not use abrasive cleaners or immerse in water.
- **Battery Replacement:** Replace batteries when the display dims or the clock functions become erratic. Follow the battery installation steps in the Setup section.
- **Storage:** If storing the clock for an extended period, remove the batteries to prevent leakage.

Troubleshooting

- **Clock not turning on/display is blank:**
  Ensure batteries are correctly installed with proper polarity. Replace with fresh batteries.
- **Alarm not sounding:**
  Verify that the alarm time is set correctly and the alarm function is activated (alarm icon visible on display). Check battery level.
- **Night light not working:**
  Ensure batteries are fresh. Press firmly on Hello Kitty's head.
- **Incorrect time display:**
  Reset the time following the 'Setting the Time' instructions.

Specifications

Image: Product dimensions of the Hello Kitty Alarm Clock.

Feature	Detail
Brand	Paladone
Model Number	14451
Display Type	Digital
Special Features	Illuminated, Musical, Snooze
Product Dimensions	3.54"W x 6.22"H (9cm W x 15.6cm H)
Power Source	Battery Powered
Batteries Required	3 AA batteries (not included)
Material	Plastic
Item Weight	8.1 ounces

Warranty and Support

For warranty information or product support, please refer to the packaging or contact Paladone customer service directly. Keep your purchase receipt as proof of purchase.

For more information about Paladone products, visit their official store:Paladone Store

© 2026 Paladone. All rights reserved.