Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Thermaltake T6BK-X87B-580-LCS

Thermaltake Reactor 9080 Gaming Desktop User Manual

Model: T6BK-X87B-580-LCS

1. Introduction

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Thermaltake Reactor 9080 Gaming Desktop. Please read this manual thoroughly before using the product to ensure proper functionality and longevity.

The Thermaltake Reactor 9080 is a high-performance gaming desktop featuring an AMD Ryzen™ 9 9900X3D processor, NVIDIA® GeForce RTX™ 5080 graphics card, 32GB DDR5 6400MT/s RGB memory, and a 2TB NVMe M.2 SSD, running on Windows 11. Its unique octagonal prism design is engineered for optimal cooling and performance.



Image 1.1: Full view of the Thermaltake Reactor 9080 Gaming Desktop.

2. Safety Information

Observe the following safety precautions to prevent damage to the product and ensure user safety:

- Always disconnect the power cable from the wall outlet before cleaning or performing any maintenance.
- Do not expose the desktop to water, moisture, or extreme temperatures.
- Ensure proper ventilation around the desktop to prevent overheating. Do not block any ventilation openings.
- Use only the power supply unit provided with the system or a certified replacement.
- Avoid placing heavy objects on the desktop or power cables.
- If you encounter any issues, refer to the troubleshooting section or contact customer support. Do not attempt to repair the system yourself unless specifically instructed.

3. Package Contents

Verify that all items are present in the package:

- Thermaltake Reactor 9080 Gaming Desktop
- Power Cable
- Documentation (Quick Start Guide, Warranty Information)
- RGB Lighting (pre-installed)

4. Component Overview

4.1 External Components

The Reactor 9080 features a distinctive octagonal prism shape with tempered glass panels for panoramic views and perforated side panels for excellent airflow.



Image 4.1: Front panel connectivity ports.

Front I/O Ports:

- 1x USB 3.2 Gen 2 Type-C Port
- 2x USB 3.0 Type-A Ports
- 1x Headphone/Line Out Jack
- 1x Microphone/Line In Jack
- Power Button
- Reset Button



Image 4.2: Rear view of the desktop, showing various I/O ports and fan exhaust.

4.2 Internal Components

The internal layout is designed for efficient cooling and easy access to components.



Image 4.3: Close-up internal view showing RGB RAM modules and the CPU liquid cooler.



Image 4.4: View of the rear of the motherboard tray, illustrating clean cable management.

5. Setup Instructions

Follow these steps to set up your Thermaltake Reactor 9080 Gaming Desktop:

1. **Unpack the Desktop:** Carefully remove the desktop and all accessories from the packaging. Retain the packaging for future transport or warranty claims.
2. **Place the Desktop:** Position the desktop on a stable, flat surface with adequate ventilation. Ensure that the front, rear, and side panels are not obstructed.
3. **Connect Peripherals:**
    - Connect your monitor(s) to the graphics card's DisplayPort or HDMI outputs.
    - Connect your keyboard and mouse to the available USB ports.
    - Connect any other peripherals such as speakers, headphones, or external drives.
4. **Connect to Network:** Connect an Ethernet cable to the LAN port on the rear I/O panel for a wired internet connection, or ensure your Wi-Fi antenna is connected for wireless connectivity.
5. **Connect Power:** Plug the power cable into the power supply unit on the rear of the desktop, then plug the other end into a grounded electrical outlet.
6. **Power On:** Press the power button located on the top front panel of the desktop. The system will boot into Windows 11.

6. Operating Instructions

Your Thermaltake Reactor 9080 comes pre-installed with Windows 11. Upon first boot, you may need to complete the initial Windows setup process, including creating a user account and connecting to a network.

- **First-Time Setup:** Follow the on-screen prompts to personalize your Windows 11 experience.
- **Software Installation:** Install any necessary drivers or software from the manufacturer's website if not already pre-installed.
- **System Updates:** Regularly check for and install Windows updates and driver updates for your graphics card and other components to ensure optimal performance and security.
- **RGB Lighting Control:** Utilize the pre-installed software (if applicable) to customize the RGB lighting effects of your memory, fans, and CPU cooler.

7. Maintenance

Regular maintenance helps ensure the longevity and performance of your desktop.

- **Cleaning:**
    - Use a soft, dry cloth to wipe down the exterior of the case.
    - Use compressed air to clean dust from fan vents and internal components periodically. Ensure the system is powered off and unplugged before cleaning.
- **Software Updates:** Keep your operating system, drivers (especially graphics drivers), and security software up to date.
- **Data Backup:** Regularly back up important data to an external drive or cloud storage to prevent data loss.

8. Troubleshooting

This section addresses common issues you might encounter.

Issue	Possible Cause	Solution
System does not power on	Power cable not connected, power supply switch off, faulty power outlet.	Check power cable connections, ensure power supply switch is on, try a different power outlet.
No display on monitor	Monitor cable loose, monitor off, incorrect input selected on monitor, graphics card issue.	Ensure monitor cables are securely connected to the graphics card, turn on monitor, select correct input, test with another monitor if possible.
System crashes or freezes frequently	Overheating, outdated drivers, software conflicts, hardware malfunction (e.g., GPU, RAM).	Ensure proper airflow, update all drivers (especially graphics), check for Windows updates, run system diagnostics. If issues persist, contact support.
Poor gaming performance	Outdated graphics drivers, high background processes, incorrect game settings.	Update graphics drivers, close unnecessary background applications, adjust in-game graphics settings.

9. Specifications

Detailed technical specifications for the Thermaltake Reactor 9080 Gaming Desktop:



Image 9.1: Overview of key specifications.

Component	Specification
Processor	AMD Ryzen™ 9 9900X3D (4.4 GHz)
Graphics Card	NVIDIA® GeForce RTX™ 5080 (16 GB GDDR6X)
Motherboard	AMD X870 Chipset
Memory	32GB DDR5 6400MT/s RGB RAM

Component	Specification
Storage	2TB NVMe M.2 SSD
Operating System	Windows 11 Home
Cooling	Closed Loop Liquid Cooling with 360mm Radiator
Connectivity	Wi-Fi, Ethernet, USB 3.2 Gen 2 Type-C, USB 3.0 Type-A, Audio Jacks
Dimensions (H x W x D)	21.65" x 11.28" x 16.54" (550mm x 286.4mm x 420mm)
Weight	51.2 pounds



Image 9.2: Diagram illustrating the case dimensions.

10. Warranty and Support

Thermaltake products are designed for reliability and performance. This product typically includes a standard manufacturer's warranty. Additional protection plans may be available for purchase.

- **Warranty Information:** Refer to the warranty card included in your package for specific terms and conditions. A 3-Year Protection Plan may be available for extended coverage.
- **Technical Support:** For technical assistance, troubleshooting beyond this manual, or warranty claims, please visit the official Thermaltake support website or contact their customer service.
- **Online Resources:** Visit the Thermaltake Store on Amazon for product information and updates.

© 2025 Thermaltake. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F8RKJVYG

More documents and user manuals: **https://manuals.plus/**