Braun HF5050

Braun HF5050 MultiFry 5 Air Fryer Instruction Manual

Model: HF5050

1. Introduction

Thank you for choosing the Braun HF5050 MultiFry 5 Air Fryer. This appliance is designed to provide a versatile and efficient cooking experience, allowing you to air fry, roast, and bake with minimal oil. Please read this manual thoroughly before first use to ensure safe operation and optimal performance. Keep this manual for future reference.

Important Safety Instructions

- Always place the appliance on a stable, level, heat-resistant surface, away from walls or other appliances to allow adequate ventilation.
- Do not immerse the main unit in water or any other liquid. Clean with a damp cloth only.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Keep children and pets away from the appliance during operation. The exterior surfaces can become hot.
- Do not block the air inlet or outlet vents during operation.
- Unplug the appliance from the power outlet when not in use and before cleaning.
- Do not operate the appliance if the plug, power cord, or the appliance itself is damaged. Contact authorized service personnel for repair.
- Only use accessories recommended by the manufacturer.

2. Product Overview

The Braun HF5050 MultiFry 5 is a versatile kitchen appliance designed for air frying, roasting, and baking. It features a touch control panel and a spacious 5.7-liter capacity cooking basket.



Figure 2.1: Front view of the Braun HF5050 MultiFry 5 Air Fryer, showing the digital display, touch control panel, and handle. The display shows '220' and various cooking icons.

Components and Controls

- **Main Unit:** Houses the heating element and fan.
- **Control Panel:** Digital display with touch-sensitive buttons for power, mode selection, temperature, and timer adjustments.
- **Cooking Basket:** Removable, non-stick coated basket with a handle for easy food placement and removal. The basket material is PTFE.

- **Air Inlet/Outlet Vents:** Located on the top and rear of the appliance for proper air circulation.

The control panel includes dedicated buttons for "Air Fry" and "Fast Oven" modes, along with icons for various pre-set cooking programs. The digital display shows temperature and time settings.

3. Setup and First Use

Unpacking

1. Carefully remove the air fryer and all packaging materials from the box.
2. Remove any stickers or labels from the appliance.
3. Inspect the appliance for any damage. Do not use if damaged.

Initial Cleaning

1. Wash the cooking basket and any removable accessories in warm, soapy water. These parts are dishwasher safe.
2. Wipe the interior and exterior of the main unit with a damp cloth.
3. Ensure all parts are thoroughly dry before use.

Placement

- Place the air fryer on a stable, heat-resistant, non-metallic surface.
- Ensure there is at least 10 cm (4 inches) of clear space around the back and sides of the appliance to allow for proper air circulation.
- Do not place the appliance near flammable materials or heat sources.

4. Operating Instructions

Basic Operation

1. **Plug In:** Connect the power cord to a grounded electrical outlet. The appliance will emit a beep, and the display will illuminate briefly.
2. **Power On:** Press the **Power button** () to turn on the appliance. The display will show default settings or the last used settings.
3. **Place Food:** Pull out the cooking basket using the handle. Place your ingredients into the basket. Do not overfill.
4. **Insert Basket:** Push the cooking basket firmly back into the appliance until it clicks into place.

Selecting Cooking Modes and Programs

- **Manual Mode:**
  a. Press the **"Air Fry"** or **"Fast Oven"** button to select the desired cooking mode.
  b. Use the temperature control buttons (/) to adjust the temperature between 80°C and 220°C.
  c. Use the timer control buttons (/) to set the cooking time.
- **Pre-set Programs:** The appliance features 15 pre-set programs for common dishes.
  a. Press the **Mode button** () repeatedly to cycle through the available pre-set programs. Each program has a default temperature and time.

b. You can adjust the temperature and time of a pre-set program if needed.

Starting and Pausing Cooking

- **Start:** Once settings are chosen, press the **Start/Pause button** () to begin cooking. The fan and heating element will activate.
- **Pause:** To pause cooking, press the **Start/Pause button** again. The appliance will stop, allowing you to check or shake the food. Press again to resume.
- **Automatic Shut-off:** The appliance will automatically shut off and beep when the set cooking time has elapsed.

Dehydration Function

The Braun HF5050 MultiFry 5 includes a dehydration function. Refer to the specific program settings for dehydration in the pre-set program list or manually set a low temperature for an extended period.

5. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the lifespan of your appliance. Always unplug the air fryer and allow it to cool completely before cleaning.

Cleaning the Cooking Basket and Accessories

- The cooking basket and any removable accessories are dishwasher safe.
- Alternatively, wash them in hot, soapy water using a non-abrasive sponge.
- For stubborn food residue, soak the basket in warm water for about 10 minutes before cleaning.
- Ensure all parts are completely dry before reassembling or storing.

Cleaning the Main Unit

- Wipe the exterior of the appliance with a damp cloth and mild detergent.
- Clean the interior with a damp cloth. Avoid using abrasive cleaners or scouring pads, as these can damage the non-stick coating.
- If necessary, use a soft brush to clean the heating element, ensuring the appliance is unplugged and cool.
- Never immerse the main unit in water or any other liquid.

Storage

Store the cleaned and dried air fryer in a cool, dry place. Ensure the power cord is neatly wrapped and not kinked.

6. Troubleshooting

If you encounter issues with your Braun HF5050 MultiFry 5, please consult the following table before contacting customer support.

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet not working; power button not pressed.	Ensure the power cord is securely plugged into a working outlet. Press the Power button.

Problem	Possible Cause	Solution
Food is not cooked evenly.	Basket overloaded; food not shaken/turned during cooking.	Do not overload the basket. Shake or turn food halfway through cooking for even results.
White smoke coming from the appliance.	Fat residue from previous use; high-fat ingredients.	Clean the basket and interior thoroughly. For high-fat foods, ensure excess fat is drained.
Food is not crispy.	Too much moisture; insufficient oil; incorrect temperature/time.	Pat food dry before cooking. Lightly coat with oil. Adjust temperature and time as per recipe.

7. Technical Specifications

Feature	Specification
Brand	Braun
Model Number	HF5050
Product Type	Air Fryer / Fast Oven
Capacity	5.7 Liters (1.6 kg fries / 1.5 kg chicken)
Power	2000 Watts
Voltage	220-240 Volts AC
Temperature Range	80°C - 220°C
Control Type	Touch Display
Number of Programs	15
Special Features	Dehydration Function, Automatic Shut-off, Dishwasher-safe parts
Material	Stainless Steel (exterior), PTFE (non-stick bowl)
Dimensions (W x D x H)	280 mm x 270 mm x 335 mm
Weight	5.05 kg

8. Warranty and Customer Support

Braun products are manufactured to the highest quality standards. For detailed information regarding your product's warranty, please refer to the warranty card included with your purchase or visit the official Braun website.

For technical assistance, troubleshooting beyond this manual, or to inquire about spare parts, please contact Braun customer support in your region. Contact information can typically be found on the Braun website or in the documentation provided with your appliance.

Please have your model number (HF5050) and purchase date available when contacting support.

© 2025 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question