Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun 62-B1200s

Braun Series 6 Electric Shaver for Men, Model 62-B1200s

User Instruction Manual

Introduction

This manual provides essential information for the safe and effective use of your Braun Series 6 electric shaver, model 62-B1200s. Designed for a comfortable and close shave, this device features advanced technology for skin comfort and versatility. Please read these instructions thoroughly before first use and keep them for future reference.



The Braun Series 6 shaver, highlighting its 2D SkinFlex technology and dual shave modes for a comfortable and gentle experience.

Safety Information

To reduce the risk of electric shock, injury, or fire, please observe the following safety precautions:

- This appliance is suitable for cleaning under running water and for use in a bath or shower. For safety reasons, the shaver can only be operated cordless when used with water.
- Unplug the shaver before using it with water.
- Keep the power supply, charging stand, and cleaning station dry.
- Your shaver is equipped with a special cord set, which has an integrated Safety Extra Low Voltage power supply. Do not exchange or manipulate any part of it. Otherwise, there is a risk of electric shock.
- Only use the Braun power supply type 492 provided.
- Do not use if the appliance or any accessory is damaged.
- Do not disassemble or open the appliance.

- The rechargeable battery in the appliance must only be replaced by an authorized Braun Service Centre.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children unless they are supervised.

Package Contents

Your Braun Series 6 shaver package includes the following items:

- Braun Series 6 Electric Shaver
- Precision Trimmer Attachment
- Travel Case
- Charger (Power Supply Type 492)
- Cleaning Brush



All items included in the Braun Series 6 shaver package.

Setup

Charging the Shaver

Before first use, fully charge your shaver. Connect the charger to the shaver and plug it into an electrical outlet. A full charge takes approximately 1 hour and provides up to 60 minutes of cordless shaving. A 5-minute quick charge is sufficient for one shave.

Attaching the Precision Trimmer

To attach the precision trimmer, remove the shaver head by pressing the release buttons on the sides. Align the precision trimmer attachment with the shaver body and press it firmly until it clicks into place.

Operating Instructions

Basic Shaving

For an optimal shave, hold the shaver at a right angle (90°) to your skin and shave against the direction of hair growth. Apply gentle, even pressure. The 2D ContourAdapt head minimizes pressure for a close and comfortable shave.



The shaver head features 3 flexible blades and adapts to facial contours for a close and comfortable shave.

Shaving Modes

The Braun Series 6 offers two shaving modes:

- **Turbo Mode:** Provides an extra fast shave for dense beards.
- **Gentle Mode:** Offers a particularly pleasant and gentle shave, ideal for sensitive skin.

Press the mode selection button to switch between Turbo and Gentle modes.



The shaver's control panel showing the options for Turbo Mode and Gentle Mode.

Wet and Dry Use

The shaver is 100% waterproof, allowing for both dry shaving and wet shaving with foam or gel, or even in the shower. For wet use, ensure the shaver is unplugged from the power supply.

Using the Precision Trimmer

Once attached, the precision trimmer can be used for shaping sideburns, mustaches, or for pre-trimming longer hairs before shaving. Turn on the shaver and carefully guide the trimmer along the desired lines.

Maintenance

Cleaning the Shaver

Regular cleaning ensures optimal performance. After each use, especially with foam or gel, rinse the shaver head under warm running water. You can also use the included cleaning brush to remove stubborn hair particles from the shaver head. Ensure

the shaver is switched off and unplugged before cleaning.



The shaver is fully waterproof and can be easily cleaned under running water.

Battery Care

To maintain battery life, avoid completely discharging the battery frequently. For long-term storage, charge the shaver fully every 6 months.

TROUBLESHOOTING

- **Shaver not turning on:** Ensure the battery is charged. If not, connect to the charger.
- **Poor shaving performance:** Clean the shaver head thoroughly. Ensure the shaver head is not damaged and replace if necessary. Shave against the direction of hair growth.
- **Battery not charging:** Check if the charger is properly connected to both the shaver and the power outlet. Ensure the power outlet is functional.

Specifications

Brand	Braun
Model Number	62-B1200s (8700216644907)
Power Source	Battery Powered (Li-ion)
Battery Life	Up to 60 minutes
Quick Charge	5 minutes for one shave
Waterproof	100% (Wet & Dry Use)
Special Features	2D ContourAdapt, Turbo & Gentle Modes, SensoAdapt
Blade Material	Stainless Steel
Country of Origin	Germany
Dimensions (L x W x H)	7.3 x 13.1 x 24.1 cm
Weight	500 grams

Warranty and Support

Your Braun Series 6 shaver comes with a manufacturer's warranty. Specific warranty terms and conditions may vary by region. Please refer to the warranty card included in your package or visit the official Braun website for detailed information.
For technical support, spare parts, or service, please contact Braun Customer Service. Contact details can typically be found on the Braun website or in your product documentation.



The product packaging highlights key features and benefits of the Braun Series 6 shaver.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F9X8XHR5

More documents and user manuals: **https://manuals.plus/**