Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Metz 43MQF7500Z

Metz TV QLED 43" 4K Smart Google TV 43MQF7500Z User Manual

Model: 43MQF7500Z | Brand: Metz

1. Product Overview

The Metz Smart TV 43" MQF7500Z is a 4K UHD HDR10+ QLED television designed to deliver an immersive viewing and audio experience. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new Metz TV.



Figure 1.1: Metz 43MQF7500Z QLED TV showcasing its vibrant display and EyeCare technology.

Key Features:

- **5th Generation QLED Technology:** Experience brighter images, richer colors, and a comfortable viewing experience with Metz's advanced QLED technology.
- **HDR10+, Dolby Vision & HLG Support:** Enjoy ultra-realistic images with enhanced contrasts, deeper blacks,

sharper details, and brighter highlights.

- **Dolby Atmos & dbx-TV Audio:** Immerse yourself in breathtaking multidimensional sound with crystal-clear dialogue and rich, balanced bass.
- **Eye-Care Low Blue Light Technology:** Designed to reduce blue light emission and flicker, minimizing eye strain for extended viewing comfort.
- **Google TV with Remote Control Search:** Navigate an intuitive interface, utilize child profiles, and never lose your remote again with the 'Find Remote Control' function.
- **MEMC Technology:** Enhances motion clarity for smoother viewing of fast-paced content.



Figure 1.2: Metz, a German brand with a legacy of innovation since 1938.

2. Setup Guide

2.1 Unpacking

Carefully remove the TV and all accessories from the packaging. Retain the packaging materials for future transport or storage.

2.2 Attaching the Stand

Place the TV screen-down on a soft, flat surface to prevent scratches. Align the included stand with the mounting holes on the bottom of the TV. Secure the stand using the provided screws. Refer to the quick start guide included in the box for detailed diagrams.

2.3 Initial Connections

Before powering on, connect all necessary cables:

- **Power Cable:** Connect the power cable to the TV's power input and then to a wall outlet.
- **HDMI Devices:** Connect your external devices (e.g., Blu-ray player, game console) to the HDMI ports.
- **USB Devices:** Connect USB drives for media playback or software updates to the USB ports.
- **Antenna/Cable:** Connect your DVB-T2/C/S2 antenna or cable to the RF input.

- **Ethernet:** For a stable internet connection, connect an Ethernet cable from your router to the TV's LAN port. Alternatively, use Wi-Fi for wireless connectivity.

2.4 First Time Setup (Google TV)

Upon first power-on, the TV will guide you through the initial setup process for Google TV. This includes:

- Language selection.
- Network connection (Wi-Fi or Ethernet).
- Google account sign-in (recommended for full Google TV features).
- Channel scanning (for DVB-T2/C/S2 tuner).
- Accepting terms and conditions.

3. Operating Instructions

3.1 Remote Control

The Metz TV comes with a Bluetooth remote control. Pair it during the initial setup or via the TV's settings menu. Utilize the "Find Remote Control" function if you misplace it.

3.2 Navigating Google TV

Google TV provides a personalized home screen with content recommendations from your streaming services. Use the remote's directional pad to navigate and the OK button to select. Voice commands via the remote's microphone are also supported.

3.3 Picture Settings

Access picture settings through the TV's main menu to adjust:

- **Picture Mode:** Choose from standard, vivid, movie, game, or custom modes.
- **Brightness, Contrast, Color, Sharpness:** Fine-tune these parameters to your preference.
- **HDR Settings:** The TV automatically detects and optimizes content for HDR10+, Dolby Vision, and HLG.
- **Eye-Care Low Blue Light:** Enable or disable this feature to reduce eye strain.
- **Wide Color Enhancer:** Optimizes color reproduction for a broader spectrum.
- **MEMC:** Motion Estimation, Motion Compensation for smoother motion.

3.4 Sound Settings

Adjust audio settings to enhance your listening experience:

- **Sound Mode:** Select from standard, music, movie, speech, or custom.
- **Dolby Atmos:** Enable for immersive, multidimensional audio.
- **dbx-TV:** Enhances audio clarity and bass response.
- **Equalizer:** Customize audio frequencies.

3.5 Connectivity

Manage your TV's connections:

- **Wi-Fi:** Connect to your home wireless network.
- **Bluetooth:** Pair with Bluetooth headphones, speakers, or other compatible devices.
- **HDMI CEC:** Control connected HDMI devices with your TV remote.

3.6 Gaming Mode

Activate Game Mode for reduced input lag and optimized picture settings when playing video games. This mode is designed to provide a more responsive gaming experience.

4. Maintenance and Care

4.1 Cleaning the Screen

To clean the screen, first turn off the TV and unplug it. Use a soft, lint-free microfiber cloth. For stubborn marks, lightly dampen the cloth with distilled water or a specialized screen cleaner. Never spray liquid directly onto the screen.

4.2 General Care

- Keep the TV away from direct sunlight and heat sources.
- Ensure adequate ventilation around the TV.
- Avoid placing heavy objects on top of the TV.
- Unplug the TV during lightning storms or if it will be unused for extended periods.

5. Troubleshooting

This section addresses common issues you might encounter with your Metz TV. If the problem persists, please contact customer support.

Problem	Possible Cause	Solution
No Power	Power cable disconnected; power outlet issue.	Ensure power cable is securely connected. Test the outlet with another device.
No Picture / Black Screen	Incorrect input source; loose HDMI cable; device not powered on.	Check input source. Reconnect HDMI cables. Power on connected devices.

Problem	Possible Cause	Solution
No Sound	Volume too low/muted; incorrect audio output; external audio system issue.	Increase volume, check mute. Verify audio output settings (TV speakers, external). Check external audio system.
Remote Control Not Responding	Low batteries; remote not paired; interference.	Replace batteries. Re-pair the Bluetooth remote. Remove obstacles between remote and TV.
Cannot achieve 120Hz or HDR on PC	PC graphics card limitations; HDMI cable version; TV settings.	Ensure your PC graphics card supports 4K@120Hz and HDR. Use a certified HDMI 2.1 cable. Check TV's HDMI input settings for 'Enhanced Format' or 'HDMI 2.1 Mode'. Update graphics drivers. Note: This model's refresh rate is 60Hz, 120Hz might be a marketing term for motion smoothing (MEMC) rather than native panel refresh rate.

6. Technical Specifications

Feature	Detail
Brand	Metz
Model	43MQF7500Z
Screen Size	43 Inches
Display Technology	LED, QLED
Resolution	4K (3840 x 2160)
Refresh Rate	60 Hz
Special Features	Wide viewing angle, Blue light filter, Game Mode, Built-in speaker, Wide color enhancer
Connectivity Technology	Bluetooth, Ethernet, HDMI, RF, USB
Total USB Ports	2
Included Components	Power cable, User manual, Stand
Aspect Ratio	16:9
Product Dimensions (LxWxH)	95.7 x 26.4 x 63 cm (with stand)

Feature	Detail
Manufacturer	Metz
Country of Origin	Poland

7. Warranty and Support

For warranty information, please refer to the documentation provided with your purchase or contact your retailer. Metz is committed to providing quality products and support.

- **Spare Parts Availability:** Information regarding spare parts availability is currently not provided.
- **Software Updates:** Information regarding guaranteed software updates is currently not provided.
- For technical assistance or service inquiries, please visit the official Metz website or contact their customer support channels.

© 2025 Metz. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FBFB1VML

More documents and user manuals: **https://manuals.plus/**