Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZOKOP HD-1861-A

ZOKOP HD-1861-A 1.8L Electric Glass Kettle User Manual

Model: HD-1861-A

1. Introduction

Thank you for purchasing the ZOKOP HD-1861-A 1.8L Electric Glass Kettle. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read these instructions thoroughly before first use and retain them for future reference.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury, do not immerse cord, plugs, or the power base in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer support for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Scalding may occur if the lid is removed during the heating cycle.
- This appliance is for household use only.

3. Product Overview

The ZOKOP HD-1861-A electric glass kettle features a durable borosilicate glass body, a stainless steel heating plate, and a convenient 360-degree rotating power base. It includes an integrated tea infuser for brewing tea directly.



An image showing the LEARCJNRT ZOKOP HD-1861-A electric glass kettle. It features a clear borosilicate glass body, a black handle,

a stainless steel base with a blue accent, and an internal stainless steel tea infuser.

Key Components:

- **Glass Body:** High-quality borosilicate glass.
- **Lid:** Easy-to-open lid for filling.
- **Handle:** Ergonomically designed for comfortable grip.
- **Spout with Filter:** Large pouring spout with a mesh filter.
- **Heating Plate:** 304 stainless steel heating element.
- **Power Base:** 360-degree rotation for cordless convenience.
- **LED Illumination:** Multi-color LED lights activate during operation.
- **Tea Infuser:** Removable stainless steel infuser for tea brewing.

4. Setup

1. **Unpack:** Carefully remove the kettle and all accessories from the packaging.
2. **Initial Cleaning:** Before first use, fill the kettle with clean water to the maximum fill line. Boil the water, then discard it. Repeat this process 2-3 times to remove any manufacturing residues.
3. **Placement:** Place the power base on a dry, flat, stable, and heat-resistant surface. Ensure the kettle is not near the edge of a counter or table to prevent accidental tipping.
4. **Power Connection:** Plug the power cord into a standard 110V US electrical outlet.

5. Operating Instructions

1. **Fill the Kettle:** Open the lid and fill the kettle with the desired amount of fresh water. Do not fill below the minimum mark or above the maximum fill line (1.8L).
2. **Close the Lid:** Ensure the lid is securely closed before operating.
3. **Place on Base:** Place the kettle firmly onto the power base.
4. **Start Boiling:** Press the ON/OFF switch located on the handle or base (depending on model variation). The LED lights will illuminate, indicating that the kettle is heating.
5. **Automatic Shut-off:** The kettle will automatically turn off once the water has reached a rolling boil. The LED lights will extinguish.
6. **Pouring:** Carefully lift the kettle from the power base and pour the hot water. Be cautious of steam and hot water.
7. **Tea Infuser Use (Optional):** If brewing tea, place loose leaf tea into the stainless steel infuser. Secure the infuser inside the kettle before filling with water and boiling. Remove the infuser after brewing to prevent over-steeping.

Boil-Dry Protection: The kettle is equipped with a boil-dry protection feature. If the kettle is accidentally switched on without sufficient water, it will automatically turn off. Allow the kettle to cool down for 15-20 minutes before refilling with cold water.

6. Maintenance and Cleaning

Regular cleaning and maintenance will prolong the life of your kettle.

- **Before Cleaning:** Always unplug the kettle from the power outlet and allow it to cool completely before cleaning.
- **Exterior Cleaning:** Wipe the exterior of the kettle with a soft, damp cloth. Do not use abrasive cleaners or scouring pads, as they may scratch the surface.
- **Interior Cleaning:** For general cleaning, rinse the interior with water. For stubborn stains, use a soft brush or sponge.

- **Descaling:** Over time, mineral deposits (limescale) may build up inside the kettle, especially in hard water areas. To descale:
    a. Fill the kettle with 1 part white vinegar and 2 parts water.
    b. Boil the mixture and let it stand for 30 minutes.
    c. Discard the mixture and rinse the kettle thoroughly with fresh water several times.
    d. Alternatively, use a commercial descaling solution following the product's instructions.
- **Filter Cleaning:** The mesh filter in the spout can be removed for cleaning. Rinse it under running water and gently brush away any deposits. Reinstall securely.
- **Do Not Immerse:** Never immerse the kettle or its power base in water or any other liquid.

7. Troubleshooting

Problem	Possible Cause	Solution
Kettle does not heat.	Not plugged in; power switch not activated; boil-dry protection activated.	Ensure kettle is plugged in and switch is ON. If boil-dry protection activated, allow to cool and refill.
Water takes too long to boil.	Limescale buildup; low voltage.	Descale the kettle. Ensure kettle is connected to a proper 110V outlet.
Kettle switches off before boiling.	Limescale buildup; faulty thermostat.	Descale the kettle. If problem persists, contact customer support.
Water tastes metallic or has particles.	New kettle residue; limescale.	Perform initial cleaning steps again. Descale the kettle.

8. Specifications

- **Model:** HD-1861-A
- **Type:** Electric Glass Kettle
- **Capacity:** 1.8 Liters
- **Material:** High-Grade Stainless Steel, High Quality Borosilicate Glass, BPA-Free Plastic
- **Voltage:** 110V, 50-60Hz
- **Power:** 1200W
- **Plug Type:** US Standard
- **Thermostat:** Double Metal Temperature Control
- **Power Cord:** Full Copper 3*0.75*100cm (Revealing Part) CE Certification
- **Heating Elements:** Heating Plate 304
- **LED Illuminated Color:** Colorful
- **Dimensions:** 9.1 x 9.1 x 9.5 inches (23 x 23 x 24 cm) (L x W x H)
- **Weight:** 3.31 lbs (1.5 kg)

9. Warranty and Support

This product is covered by a standard manufacturer's warranty. For specific warranty details, please refer to the warranty card

included with your purchase or contact the retailer. For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact customer service through your point of purchase.

© 2025 ZOKOP. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FBQR2QCH

More documents and user manuals: **https://manuals.plus/**