Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Jocoevol 24*24*71

Jocoevol Farmhouse Corner Pantry Cabinet 24x24x71 - Instruction Manual

Model: 24*24*71 All White

1. Introduction

Thank you for choosing the Jocoevol Farmhouse Corner Pantry Cabinet. This manual provides essential information for the safe assembly, operation, and maintenance of your new cabinet. Please read these instructions carefully before beginning assembly and retain them for future reference.



Image 1.1: The Jocoevol Farmhouse Corner Pantry Cabinet in its closed state.

2. Product Features

The Jocoevol Farmhouse Corner Pantry Cabinet is designed to maximize storage efficiency and enhance your living space with its unique features:

- **Space-Saving Corner Design:** Specifically shaped to fit into a 90-degree corner, optimizing unused space.
- **Door-Activated Sensor Light:** An integrated sensor light automatically illuminates the interior when doors are opened, improving visibility.
- **Roomy and Flexible Storage:** Features two main cabinet compartments, four doors, eight door shelves, and four interior shelves. Two interior shelves are adjustable to accommodate items of various heights.
- **Farmhouse Aesthetic:** Boasts a weathered finish and metal accents for a rustic, inviting appearance.
- **Stable Construction:** Designed with a sturdy base and includes anti-tip hardware for enhanced safety and stability.



Image 2.1: Interior view of the cabinet with the door-activated sensor light illuminated.



Image 2.2: The cabinet's spacious interior, suitable for various kitchen items and small appliances.

3. Setup and Assembly

Assembly of this cabinet is designed to be straightforward. Please ensure all parts are present before beginning. It is recommended to assemble the cabinet on a soft, clean surface to prevent scratches.

3.1. Package Contents

Verify that all components listed in the included assembly guide are present and undamaged. Contact customer support if any parts are missing or defective.

3.2. Tools Required (Not Included)

- Phillips head screwdriver
- Hammer (for dowels, if applicable)
- Level

3.3. Assembly Steps

1. Follow the step-by-step instructions provided in the separate assembly manual. All parts are numbered, and pre-drilled holes are provided for ease of installation.
2. Assemble the main frame components first, ensuring all connections are secure.
3. Attach the back panels, ensuring they are properly aligned and fastened.
4. Install the interior shelves. For adjustable shelves, select the desired height before securing.
5. Mount the doors, ensuring they open and close smoothly.
6. Install the door-activated sensor light according to its specific instructions. Ensure batteries are correctly inserted (if applicable).
7. Secure the anti-tip hardware to the cabinet and a wall stud to prevent accidental tipping. This is a critical safety step.



Image 3.1: Product dimensions for planning and assembly.

4. Operating Instructions

4.1. Using Adjustable Shelves

The interior shelves can be adjusted to different heights to accommodate various items. To adjust a shelf:

1. Empty the shelf of all contents.
2. Carefully lift the shelf and remove the shelf pins from their current holes.
3. Reinsert the shelf pins into the desired new holes, ensuring they are level and fully seated.
4. Place the shelf back onto the pins, ensuring it is stable before placing items on it.

Image 4.1: Detail of adjustable interior shelves and convenient door shelves.

4.2. Door-Activated Sensor Light

The cabinet is equipped with a sensor light that activates automatically when the doors are opened and turns off when they are closed. This feature requires batteries (not included or pre-installed). Refer to the sensor light's specific instructions for battery installation and any operational modes.

5. Maintenance

Proper care will ensure the longevity and appearance of your Jocoevol Farmhouse Corner Pantry Cabinet.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, which can damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or moisture damage to the engineered wood.
- **Hardware:** Periodically check all screws and fasteners to ensure they are tight. Retighten as necessary.
- **Sensor Light:** Replace batteries in the sensor light as needed to maintain functionality.

6. Troubleshooting

Problem	Possible Cause	Solution
Cabinet feels wobbly or unstable.	Loose fasteners; uneven floor; anti-tip hardware not installed.	Ensure all screws are tightened. Place shims under legs if floor is uneven. Install anti-tip hardware securely to a wall stud.
Doors do not close properly or are misaligned.	Hinges are loose or improperly adjusted.	Adjust hinge screws to align doors. Refer to hinge adjustment instructions in the assembly guide.
Sensor light is not working.	Dead batteries; incorrect battery installation; sensor obstruction.	Replace batteries. Ensure batteries are inserted with correct polarity. Check if anything is blocking the sensor.

7. Specifications

Attribute	Detail
Brand	Jocoevol
Model	24*24*71
Color	All White
Material	Engineered Wood
Product Dimensions (D x W x H)	33"D x 15"W x 71"H (Overall)
Item Weight	90 pounds
Number of Shelves	8 (including door shelves)
Number of Doors	4

Attribute	Detail
Mounting Type	Freestanding
Style Name	Farmhouse
Special Feature	Adjustable Shelf, Door-Activated Sensor Light

8. Warranty and Support

For warranty information or customer support, please refer to the documentation included with your purchase or contact Jocoevol customer service directly. Keep your purchase receipt for warranty claims.

For further assistance, please visit the Jocoevol Store on Amazon.

© 2023 Jocoevol. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FCFFTGG9

More documents and user manuals: **https://manuals.plus/**