Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CyberChill IM-BS260C

CyberChill Countertop Ice Maker Instruction Manual

Model: IM-BS260C | Brand: CyberChill

1. Introduction

The CyberChill Countertop Ice Maker (Model IM-BS260C) is a portable and efficient appliance designed to provide fresh ice quickly. Ideal for various settings including homes, kitchens, RVs, and camping, this ice maker produces bullet-shaped ice in two selectable sizes. Its user-friendly design includes one-touch controls, a transparent viewing window, and a self-cleaning function for convenient operation and maintenance.
Key features include:

- Fast Ice Production: Produces ice in approximately 6-13 minutes, with a daily capacity of up to 26 lbs.
- Two Ice Sizes: Choose between small and large bullet ice to suit your preference.
- Self-Cleaning Function: One-touch cleaning for effortless maintenance.
- Quiet Operation: Designed to operate with minimal noise.
- Compact and Portable: Space-saving design with a handle for easy transport.



Figure 1: Illustration of the ice maker producing 9 ice cubes in 6 minutes.

2. Safety Information

Please read all safety instructions carefully before operating the CyberChill Countertop Ice Maker. Retain this manual

for future reference.

Important Safety Warnings:

- **DANGER: Risk of Fire or Explosion.** This appliance uses flammable refrigerant (R600a).
- **DO NOT** use mechanical devices or other means to defrost the ice maker.
- **DO NOT** puncture the refrigerant tubing.
- Ensure the appliance is placed on a stable, level surface.
- Keep at least 4 inches (10 cm) of clearance around the unit for proper air circulation.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Unplug the appliance before cleaning or when not in use.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

3. Package Contents

Verify that all items are present in the package:

- CyberChill Countertop Ice Maker Unit
- Ice Basket
- Ice Scoop
- Instruction Manual
- Portable Handle (requires assembly)
- Ice Storage Bags (for transferring ice to freezer)



Figure 2: Ice maker with its included ice basket and scoop.

4. Setup

4.1 Unpacking and Placement

1. Remove all packaging materials and inspect the ice maker for any damage.
2. Place the ice maker on a stable, level surface away from direct sunlight and heat sources.

3. Ensure there is at least 4 inches (10 cm) of clearance on all sides for proper ventilation.



Figure 3: The compact design of the ice maker, suitable for various spaces.

4.2 Initial Cleaning

Before first use, it is recommended to clean the ice maker thoroughly. The unit features a self-cleaning mode for convenience.

1. Fill the water reservoir with clean drinking water up to the MAX line.
2. Press and hold the "SELECT" button for 5 seconds to activate the self-cleaning cycle.
3. Allow the cycle to complete (approximately 15 minutes).
4. Drain the water from the unit using the built-in drain plug.
5. Repeat the cleaning process 2-3 times to ensure thorough cleaning.



Figure 4: Visual representation of the self-cleaning process.

4.3 Handle Assembly (Optional)

The portable handle can be easily attached for convenient transport.

1. Align the ends of the handle with the designated slots on the sides of the ice maker.
2. Press firmly until the handle clicks securely into place.



Figure 5: The ice maker with its portable handle installed.

5. Operating Instructions

5.1 Filling the Water Reservoir

1. Open the top lid of the ice maker.
2. Remove the ice basket.

3. Fill the water reservoir with clean drinking water up to the MAX fill line*Do not use distilled water or carbonated beverages.*
4. Replace the ice basket and close the lid.

5.2 Powering On and Selecting Ice Size

1. Plug the ice maker into a grounded electrical outlet. The "POWER" indicator light will illuminate.
2. Press the "ON/OFF" button to turn on the ice maker.
3. Press the "SELECT" button to choose your desired ice cube size:
    - **SMALL:** Produces smaller ice cubes, typically in a shorter cycle time.
    - **LARGE:** Produces larger ice cubes.
4. The corresponding indicator light (SMALL or LARGE) will illuminate.



Figure 6: The control panel with "ON/OFF" and "SELECT" buttons for operation.



Figure 7: Comparison of small and large ice cube sizes.

5.3 Ice Making Cycle

The ice making cycle typically lasts for 6-13 minutes, depending on the ambient temperature and water temperature. If the ambient temperature is too high, the cycle may take longer.

- The ice maker will automatically begin producing ice.
- The "ICE FULL" indicator light will illuminate when the ice basket is full, and the ice making process will pause.
- The "ADD WATER" indicator light will illuminate when the water reservoir is low, and the ice making process will pause. Refill the water reservoir to resume operation.

5.4 Harvesting Ice Cubes

After the ice-making cycle ends, the ice cubes will automatically fall into the ice basket.

- Use the provided ice scoop to remove ice from the basket.
- The ice maker does not have a freezing function to store ice long-term. To prevent melting, transfer harvested ice cubes to a freezer using the included ice bags.
- For each use, the first three ice-making cycles may produce smaller ice cubes. This is normal.

6. Maintenance

6.1 Self-Cleaning Function

Regularly use the self-cleaning function to maintain hygiene and performance.

1. Ensure the water reservoir is filled with clean water.
2. Press and hold the "SELECT" button for 5 seconds to start the self-cleaning cycle.
3. After the cycle, drain the water and wipe down the interior with a soft cloth.

6.2 General Cleaning

For deeper cleaning:

- Unplug the ice maker before cleaning.
- Remove the ice basket and wash it with mild detergent and warm water. Rinse thoroughly.
- Wipe the interior and exterior surfaces of the ice maker with a soft cloth dampened with mild detergent.
- Ensure all parts are completely dry before reassembling and storing or using the appliance.

- Do not use abrasive cleaners or sharp objects to clean the ice maker.

7. Troubleshooting

Problem	Possible Cause	Solution
Ice maker not producing ice.	No water in reservoir; "ADD WATER" light on.	Fill water reservoir to MAX line.
Ice cubes are too small.	First few cycles; ambient temperature too high.	This is normal for initial cycles. Ensure unit is in a cool environment.
"ICE FULL" light is on, but basket is not full.	Ice cubes are blocking the sensor.	Rearrange ice cubes or remove some from the basket.
Ice is melting quickly in the basket.	Ice maker does not have a freezing function.	Transfer ice to a freezer for long-term storage.

If you encounter any issues not listed here or require further assistance, please contact customer support.

8. Specifications

Brand:	CyberChill
Model Name:	IM-BS260C
Product Dimensions:	8.74"D x 11.42"W x 11.57"H
Capacity:	1.2 Liters (Water Tank) / 26 lbs/Day (Ice Production)
Voltage:	115 Volts
Refrigerant:	R600a
Material:	Plastic
Item Weight:	13.57 pounds
UPC:	768365708374

9. Warranty and Support

For warranty information, product registration, or technical support, please contact CyberChill customer service.
Email: support@cyberchill.com
Please have your model number (IM-BS260C) and purchase date available when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FD3BNKK8

More documents and user manuals: **https://manuals.plus/**