Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VAUNO EN8835

VAUNO EN8835 Digital Alarm Clock User Manual

Model: EN8835

Product Overview

The VAUNO EN8835 is a compact digital alarm clock designed for bedrooms, offices, and classrooms. It features a 5.1-inch LED display with adjustable brightness, dual alarms, and a snooze function. The clock can be powered by a DC adapter (not included) or 3 AAA batteries (not included) for backup.



Image: Front view of the VAUNO EN8835 Digital Alarm Clock, showing the time display.

Key Features

- **Accurate Timekeeping:** Utilizes advanced chip technology for precise time display.
- **Large LED Display:** 5.1-inch display for easy readability from a distance.
- **Adjustable Brightness:** 3 levels of brightness and an automatic night mode for comfortable viewing.
- **Dual Alarms:** Set two independent alarms for different wake-up times.
- **Snooze Function:** Convenient snooze button for additional sleep.
- **Silent Operation:** Ensures a quiet sleeping environment.
- **Dual Power Modes:** Operates via DC power (USB cable included, adapter not) or 3 AAA batteries (not included) for backup.
- **Mirror Surface:** The display surface can also function as a makeup mirror.

Package Contents

- VAUNO EN8835 Digital Alarm Clock

- USB Power Cable (DC adapter not included)
- User Manual

Component Identification



Image: Diagram showing the top buttons (SNOOZE/LIGHT, M, +, -, AL) and display elements (Time, AM/PM, Alarm 1, Alarm 2 icons) of the VAUNO EN8835 Digital Alarm Clock.

- **SNOOZE/LIGHT Button:** Press to snooze alarm or adjust display brightness.
- **M (Mode) Button:** Press and hold to enter time setting mode; press to cycle through settings.
- **+ Button:** Increase values during setting.
- **- Button:** Decrease values during setting.
- **AL (Alarm) Button:** Press to select and set alarms.
- **DC 5V Input:** Power input port.
- **Battery Compartment:** Holds 3 AAA batteries for backup power.

Setup

Powering the Clock

1. Connect the provided USB power cable to the DC 5V input port on the back of the clock.
2. Plug the other end of the USB cable into a USB power adapter (not included) or a powered USB port.
3. For battery backup, open the battery compartment on the back and insert 3 AAA batteries (not included), ensuring correct polarity. The display will automatically turn off after 10 seconds when powered by batteries only to save power. It is recommended to use both DC power and batteries simultaneously to prevent loss of settings during power outages.

▶ **Watch video online**
Alarm Clock EN8835

Video: Demonstrates how to power on the VAUNO EN8835 Digital Alarm Clock by connecting the power cable and inserting AAA batteries.



Image: Illustration of the two power supply modes: AAA battery compartment and USB/DC power supply port.

Operating Instructions

Setting the Time

1. Press and hold the "M" (Mode) button for 3 seconds to enter time setting mode. The display will show "24Hr" or "12Hr".
2. Use the "+" or "-" buttons to select between 12-hour or 24-hour format.
3. Press "M" once to move to the hour setting. Use "+" or "-" to adjust the hour.
4. Press "M" once to move to the minute setting. Use "+" or "-" to adjust the minutes.
5. Press "M" again to exit time setting mode.

▶ **Watch video online**
Alarm Clock EN8835

Setting the Alarm

The clock supports two independent alarms (Alarm 1 and Alarm 2).

1. In time display mode, press the "AL" (Alarm) button once to select Alarm 1. The Alarm 1 icon will flash.
2. Press and hold "AL" for 3 seconds to enter Alarm 1 setting mode. The hour will flash.
3. Use the "+" or "-" buttons to adjust the alarm hour.
4. Press "AL" once to move to the minute setting. Use "+" or "-" to adjust the alarm minutes.
5. Press "AL" again to confirm Alarm 1 setting and exit.
6. Repeat steps 1-5 for Alarm 2 by pressing "AL" twice to select Alarm 2.



Image: Depicts the dual alarm function, showing two different alarm times set on the clock.

Video: Demonstrates how to set the alarm time on the VAUNO EN8835 Digital Alarm Clock, including selecting the alarm and adjusting hours and minutes.

Activating/Deactivating Alarm

- In time display mode, press "AL" once to activate Alarm 1. The Alarm 1 icon will appear on the display. Press "AL" again to activate Alarm 2. The Alarm 2 icon will appear.
- Press "AL" a third time to activate both alarms.
- Press "AL" a fourth time to deactivate all alarms. The alarm icons will disappear.

Snooze Function

- When the alarm sounds, press the large "SNOOZE/LIGHT" button on top to activate snooze. The alarm will pause for a set duration (default 5 minutes) and sound again later.
- To stop the alarm completely, press any other button (M, +, -, AL) except "SNOOZE/LIGHT". The alarm will stop and reset for the next day.



Image: A person reaching for the large SNOOZE/LIGHT button on top of the VAUNO EN8835 Digital Alarm Clock.

Brightness Control

- In time display mode, press the "SNOOZE/LIGHT" button to cycle through 3 levels of display brightness (Bright, Medium, Dim).
- The clock also features a night mode that automatically adjusts brightness during a preset period.



Image: Comparison of the VAUNO EN8835 Digital Alarm Clock display at Bright, Medium, and Dim brightness settings.

Video: Demonstrates how to adjust the brightness of the LED display on the VAUNO EN8835 Digital Alarm Clock using the SNOOZE/LIGHT button.

Night Mode Setting

1. In time display mode, press "M" once to enter night mode setting. The display will show "ON" or "OFF".
2. Use "+" or "-" to toggle night mode ON or OFF.
3. If "ON" is selected, press and hold "M" for 3 seconds to enter the interval time setting.
4. Use "+" or "-" to set the start hour for night mode.
5. Press "M" once to set the start minute.
6. Press "M" once to set the end hour.
7. Press "M" once to set the end minute.
8. Press "M" again to confirm and exit night mode setting.

Video: Demonstrates how to set the night mode on the VAUNO EN8835 Digital Alarm Clock, including enabling/disabling and setting the start and end times for automatic dimming.

Maintenance

- Clean the clock surface with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- Keep the clock away from direct sunlight, extreme temperatures, and high humidity.
- If using batteries for backup, replace them annually or when the display shows signs of dimming when unplugged.

Troubleshooting

Problem	Possible Cause	Solution
Display is blank.	No power or batteries are dead.	Ensure the USB cable is securely connected and plugged into a working power source. If using batteries, replace them.
Alarm does not sound.	Alarm is not activated or set incorrectly.	Verify that the alarm icon (1 or 2) is displayed, indicating activation. Recheck alarm time settings.
Display is too dim/bright.	Brightness setting needs adjustment or night mode is active.	Press "SNOOZE/LIGHT" to cycle brightness levels. Check night mode settings.
Time is incorrect.	Time was not set correctly or power interruption occurred without battery backup.	Reset the time following the "Setting the Time" instructions. Ensure batteries are installed for backup.

Specifications

Feature	Detail
Brand	VAUNO
Model Number	EN8835
Display Type	Digital LED
Screen Size	5.1 inches
Product Dimensions	5.3"W x 2.4"H
Power Source	Corded Electric (USB) / 3x AAA Batteries (backup)

Feature	Detail
Special Features	Adjustable Brightness, Dual Alarms, Snooze, Night Mode, Silent Clock
Material	Plastic

Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official VAUNO website. Keep your purchase receipt for warranty claims.

© 2026 VAUNO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FD3DMBZR

More documents and user manuals: **https://manuals.plus/**