Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Sweetcrispy PKWT2-DJY-H2su

Sweetcrispy Ergonomic Gaming Chair with Footrest (Model: PKWT2-DJY-H2su) - Instruction Manual

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your Sweetcrispy Ergonomic Gaming Chair. Please read thoroughly before use.

1. Setup

1.1 Unpacking and Parts Check

Carefully remove all components from the packaging. Verify that all parts are present and undamaged. Refer to the assembly video for a visual guide to included accessories.

1.2 Assembly Instructions

For a comprehensive visual guide to assembly, please refer to the official installation video below. Follow the steps precisely to ensure correct and safe assembly.

▶ **Watch video online**
Accessories display & installation steps

Video: Accessories display & installation steps. This video provides a detailed walkthrough of the chair's assembly process, including identifying parts and step-by-step installation.

1. **Assemble the Base:** Attach the five legs to the central hub using the provided screws (R*10, M8*10mm) and tighten securely. Insert the casters into the leg ends.
2. **Install the Gas Lift:** Place the gas lift cylinder into the center hole of the assembled base.
3. **Attach the Mechanism to the Seat:** Secure the seat mechanism to the underside of the seat cushion using the specified screws (P*4, M8*25mm). Ensure it is oriented correctly.
4. **Attach Armrests:** Secure the armrests to the seat cushion using the designated screws (O*6, M8*25mm).
5. **Attach Footrest:** Assemble the footrest frame and cushion, then attach it to the underside of the seat using the specified screws (D*1, M5*10mm and O*6, M8*25mm).
6. **Connect Seat to Backrest:** Align the backrest with the seat and secure it using the appropriate screws (Q*8, M8*20mm).
7. **Attach Backrest to Mechanism:** Secure the backrest to the seat mechanism using the specified screws

(S*4, M8*40mm).

8. **Install Headrest and Lumbar Pillow:** Attach the headrest and lumbar support pillow using their integrated straps and buckles.

2. Operating Instructions

Your Sweetcrispy Gaming Chair offers multiple adjustments for personalized comfort.

2.1 Adjusting Chair Height

To adjust the chair's height, locate the lever on the right side beneath the seat. While seated, pull the lever up to lower the chair. To raise the chair, stand up slightly and pull the lever up. Release the lever at your desired height.

2.2 Reclining the Backrest

The backrest can be reclined from 90° (focused position) to 135° (relaxed position). Use the recline lever on the left side of the chair to adjust the angle. Lean back to your desired position and release the lever to lock it.

2.3 Using the Footrest

The chair features a retractable footrest for added comfort. Pull the footrest out from under the seat when desired, and push it back in when not in use. Ensure the footrest is fully extended and stable before placing your feet on it.

▶ **Watch video online**
Sweetcrispy Video game chair with footrest

Video: Sweetcrispy Video game chair with footrest. This video demonstrates the use of the chair's footrest and reclining function.

2.4 Adjusting Lumbar Support and Headrest

The chair includes a removable headrest and an adjustable lumbar support pillow. The lumbar pillow can be slid up or down to adapt to your sitting position, providing optimal support for your lower back.



Image: Ergonomic Design. This image illustrates the ergonomic support points of the chair, including head, shoulder, waist, hip, and leg areas, and shows the angle adjusting lever.



Image: Upgraded Linkage Armrest. This image highlights the design of the fixed armrests, providing strong support from wrist to elbow.

3. Maintenance

3.1 Cleaning Instructions

- Wipe clean with a damp cloth.
- Avoid using harsh chemicals or abrasive cleaners, as these can damage the PU leather.
- For stubborn stains, use a mild soap solution and wipe dry immediately.

3.2 General Maintenance

- Periodically check all screws and bolts to ensure they are tight. Retighten if necessary.
- Inspect the casters for any debris or hair that might hinder smooth rolling. Clean as needed.
- Avoid exposing the chair to direct sunlight or extreme temperatures for prolonged periods to prevent material degradation.

4. Troubleshooting

Issue	Possible Cause	Solution
Chair is unstable or wobbly	Loose screws or uneven assembly.	Check and tighten all assembly screws. Ensure the chair is on a flat, even surface.
Difficulty adjusting height	Gas lift malfunction or lever obstruction.	Ensure the height adjustment lever is not obstructed. If the issue persists, the gas lift may need replacement.
Casters not rolling smoothly	Debris in casters or damaged casters.	Remove any hair or debris from the casters. If damaged, replace the casters.
Backrest does not recline or lock	Recline mechanism obstruction or damage.	Check for any obstructions around the recline mechanism. Ensure the lever is fully engaged. If damaged, contact support.

5. Specifications

Feature	Detail
Brand	Sweetcrispy
Model Name	Sweetcrispy Computer Video Game Chair
Model Number	PKWT2-DJY-H2su
Color	Pink White
Product Dimensions	26.8"D x 25.4"W x 52.4"H
Maximum Weight Recommendation	275 Pounds
Material	Alloy Steel, Faux Leather, Sponge
Special Features	Adjustable Height, Ergonomic, Foot Rest, Reclining, Rolling
Back Style	Soft back
Arm Style	Fixed armrest
Furniture Base Movement	Swivel
Reclining Position Count	2 (90° to 135°)
Item Weight	37.6 pounds



Image: Product Dimensions. This diagram provides detailed measurements and the maximum weight capacity of the chair.

6. Important Safety Information

- Do not exceed the maximum weight limit of**275 pounds**.
- Always follow the assembly instructions carefully to ensure safe use of the chair.
- Ensure all bolts and screws are securely tightened before each use.
- Avoid sudden movements or excessive force when reclining or adjusting the chair to prevent tipping or injury.
- Keep children and pets away from the chair during assembly and adjustment.
- Do not stand on the chair.

7. Warranty and Support

For information regarding the product warranty, please refer to the documentation provided with your purchase or contact the retailer directly. For any questions, technical assistance, or to report issues, please contact Sweetcrispy customer service through your purchase platform or the official Sweetcrispy website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FDFL66P9

More documents and user manuals: **https://manuals.plus/**