Manuals+
Q & A | Deep Search | Upload

D1D9 B0FDFMG16M

User Manual: D1D9 10.1 Inch Smart Digital Calendar

Model: B0FDFMG16M
Brand: D1D9

Product Overview

The D1D9 10.1 Inch Smart Digital Calendar is a versatile HD touchscreen device designed to streamline family and work scheduling. It functions as a chore chart, meal planner, and digital calendar, offering seamless synchronization with popular calendar services. Beyond its organizational capabilities, it also features a built-in cloud photo frame and art gallery, transforming into a dynamic display when not actively used for planning. This device is suitable for various environments including home, kitchen, office, and school settings.



Image: The D1D9 Smart Digital Calendar displayed alongside its mobile application interface, illustrating its primary function as a scheduling and organizational tool.

Setup Guide

1. Unpacking and Initial Placement

Carefully remove the Smart Digital Calendar from its packaging. The device can be placed on a desktop using its removable stand or mounted on a wall. Ensure the chosen location has access to a power outlet as the device requires continuous power to operate.



Image: A detailed diagram illustrating the physical dimensions of the 10.1-inch display, the location of the power button, Type-C port, Micro SD slot, DC power input, removable stand, and wall-mounted hole for installation.

2. Power Connection

Connect the provided power adapter to the DC input port on the back of the device. Plug the adapter into a standard electrical outlet. The device will power on automatically or can be turned on using the power button located on the top edge.

3. App Installation and Wi-Fi Connection

Download the free "FotoCube" application from your mobile device's app store. Once installed, open the app and follow the on-screen instructions to register. You will be prompted to connect the Smart Digital Calendar to your Wi-Fi network. This connection is essential for syncing calendars, uploading photos, and accessing online features. You can typically scan a QR code displayed on the calendar screen or manually input a code within the FotoCube app to establish the connection.

Operating Instructions

1. Smart Calendar Synchronization

The D1D9 Smart Digital Calendar can effortlessly sync with various external calendar services, including Google Calendar, iCloud Calendar, Outlook, Cozi, and Yahoo. This is managed through the FotoCube app.

To Synchronize iCloud Calendar:

1. Open the FotoCube app and navigate to the import section.
2. Select the "Sync" option for iCloud Calendar.
3. Follow the prompts to complete the synchronization process, which may involve logging into your iCloud account.

Image: Visual guide showing the steps to import and synchronize an iCloud calendar with the FotoCube app, including selecting "Import," "Sync," and "Sync iCloud Calendar."

2. Family Calendar Management

The calendar supports multiple family members, allowing each to create and manage their own plans and schedules. Utilize the "Member List Function" within the app to assign different colors to each family member, providing a clear visual distinction for events.



Image: The Smart Digital Calendar displaying a family member list on the mobile app and a user interacting with the calendar on the device, demonstrating personalized planning.

3. Chore Chart and Meal Planner

Easily add, edit, and track chores and meal plans directly on the digital calendar. This feature helps keep your family informed and organized regarding daily tasks and dinner arrangements.

4. Work Plan Creation

Beyond family use, the calendar can be utilized to create and manage work plans, ensuring you stay on top of important meetings and documents. Events can be added directly on the device or through the FotoCube app.



Image: The digital calendar displaying interfaces for daily life planning and work planning, with corresponding mobile app views for adding events like "Make lunch" or "send an email."

5. Cloud Photo Frame & Art Gallery

When not actively used for scheduling, the device transforms into a digital picture frame. Upload and share family photos to the album via the FotoCube app. The calendar also includes an elegant oil painting display function, accessible through the Art Gallery feature.

Image: The Smart Digital Calendar functioning as a cloud photo frame displaying family pictures and as an art gallery showcasing a digital painting, highlighting its dual functionality.

Maintenance

To ensure the longevity and optimal performance of your D1D9 Smart Digital Calendar, follow these maintenance guidelines:

- **Cleaning:** Use a soft, lint-free cloth to gently wipe the touchscreen and device exterior. Avoid abrasive cleaners, solvents, or aerosol sprays, which can damage the screen or finish.
- **Power Supply:** Always use the original power adapter provided with the device. Ensure the device remains plugged into an outlet for continuous operation.
- **Environment:** Keep the device in a dry environment, away from direct sunlight, extreme temperatures, and high humidity.
- **Software Updates:** Periodically check the FotoCube app for any available software or firmware updates for your device to ensure you have the latest features and security enhancements.

Troubleshooting

This section addresses common issues you might encounter with your D1D9 Smart Digital Calendar.

Problem	Possible Cause	Solution
Device does not power on.	Not connected to power, power adapter faulty, or power button not pressed.	Ensure the power adapter is securely connected to both the device and a working electrical outlet. Press the power button firmly.
Cannot connect to Wi-Fi.	Incorrect Wi-Fi password, out of range, or network issue.	Verify the Wi-Fi password. Move the device closer to the router. Restart your router and the digital calendar.
Calendar synchronization issues.	Incorrect account credentials, app not updated, or server issues.	Double-check your login details for the external calendar service (Google, iCloud, etc.). Ensure the FotoCube app is updated to the latest version. Try re-linking the calendar service within the app.
App pairing is difficult or fails.	Bluetooth/Wi-Fi interference, app glitch, or device not in pairing mode.	Ensure both the device and your phone have Wi-Fi enabled. Restart both the app and the digital calendar. Try scanning the QR code again or manually entering the pairing code.
Screen is unresponsive or frozen.	Temporary software glitch.	Perform a soft reset by pressing and holding the power button until the device restarts. If the issue persists, contact customer support.

Specifications

Feature	Detail
Model Number	B0FDFMG16M
Brand	D1D9
Display Size	10.1 inches
Display Type	HD Touchscreen
Color	Black
Material	Plastic
Item Weight	1.85 pounds (0.84 kg)
Package Dimensions	10.75 x 9.37 x 1.46 inches
Calendar Type	Yearly, Engagement Calendar
Connectivity	Wi-Fi, Micro SD, Type-C
Internal Storage	32GB (for Cloud Photo Frame)
Power Source	Requires continuous power via DC input
Target Audience	Adult, Student
UPC	794775728909

Warranty and Support

For detailed warranty information regarding your D1D9 Smart Digital Calendar, please refer to the documentation included with your purchase or visit the official D1D9 website. Warranty terms typically cover manufacturing defects for a specified period from the date of purchase.

If you encounter any issues not covered in the troubleshooting section or require further assistance, please contact D1D9 customer support. Have your model number (B0FDFMG16M) and purchase details ready when contacting support to facilitate a quicker resolution.

You can often find contact information for support on the manufacturer's website or through the FotoCube application.

© 2025 D1D9. All rights reserved.