Manuals+
Q & A | Deep Search | Upload

XREXS 3039YK-B

XREXS 14.17 Inch Digital Wall Clock

Model: 3039YK-B User Manual

1. Introduction

Welcome to your new XREXS Digital Wall Clock. This manual provides comprehensive instructions for the setup, operation, and maintenance of your Model 3039YK-B clock. Please read this document thoroughly to ensure proper use and to fully utilize all features of your device.

2. Features

- **Extra-Large LCD Display:** Features bold, easy-to-read numbers visible from a distance.
- **Automatic Backlight:** Two adjustable brightness levels activate in low light conditions (radar-sensing, approximately 30-second duration).
- **Multi-functional Display:** Shows time (12/24 hour format), date, month, day of the week, and temperature (°F/°C).
- **Integrated Functions:** Includes alarm clock, countdown timer, and stopwatch capabilities.
- **Remote Control:** For convenient setting and operation without needing to access the clock directly.
- **Battery Operated:** Provides flexible placement options without the need for a power outlet.
- **Automatic DST Adjustment:** Automatically adjusts for Daylight Saving Time.
- **Low Battery Indicator:** Notifies you when batteries need replacement.
- **Versatile Placement:** Designed for both wall-mounting and desk-standing.

Figure 2.1: Overview of the clock's multifunctional features.

3. Package Contents

Please verify that all items listed below are included in your package:

- 1 x XREXS 14.17 Inch Digital Wall Clock
- 1 x Remote Control
- 4 x AA Batteries (for clock)
- 2 x AAA Batteries (for remote)
- 1 x Mounting Template (for wall installation)
- 1 x User Manual (this document)

Figure 3.1: XREXS Digital Wall Clock and Remote Control.

4. Setup

4.1 Battery Installation

1. Locate the battery compartment on the back of the clock.
2. Insert 4 AA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
3. For the remote control, open its battery compartment and insert 2 AAA batteries, observing polarity.
4. *Note:* Remove any protective wrapping from the batteries before insertion.

Figure 4.1: Battery compartments and clock dimensions.

4.2 Placement Options

The clock offers two placement methods:

- **Desk Placement:** Extend the fold-out stand located on the back of the clock to place it securely on any flat surface.
- **Wall Mounting:**
  a. Use the provided mounting template to mark the desired screw positions on the wall.
  b. Install two screws into the wall, leaving a small portion of the screw head exposed.
  c. Align the clock's keyhole slots with the installed screws and slide the clock downwards to secure it in place.

Figure 4.2: Wall mount and desk stand options.

5. Operating Instructions

5.1 Initial Power-On

Once batteries are correctly installed, the clock will power on automatically and display default settings.

5.2 Setting Time and Date (Using Remote Control)

1. Press the "SET" button on the remote control. The hour digit on the clock display will begin to flash.
2. Use the "HR" button to adjust the hour.
3. Press "SET" again. The minute digit will flash.
4. Use the "MIN" button to adjust the minute.
5. Continue pressing "SET" to cycle through the year, month, date, and day of the week settings. Adjust each value using the appropriate buttons (e.g., "HR" for year, "MIN" for month/date).
6. Press "SET" one last time to confirm all settings and exit the setting mode.

Figure 5.1: Remote control for easy adjustments.

5.3 12/24 Hour Format

Press the "+/12-24HR" button on the remote control to switch between the 12-hour and 24-hour display formats.

5.4 Temperature Unit (°C/°F)

Press the "°C/°F" button on the remote control to toggle between Celsius and Fahrenheit temperature display units.

5.5 Backlight Function

The clock features an automatic backlight that activates in low light conditions. It offers two brightness levels and remains illuminated for approximately 30 seconds after activation. To disable the backlight, locate the "Backlight" switch on the back of the clock and set it to "Off".

Figure 5.2: Automatic backlight in action.

5.6 Daylight Saving Time (DST)

The clock is equipped with an automatic Daylight Saving Time (DST) adjustment feature. Ensure this feature is enabled if your region observes DST.

5.7 Alarm Clock

1. Press "Alarm SET" on the remote. The alarm hour will flash.
2. Use "HR" to set the desired alarm hour.
3. Press "Alarm SET" again. The alarm minute will flash.
4. Use "MIN" to set the desired alarm minute.
5. Press "Alarm SET" to confirm the alarm setting.
6. To activate or deactivate the alarm, press the "Alarm SET" button briefly outside of setting mode. An alarm icon will appear or disappear on the display to indicate its status.
7. To snooze, press "SNOOZE" when the alarm sounds.

5.8 Timer/Stopwatch

1. Press "Enter Exit Timer" on the remote to enter timer mode.

2. **Countdown Timer:**
    a. Use the "HR", "MIN", and "SEC" buttons to set the desired countdown time.
    b. Press "Timer ST/SP" to start or pause the countdown.
    c. Press "Timer Reset" to clear the timer.
3. **Stopwatch:**
    a. In timer mode, ensure the timer is reset to 00:00:00.
    b. Press "Timer ST/SP" to start the stopwatch.
    c. Press "Timer ST/SP" again to pause.
    d. Press "Timer Reset" to clear the stopwatch.

Figure 5.3: Timer, clock, and alarm modes.

6. Maintenance

- **Cleaning:** Wipe the clock and remote control with a soft, dry cloth. Avoid using abrasive cleaners or chemical solvents, as these may damage the display or casing.
- **Battery Replacement:** Replace all batteries when the low battery indicator appears on the display or when the display dims significantly. Always replace all batteries at once with new ones of the same type

to ensure optimal performance.

7. Troubleshooting

- **Display is dim or blank:**
  - Check if batteries are correctly installed and have sufficient charge. Replace all batteries if necessary.
  - Ensure the backlight switch on the back of the clock is not set to "Off" if you desire illumination.
- **Remote control not working:**
  - Check remote batteries and replace if needed.
  - Ensure there are no obstructions between the remote and the clock.
  - Verify the remote is pointed directly at the clock.
- **Clock not keeping accurate time:**
  - Replace batteries with fresh ones.
  - If the issue persists, contact customer support.
- **Backlight not staying on:**
  - The backlight is radar-sensing and designed to illuminate for approximately 30 seconds. This is normal operation and not a malfunction.

8. Specifications

Attribute	Detail
Brand	XREXS
Model Number	3039YK-B
Display Type	Digital LCD
Dimensions	14.2"W x 5.9"H x 0.98"D
Power Source	Battery Powered (4 x AA for clock, 2 x AAA for remote)
Special Features	Adjustable Backlight, Calendar, Day Mode, DST, Snooze, Alarm, Timer, Stopwatch, Temperature Display
Mounting Type	Wall-mountable, Tabletop
Frame Material	Plastic
Item Weight	2.38 pounds (1.08 Kilograms)

9. Warranty and Support

For warranty information or technical support, please contact XREXS customer service through their official website or the retailer where the product was purchased. Please have your model number (3039YK-B) and purchase details ready when contacting support.