Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HANGSUN HOC-660

HANGSUN Water Flosser HOC-660 Instruction Manual

Comprehensive guide for setup, operation, and maintenance of your HANGSUN Portable Travel Cordless Water Flosser.

1. Introduction

Thank you for choosing the HANGSUN Water Flosser HOC-660. This portable and powerful oral irrigator is designed to provide effective plaque removal and improve your oral hygiene, especially for those with sensitive gums, braces, implants, crowns, or veneers. Its compact, collapsible design makes it ideal for both home use and travel.



Image: The HANGSUN Water Flosser HOC-660 demonstrating its compact and portable design, shown next to a smartphone for scale and easily fitting into a small bag.

2. Safety Information

- Do not charge the device while wet. Ensure the charging port is completely dry before connecting the USB-C cable.
- Keep the device away from open flames or high heat sources.
- This device is not intended for use with certain medical conditions. Consult a healthcare professional if you have concerns.
- Always clean the device and its nozzles thoroughly before and after each use to maintain hygiene and prevent bacterial growth.
- Avoid using hot water or harsh chemical cleaning agents. Use only mild soap and water for cleaning.

3. Package Contents

The HANGSUN Water Flosser HOC-660 package includes:

- 1 x HANGSUN Cordless Water Flosser (Model HOC-660)
- 4 x Standard Jet Tips (for daily cleaning)
- 1 x Orthodontic Jet Tip (for braces and dental appliances)
- 1 x Tongue Cleaning Tip (for tongue coating removal)
- 1 x Travel Storage Pouch
- 1 x USB-C Charging Cable (compatible with any 5V adapter, adapter not included)



Image: All components included with the HANGSUN Water Flosser, laid out for clear viewing.

4. Setup

4.1 Charging the Device

1. Ensure the device is completely dry before charging.

2. Connect the provided USB-C cable to the charging port on the device.
3. Connect the other end of the USB-C cable to a 5V USB power adapter (not included), power bank, or laptop.
4. A full charge takes approximately 4 hours and provides up to 30 days of daily use.



Image: Visual representation of the water flosser's charging capabilities and extended battery life.

4.2 Attaching a Nozzle

1. Select the desired nozzle (Standard, Orthodontic, or Tongue Cleaning).
2. Insert the nozzle into the opening at the top of the flosser until it clicks securely into place.
3. To remove a nozzle, press the small release button located near the nozzle opening and pull the nozzle out.



Image: The various nozzles provided with the water flosser, illustrating their specific uses and the integrated storage feature.

4.3 Filling the Water Tank

1. Open the water tank cover located at the bottom of the device.
2. Extend the telescopic tank by pulling it downwards until fully open.
3. Fill the 180ml tank with lukewarm water. Avoid using hot water or mouthwash directly in the tank unless specified by a dental professional.
4. Close the water tank cover securely.



Image: The collapsible water tank, demonstrating its compact nature for travel and storage.

5. Operating Instructions

5.1 Powering On and Selecting a Mode

1. Press the Power button () to turn on the water flosser.
2. Repeatedly press the Mode button (⇶) to cycle through the 4 available modes:
    - **NORMAL:** For daily powerful cleaning and plaque removal.
    - **SOFT:** Gentle pressure for sensitive gums or first-time users.
    - **PULSE:** Alternating water pulses for deep massage and gum stimulation.
    - **CUSTOM:** Allows for 8 adjustable intensity levels for personalized pressure.
3. The corresponding indicator light will illuminate for the selected mode.



Image: An overview of the water flosser's 4 adjustable modes, designed to cater to various oral care needs.

5.2 Adjusting Custom Mode Intensity

1. Select the CUSTOM mode using the Mode button.
2. Press and hold the Mode button for 3 to 5 seconds until the CUSTOM indicator light begins to flash. This indicates you are in adjustment mode.
3. Repeatedly press the Mode button to cycle through the 8 intensity levels (10 psi to 140 psi).
4. Once your desired pressure level is set, you can begin flossing immediately. The device will remember your last custom setting for future use.



Image: Detailed instructions for customizing the water pressure to suit individual preferences.

5.3 Flossing Technique

1. Before turning on the device, place the nozzle tip in your mouth.
2. Lean over a sink and close your lips slightly around the nozzle to prevent splashing, allowing water to flow into the sink.
3. Aim the water jet at the gumline at a 90-degree angle.
4. Start with your back teeth and work your way to the front, pausing briefly between teeth and along the gumline.
5. For optimal cleaning, follow the gumline and the spaces between your teeth.
6. The device delivers 1,400 pulses per minute and a 0.6mm fine water stream for effective plaque removal.



Image: A visual demonstration of the water flosser's powerful and precise cleaning action.

6. Maintenance

6.1 Cleaning the Device and Nozzles

- After each use, empty any remaining water from the tank.
- Rinse the water tank and nozzles with clean water.
- Wipe the exterior of the device with a soft, damp cloth. Do not immerse the main unit in water, although it is IPX7 waterproof for shower use, it should not be submerged for cleaning.
- For deeper cleaning, use mild soap and water. Avoid abrasive cleaners or harsh chemicals.



Image: The water flosser's IPX7 waterproof feature, indicating its suitability for use in the bathroom.

6.2 Storage

- Ensure the device is clean and dry before storing.
- The water tank can be collapsed for compact storage.
- Store nozzles in the built-in nozzle storage compartment on the device or in the provided travel pouch to keep them hygienic and protected.

Image: The convenient built-in storage for nozzles, enhancing portability and hygiene.

7. Troubleshooting

- **Device not turning on:** Ensure the device is fully charged. If the battery is low, charge it for 4 hours.
- **Weak water pressure:** Check if the water tank is sufficiently filled. Ensure the nozzle is securely attached. Clean the nozzle for any blockages.
- **Water leakage:** Verify that the water tank cover is securely closed and the nozzle is properly inserted.
- **Device not charging:** Ensure the USB-C cable is correctly connected to both the device and the power source. Confirm the power source is active. Ensure the charging port is dry.

8. Specifications

Brand	HANGSUN
Model Number	HOC-660
Water Tank Capacity	180ml (collapsible)
Water Pressure	Up to 140 PSI (Custom mode: 10-140 PSI)
Pulsations Per Minute	1,400 IPS
Nozzle Types	Standard (x4), Orthodontic (x1), Tongue Cleaning (x1)
Battery Life	Up to 30 days on a single charge
Charging Time	Approx. 4 hours (USB-C)
Waterproof Rating	IPX7
Dimensions (Collapsed)	Approx. 5.39 inches tall

Weight	Approx. 13.76 ounces

9. Warranty and Support

The HANGSUN Water Flosser HOC-660 comes with a 2-year worry-free warranty. For warranty claims or after-sales support, please refer to the QR code on the product packaging or in this manual, or contact the seller directly.
For further assistance, please visit the official HANGSUN support website or contact customer service.

© 2025 HANGSUN. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FGXBVKG8

More documents and user manuals: **https://manuals.plus/**