Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Sweetcrispy KZ-D6QT-GY

Sweetcrispy 6-Quart Air Fryer with Window Instruction Manual

Model: KZ-D6QT-GY

1. Important Safeguards

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface.

2. Product Overview

Components

The Sweetcrispy 6-Quart Air Fryer consists of the main unit, a removable non-stick crisper basket, and an integrated control panel.



Image: The Sweetcrispy 6-Quart Air Fryer in grey, with its square crisper basket partially extended, revealing food being cooked. The top features a digital touch control panel.

Features

- **Clear Viewing Window:** Allows monitoring of food without opening the basket, maintaining consistent temperature and cooking times.
- **Large 6.34-Quart Capacity:** Designed for family meals, the square basket maximizes cooking space.
- **Safe and Non-toxic Materials:** Constructed with materials free from harmful chemicals.
- **Dishwasher Safe Basket:** The non-stick crisper basket and accessories are safe for dishwasher cleaning.

- **12-in-1 Functions:** Offers versatile cooking options including Air Fry, Roast, Bake, Reheat, Dehydrate, and specific presets for various foods.
- **Digital Touch Control Panel:** Intuitive interface for setting temperature, time, and selecting cooking presets.



Image: A close-up of the Sweetcrispy Air Fryer's clear viewing window, through which a whole chicken is visible during the cooking process.



Image: The top-mounted digital touch control panel of the air fryer, displaying various cooking functions such as Air Fry, Roast, Bake, Reheat, Dehydrate, Chicken, Fries, Steam, Custard Tart, Wings, Seafood, and Vegetables. A digital timer and temperature display are also visible.

3. Setup

Unpacking and Initial Cleaning

1. Remove all packaging materials, stickers, and labels from the appliance.
2. Wash the crisper basket and any removable accessories in hot, soapy water. Rinse and dry thoroughly.
3. Wipe the interior and exterior of the appliance with a clean, damp cloth.
4. Before first use, it is recommended to run the air fryer empty for approximately 10-15 minutes at 350°F (175°C) to eliminate any manufacturing odors. Ensure the area is well-ventilated during this process.

Placement

- Place the air fryer on a stable, level, and heat-resistant surface.

- Ensure there is at least 6 inches (15 cm) of clear space around the back and sides of the appliance to allow for proper air circulation.
- Do not place the air fryer directly under cabinets or near flammable materials.

4. Operating Instructions

General Operation

1. Plug the power cord into a grounded wall outlet. The display will illuminate.
2. Pull out the crisper basket. Place ingredients into the basket. Do not overfill.
3. Slide the crisper basket back into the air fryer until it clicks into place.
4. Select a preset function or manually set the desired temperature and time using the touch controls.
5. Press the Start/Pause button to begin cooking.
6. During cooking, you can pull out the basket to shake or flip ingredients. The air fryer will pause automatically and resume when the basket is reinserted.
7. The air fryer will beep when the cooking cycle is complete. Carefully remove the basket and transfer food to a serving dish.

Preset Functions

The Sweetcrispy Air Fryer features 12 preset cooking functions for convenience. Each preset has a default temperature and time, which can be adjusted manually.

Function	Description
Air Fry	For crispy results with minimal oil.
Roast	Ideal for meats and vegetables.
Bake	Suitable for cakes, pastries, and other baked goods.
Reheat	Warms up leftovers efficiently.
Dehydrate	For drying fruits, vegetables, or making jerky.
Chicken	Optimized for cooking chicken pieces.
Fries	Achieves crispy french fries.
Steam	For gentle cooking with steam (requires additional accessories, not included).
Custard Tart	Specific setting for custard tarts.
Wings	Designed for cooking chicken wings.
Seafood	Suitable for various seafood preparations.
Vegetables	For roasting or air frying vegetables.

5. Cleaning and Maintenance

Regular cleaning ensures optimal performance and extends the lifespan of your air fryer.

1. Always unplug the air fryer and allow it to cool completely before cleaning.

2. **Crisper Basket and Accessories:** The non-stick crisper basket and any removable accessories are dishwasher safe. Alternatively, wash them in hot, soapy water using a non-abrasive sponge.
3. **Interior:** Wipe the interior of the air fryer with a damp cloth or non-abrasive sponge. For stubborn food residue, a small amount of mild dish soap can be used. Ensure no water enters the heating element.
4. **Exterior:** Wipe the exterior with a damp cloth. Do not use harsh abrasive cleaners or scouring pads, as they may damage the finish.
5. **Heating Element:** If necessary, gently clean the heating element with a soft brush to remove any food particles.
6. Ensure all parts are completely dry before storing or using the air fryer again.

6. Troubleshooting

If you encounter issues with your air fryer, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Air fryer does not turn on.	Not plugged in; power outlet malfunction; basket not fully inserted.	Ensure the power cord is securely plugged into a working outlet. Push the crisper basket fully into the unit until it clicks.
Food is not cooked evenly.	Basket is overfilled; food not shaken/flipped.	Do not overfill the basket. Shake or flip ingredients halfway through cooking for even results.
White smoke coming from the appliance.	Grease from previous use; fatty ingredients.	Clean the basket and interior thoroughly after each use. For fatty foods, consider draining excess oil.
Appliance emits a plastic smell during first uses.	New appliance odor.	This is normal for new appliances. Run the air fryer empty for 10-15 minutes in a well-ventilated area before first use. The smell should dissipate with subsequent uses.
Food is not crispy.	Insufficient cooking time/temperature; too much moisture.	Increase cooking time or temperature. Pat food dry before cooking. Use a light coating of oil for best crispiness.

7. Specifications

Feature	Detail
Brand	Sweetcrispy
Model Name	Air Fryer 6QT with Window
Model Number	KZ-D6QT-GY
Capacity	6.34 Quarts
Product Dimensions (D x W x H)	10.5" x 12.9" x 13.6"
Material	Polypropylene (PP)
Output Wattage	1700 Watts

Feature	Detail
Special Feature	Temperature Control, Viewing Window
Nonstick Coating	Yes
Dishwasher Safe Parts	Basket and accessories
Item Weight	9.9 Pounds
UPC	781434693708

8. Warranty and Support

For warranty information or product support, please refer to the documentation included with your purchase or contact Sweetcrispy customer service. Keep your purchase receipt as proof of purchase for any warranty claims.

© 2025 Sweetcrispy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FH43YS6Y

More documents and user manuals: **https://manuals.plus/**