Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BMAX BMR809

BMAX BMR809 Digital LED Alarm Clock User Manual

Model: BMR809

Introduction

Thank you for purchasing the BMAX BMR809 Digital LED Alarm Clock. This device is designed to provide accurate time, temperature display, and a gentle alarm function, suitable for various indoor environments. Please read this manual carefully before use to ensure proper operation and longevity of your device.



Image: The BMAX BMR809 clock displaying time and temperature in a modern office setting.

Package Contents

- 1 x BMAX BMR809 Digital LED Alarm Clock
- 1 x USB Power Cable

- 2 x AAA Batteries (for time backup, included)

Product Features

- Large LED Display for easy readability.
- Time and Temperature display.
- 3-level adjustable brightness.
- Silent alarm function with gentle tone.
- Versatile placement: tabletop or wall-mounted.
- USB powered with battery backup for time settings.



Image: Key features of the BMAX BMR809 clock highlighted.

Setup

1. Power Connection

1. Insert the small end of the USB power cable into the DC 5V port on the back of the clock.
2. Plug the other end of the USB cable into a standard USB power adapter (not included) or a powered USB port.
3. The display will light up, indicating the clock is powered on.

2. Battery Installation (for Time Backup)

1. Locate the battery compartment on the back of the clock.
2. Open the battery compartment cover.
3. Insert 2 AAA batteries, ensuring correct polarity (+ and -).
4. Close the battery compartment cover. These batteries will maintain time settings during power outages.

Operating Instructions

1. Setting the Time

Specific buttons for time setting are usually located on the back or side of the clock. Look for buttons labeled "SET", "TIME", or similar.

1. Press and hold the "SET" button (or equivalent) until the hour digits start flashing.
2. Use the "UP" or "DOWN" buttons (or "+" / "-" buttons) to adjust the hour.
3. Press "SET" again to move to the minute digits.

4. Use the "UP" or "DOWN" buttons to adjust the minutes.
5. Press "SET" one more time to confirm and exit time setting mode.

2. Setting the Alarm

Look for buttons labeled "ALARM", "AL", or an alarm icon.

1. Press and hold the "ALARM" button until the alarm hour digits start flashing.
2. Use the "UP" or "DOWN" buttons to set the desired alarm hour.
3. Press "ALARM" again to move to the alarm minute digits.
4. Use the "UP" or "DOWN" buttons to set the desired alarm minutes.
5. Press "ALARM" one more time to confirm. An alarm icon should appear on the display, indicating the alarm is active.
6. To turn off the alarm sound when it rings, press any button. To disable the alarm completely, press the "ALARM" button until the alarm icon disappears.

3. Adjusting Brightness

The clock features 3 levels of brightness. Look for a "BRIGHTNESS" button, a sun icon, or a general "MODE" button that cycles through brightness settings.

1. Press the "BRIGHTNESS" button (or equivalent) repeatedly to cycle through the brightness levels (High, Medium, Low).
2. Select the level that best suits your environment.



Image: The clock displaying time and temperature in a low-light bedroom setting.

4. Temperature Display

The clock automatically displays the ambient temperature in Celsius (°C). No specific setting is usually required for this function.

Mounting Options

1. Tabletop Placement

Place the clock on any flat, stable surface such as a desk, nightstand, or shelf. Ensure it is not near direct heat sources or in direct sunlight.

2. Wall Mounting

1. Locate the keyhole slots on the back of the clock.
2. Mark the desired position on the wall for the mounting screws (screws not included). Ensure the marks are level and match the keyhole spacing.

3. Install appropriate screws into the wall, leaving the screw heads slightly protruding.
4. Align the keyhole slots on the back of the clock with the screw heads and slide the clock down to secure it.



Image: The clock displayed as a wall-mounted unit in a reception area.

Maintenance

- **Cleaning:** Wipe the clock with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** Replace AAA backup batteries annually or when the clock fails to retain time during power outages.
- **Environment:** Avoid exposing the clock to extreme temperatures, humidity, or direct sunlight.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Display is blank	No power supply.	Check USB cable connection and power source. Ensure the USB adapter is working.
Time is incorrect after power outage	Backup batteries are dead or not installed.	Install or replace 2 AAA backup batteries.
Alarm does not sound	Alarm is not set or is disabled.	Ensure the alarm is set correctly and the alarm icon is visible on the display.
Temperature reading seems inaccurate	Clock is placed near a heat source or in direct sunlight.	Move the clock to a location with stable ambient temperature.

Specifications

- **Model:** BMR809
- **Brand:** BMAX
- **Display Type:** Digital LED
- **Color:** Black
- **Material:** ABS Plastic
- **Dimensions:** Approximately 25cm (L) x 9cm (H)
- **Power Source:** USB Cable (DC 5V)
- **Backup Battery:** 2 x AAA (included)
- **Special Features:** Alarm, Temperature Display, Adjustable Brightness
- **Mounting:** Tabletop or Wall Mount

Warranty and Support

This product comes with a standard manufacturer's warranty. For specific warranty details, please refer to the product packaging or contact your retailer. For technical support or inquiries, please contact the vendor through your purchase platform.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FH7CP597

More documents and user manuals: **https://manuals.plus/**