Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SICOTAS TV113

SICOTAS TV Stand Model TV113 (59-inch) Instruction Manual

Brand: SICOTAS | Model: TV113

Important Safety Information

Please read and understand all instructions before assembly and use. Failure to follow these instructions may result in injury or product damage.

- Always assemble with at least two people to ensure stability and safety.
- Be cautious of sharp edges on metal mesh doors during assembly and handling.
- Do not place heavy objects on the top shelf that exceed the weight capacity to prevent tipping.
- Keep the TV stand away from direct heat sources, such as radiators or fireplaces, to prevent damage to the finish and material.
- Keep small parts and hardware out of reach of children to prevent choking hazards.
- Ensure all connections are securely tightened before use. Periodically check and re-tighten hardware as needed.

Package Contents

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

Component	Quantity
Top Panel	1
Side Panels	2
Bottom Panel	1
Back Panels	Multiple
Doors with Metal Mesh	4
Adjustable Shelves	4
Legs	5 (4 main, 1 center support)

Component	Quantity
Door Handles	4
Hardware Pack (screws, dowels, hinges, magnetic catches, shelf pins, etc.)	1
Installation Tools	1 set
User Manual	1

Assembly Instructions

Follow these steps carefully. It is recommended to assemble the unit on a soft, clean surface to prevent scratches.

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out and compare them with the parts list to ensure everything is present and undamaged.
2. **Attach Legs:** Secure the five legs to the bottom panel using the provided hardware. Ensure the center support leg is properly positioned for stability.
3. **Assemble Frame:** Connect the side panels to the bottom panel, then attach the top panel. Use the appropriate screws and dowels as indicated in the detailed assembly diagram (refer to included paper manual for diagrams).
4. **Install Back Panels:** Slide or fasten the back panels into place. Ensure the cable management holes are correctly oriented.
5. **Install Door Hinges:** Attach the hinges to the doors and then to the main frame of the TV stand. Adjust hinges as necessary for proper door alignment.
6. **Attach Door Handles:** Secure the elegant gold handles to the front of each door.
7. **Insert Adjustable Shelves:** Place the shelf pins into the desired height positions within the cabinet compartments. Carefully slide the adjustable shelves onto the pins.
8. **Final Checks:** Ensure all screws are tightened, and the unit is stable. Gently test the doors to confirm they open and close smoothly.

Product Dimensions

Practical storage solutions



Dimensions
Overall: 58.5"W x 13.9"D x 28.9"H

Image: Fully assembled SICOTAS TV Stand, showcasing its design and closed doors.



Image: Interior view of the TV stand with doors open, highlighting the adjustable shelves and cable management features.

Setup

Placement

Choose a flat, level surface for the TV stand to ensure stability. Avoid placing it in direct sunlight or near heat sources to prevent material degradation.

TV Size Compatibility

This TV stand is designed to accommodate televisions up to 65 inches. Ensure your TV's base fits within the dimensions of the top panel (58.5" W x 13.9" D).



Image: Product dimensions diagram, illustrating the overall size and suitable TV sizes.

Operating Instructions

Adjustable Shelving

The interior shelves can be adjusted to three different heights to accommodate various media devices, books, or decorative items. To adjust, remove the shelf, reposition the shelf pins to the desired height, and then reinsert the shelf.



Image: Detailed view of the adjustable shelves inside the cabinet.

Cable Management

Utilize the integrated cable management holes on the back panel to route and organize power cords and audio/video cables. This helps maintain a tidy and professional appearance.

Door Operation

The four doors feature magnetic catches for secure closure and elegant gold handles for easy opening. The snowflake metal mesh design allows for remote control signals to pass through to devices stored inside.



Image: Close-up of the snowflake metal mesh design on the cabinet doors.

Product Overview Video

▶ **Watch video online**
SICOTAS TV Stand for Bedroom

Video: A brief overview of the SICOTAS TV Stand, highlighting its design elements and features such as the snowflake metal mesh, elegant gold handles, adjustable shelves, and thick top panel.

Maintenance

- **Cleaning:** Wipe the surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as they may damage the finish.
- **Dusting:** Regularly dust the unit with a dry, soft cloth to prevent buildup.
- **Spills:** Immediately wipe up any spills to prevent staining or water damage.
- **Hardware Check:** Periodically inspect all screws and connections to ensure they remain tight. Re-tighten if necessary.

- **Movement:** When moving the TV stand, always lift it rather than dragging it to prevent damage to the legs and frame.

Troubleshooting

Problem	Possible Cause	Solution
Unit is wobbly or unstable.	Loose hardware; uneven floor.	Check and tighten all screws. Ensure the unit is on a level surface; use shims if necessary.
Doors do not close properly or are misaligned.	Hinges are loose or incorrectly adjusted; magnetic catches are misaligned.	Adjust the door hinges using a screwdriver. Ensure magnetic catches are securely installed and aligned with the door.
Shelves are not level.	Shelf pins are not inserted correctly or are at different heights.	Remove the shelf and re-insert shelf pins into corresponding holes at the same height on both sides.
Missing parts or damaged components.	Packaging error or shipping damage.	Contact SICOTAS customer support with your purchase details for assistance.

Specifications

Brand: SICOTAS

Model Name: TV113 59 Inches TV Stand

Color: Light Walnut

Material: Engineered Wood

Product Dimensions: 58.5" W x 13.9" D x 28.9" H

Item Weight: 59 Pounds

Number of Shelves: 4 (3-height adjustable)

Special Features: 4 Cable Management Holes, Adjustable Shelving, Snowflake Metal Mesh Doors

Mounting Type: Floor Mount

Assembly Required: Yes

UPC: 635508494497

Warranty and Customer Support

For warranty information, missing parts, or any questions regarding your SICOTAS TV Stand, please refer to the warranty card included in your package or contact SICOTAS customer support directly. Our dedicated customer service team is available to assist you.
Please retain your proof of purchase for any warranty claims.

© 2025 SICOTAS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the

question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FHJ44S15

More documents and user manuals: **https://manuals.plus/**