Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

NutriBullet NB9-0901AK

NutriBullet Pro Personal Blender User Manual

Model: NB9-0901AK

1. Introduction

Welcome to the NutriBullet Pro experience. This personal blender is designed to effortlessly blend fruits, vegetables, and liquids into nutritious smoothies, helping you achieve a healthier lifestyle. Please read this manual thoroughly before first use to ensure safe and optimal operation of your appliance.

Important Safeguards

- Always unplug the NutriBullet Pro when not in use, before assembling or disassembling parts, and before cleaning.
- Do not immerse the motor base in water or any other liquid.
- Avoid contact with moving parts. Blades are sharp; handle with care.
- Keep hands and utensils out of the container while blending to reduce the risk of severe injury to persons or damage to the blender.
- Do not blend hot liquids, as this may cause pressure buildup and result in injury.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

2. What's Included

Your NutriBullet Pro package includes the following components:

- 1 x 900W Motor Base
- 1 x Extractor Blade
- 1 x 32 oz (900ml) Cup
- 1 x 24 oz (700ml) Cup
- 1 x To-Go Lid
- 1 x Lip Ring
- 1 x Lip Ring with Handle
- User Guide (this document)



Image: All components included with the NutriBullet Pro Personal Blender, featuring the motor base, extractor blade, various cups, and lids.

3. Setup

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Placement:** Place the motor base on a clean, dry, and level surface. Ensure the surface is stable and away from the edge of the counter.
3. **Power:** Ensure the power cord is easily accessible and that the voltage of your outlet matches the appliance's requirements (120V for North American standards). Do not plug in the unit yet.
4. **Prepare Cup:** Add your desired ingredients to one of the NutriBullet cups. Do not fill ingredients past the MAX line.
5. **Attach Blade:** Screw the Extractor Blade firmly onto the open end of the cup until it is tightly sealed.



Image: A close-up view of the stainless steel Extractor Blade, designed for efficient nutrient extraction.

4. Operating Instructions

1. **Plug In:** Plug the power cord into a standard electrical outlet.
2. **Place Cup:** Invert the cup (with the blade assembly facing down) onto the motor base.
3. **Blend:** Press down firmly on the cup and twist clockwise until the tabs lock into place. The blender will start operating. Blend until your desired consistency is achieved. For best results, blend for no more than one minute at a time. If ingredients are too thick, pulse by pressing down and releasing the cup several times.
4. **Stop Blending:** To stop blending, twist the cup counter-clockwise and lift it off the motor base.
5. **Serve:** Unscrew the Extractor Blade from the cup. You can then attach a To-Go Lid or Lip Ring for immediate consumption.

Blending Tips:

- Always add liquids first for smoother blending.
- Do not overfill the cup; ensure ingredients are below the MAX line.
- For frozen ingredients, use a 1:1 ratio of frozen to fresh ingredients, and add sufficient liquid.
- If the motor sounds strained, add more liquid.



Image: A user demonstrating the simple push-and-twist operation of the NutriBullet Pro Personal Blender.

5. Maintenance and Cleaning

Proper cleaning ensures the longevity and hygiene of your NutriBullet Pro.

1. **Unplug:** Always ensure the motor base is unplugged from the power outlet before cleaning.
2. **Cups and Lids:** Twist off the Extractor Blade from the cup. Rinse the cups, lids, and lip rings with soap and water immediately after use. All cups and lids are top-rack dishwasher safe.
3. **Extractor Blade:** Rinse the Extractor Blade under running water. Use a brush to clean around the blades if necessary. Do not put the Extractor Blade in the dishwasher, as this can damage the gasket.
4. **Motor Base:** Wipe the motor base with a damp cloth. Never immerse the motor base in water or any other liquid.
5. **Drying:** Ensure all parts are completely dry before storing.



Image: A user cleaning a NutriBullet cup under running water, highlighting the ease of maintenance.

6. Troubleshooting

If you encounter any issues with your NutriBullet Pro, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Blender does not turn on	Not plugged in; Cup not properly engaged; Overload protection activated.	Check power connection; Ensure cup is twisted securely onto the base; Unplug for 15 minutes to reset, then try again.
Leaking from the cup	Blade not tightened; Cup overfilled; Gasket damaged.	Ensure blade is tightly screwed on; Do not fill past MAX line; Inspect gasket for damage and replace if necessary.
Motor stops during blending	Overheating due to prolonged use or thick ingredients; Overload protection activated.	Unplug and let cool for 15 minutes; Reduce ingredient load or add more liquid; Blend in shorter intervals.
Ingredients not blending smoothly	Too little liquid; Too many hard ingredients; Ingredients stuck.	Add more liquid; Reduce amount of hard ingredients; Pulse the blender or shake the cup gently to dislodge ingredients.

7. Specifications

Brand	NutriBullet
Model Number	NB9-0901AK
Wattage	900 watts
Voltage	120 volts
Capacity	32 oz (900ml) and 24 oz (700ml) cups
Product Dimensions	5.5"D x 5.5"W x 7.9"H
Material	Plastic, Stainless Steel
Special Feature	Dishwasher Safe (cups and lids)
Control Type	Manual
UPC	810097970014

8. Warranty and Support

Your NutriBullet Pro Personal Blender comes with a limited warranty. For full details regarding the warranty period, coverage, and terms, please refer to the warranty card included in your product packaging or visit the official NutriBullet website.

For customer support, troubleshooting assistance, or to purchase replacement parts, please visit the official NutriBullet store or contact their customer service department:

Official NutriBullet Store: Visit Store

Please have your model number (NB9-0901AK) and proof of purchase ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FJF3P5GV

More documents and user manuals: **https://manuals.plus/**