Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Goldair GAF-23H

Goldair Air Fryer Oven (Model GAF-23H)

23 Litre Capacity Instruction Manual

1. Introduction

Thank you for purchasing the Goldair Air Fryer Oven. This appliance is designed to provide a versatile cooking experience, combining the functions of an air fryer and a compact oven. Please read this instruction manual thoroughly before operating the appliance to ensure safe and efficient use. Keep this manual for future reference.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons. Read all instructions carefully.

- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Oversized foods or metal utensils must not be inserted in a toaster oven as they may create a fire or risk of

electric shock.

- A fire may occur if the oven is covered or touching flammable material, including curtains, drapes, walls, and the like, when in operation.
- Do not place any of the following materials in the oven: paper, cardboard, plastic, and the like.
- Do not store any materials, other than manufacturer's recommended accessories, in this oven when not in use.
- Do not place cooking utensils or baking dishes on the glass door.

3. Product Overview

Familiarize yourself with the components of your Goldair Air Fryer Oven before first use.



Image: Front view of the Goldair Air Fryer Oven, showing the control panel, door, and interior with food.

Main Components:

- **Control Panel:** Features knobs for temperature, cooking function, and timer.
- **Oven Door:** Transparent glass door for viewing cooking progress.
- **Interior Cavity:** 23 Litre capacity, designed for various cooking tasks.
- **Heating Elements:** Located at the top and bottom for even cooking.
- **Power Cord:** For connecting to an electrical outlet.

Included Accessories:

- 1 x Goldair Air Fryer Oven, 23 Litre Capacity (main unit)
- *Additional accessories such as air fry basket, baking pan, or oven rack may be included. Refer to your packaging for a complete list.*

4. Setup

Follow these steps to set up your air fryer oven for the first time.

1. **Unpack:** Carefully remove the appliance and all accessories from the packaging. Retain packaging for future storage or transport if needed.
2. **Clean:** Wipe the exterior of the oven with a damp cloth. Wash all removable accessories (e.g., air fry basket, baking pan) in warm, soapy water, rinse thoroughly, and dry completely.
3. **Placement:** Place the oven on a stable, level, heat-resistant surface. Ensure there is at least 10-15 cm of clear space on all sides and above the oven for proper ventilation. Do not place near flammable materials.
4. **First Use (Burn-off):** Before cooking food, operate the oven empty for approximately 15 minutes at 200°C (400°F) on the 'Bake' or 'Roast' function. This will help burn off any manufacturing residues and eliminate initial odors. A slight smoke or odor is normal during this process. Ensure the area is well-ventilated.

5. Operating Instructions

This section details how to operate your Goldair Air Fryer Oven for various cooking functions.

General Operation:

1. **Plug In:** Ensure the oven is unplugged before loading food. Once food is placed inside, plug the power cord into a grounded electrical outlet.
2. **Load Food:** Place food on the appropriate accessory (e.g., air fry basket for air frying, baking pan for baking). Insert the accessory into the oven cavity.
3. **Select Function:** Turn the Function knob to select the desired cooking mode (e.g., Air Fry, Bake, Roast, Toast).
4. **Set Temperature:** Turn the Temperature knob to the desired cooking temperature.
5. **Set Timer:** Turn the Timer knob to the desired cooking time. The oven will begin heating once the timer is set. A bell will sound when the timer reaches zero.
6. **Monitor Cooking:** Use the oven door to observe cooking progress. For even cooking, especially with air frying, it may be necessary to shake or flip food halfway through the cooking cycle.
7. **Remove Food:** Once cooking is complete and the timer sounds, carefully open the oven door. Use oven mitts to remove the hot food and accessories.
8. **Unplug:** Always unplug the appliance from the power outlet after use.

Cooking Tips:

- For best air frying results, do not overcrowd the air fry basket. Cook in batches if necessary.
- Lightly oiling food can enhance crispiness when air frying.
- Preheating the oven for 5-10 minutes before adding food can improve cooking results for most functions.
- Cooking times may vary based on food quantity, density, and desired doneness. Adjust as needed.

6. Cleaning and Maintenance

Regular cleaning and proper maintenance will ensure the longevity and optimal performance of your Goldair Air Fryer Oven.

1. **Unplug and Cool:** Always unplug the oven from the power outlet and allow it to cool completely before

cleaning.

2. **Exterior:** Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or scouring pads, as they may damage the finish.
3. **Interior:** Wipe the interior walls with a damp cloth and mild detergent. For stubborn stains, a non-abrasive sponge can be used. Ensure the interior is dry before next use.
4. **Accessories:** Wash the air fry basket, baking pan, and other removable accessories in warm, soapy water. They may also be dishwasher safe (check individual accessory instructions if provided). Rinse and dry thoroughly.
5. **Crumb Tray:** If your model includes a removable crumb tray, slide it out and empty crumbs after each use. Wash and dry it.
6. **Do Not Immerse:** Never immerse the main unit, power cord, or plug in water or any other liquid.
7. **Storage:** Store the clean and dry oven in a cool, dry place.

7. Troubleshooting

If you encounter any issues with your Goldair Air Fryer Oven, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in. Power outlet malfunction. Timer not set.	Ensure power cord is securely plugged into a working outlet. Check circuit breaker. Turn the timer knob to the desired cooking time.
Food is not cooking evenly.	Overcrowding the basket/tray. Incorrect temperature/time.	Cook food in smaller batches. Shake or flip food halfway through cooking. Adjust temperature and time as per recipe or food type.
White smoke coming from the oven.	Excess oil/grease from food. Food residue on heating elements.	Ensure drip tray is clean. Clean the interior of the oven and heating elements after cooling. Use less oil if possible.
Food is not crispy.	Too much moisture in food. Overcrowding. Not enough cooking time/high enough temperature.	Pat food dry before cooking. Cook in smaller batches. Increase cooking time or temperature slightly.

If the problem persists after trying these solutions, please contact Goldair customer support or a qualified service technician.

8. Specifications

Key technical specifications for the Goldair Air Fryer Oven (Model GAF-23H).

- **Model Name:** Air Fryer
- **Model Number:** GAF-23H

- **Brand:** Goldair
- **Capacity:** 23 Liters
- **Material:** Stainless Steel
- **Color:** Black
- **Product Dimensions (D x W x H):** 40.3 cm x 32.3 cm x 20.3 cm
- **Special Feature:** Durable construction
- **Country of Origin:** South Africa

9. Warranty and Support

For warranty information, please refer to the warranty card included with your product or visit the official Goldair website. Do not attempt to repair the appliance yourself, as this may void the warranty and pose safety risks. For technical support, spare parts, or service inquiries, please contact Goldair customer service through their official channels. Contact details are typically available on the product packaging or the manufacturer's website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FJG7KDT8

More documents and user manuals: **https://manuals.plus/**