Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Sweetcrispy A-SWELT48WT

Sweetcrispy Electric Standing Desk User Manual

Model: A-SWELT48WT | Size: 48x24 inch

Introduction

Welcome to your new Sweetcrispy Electric Standing Desk. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure optimal use of your adjustable height workstation. Please read this manual thoroughly before using the product.

Safety Information

- Read all instructions before assembly and initial use.
- Ensure all screws and bolts are tightened securely before operating the desk.
- Keep children and pets away from the desk during height adjustments.
- Do not exceed the maximum weight capacity of 176 lbs (80 kg).
- Avoid placing liquids directly on the control panel or motor components.
- Disconnect power before cleaning or performing any maintenance.
- Do not attempt to modify the desk's structure or electrical components.

Package Contents

Please verify that all components are present and undamaged before beginning assembly:

- Desk Frame (Stainless Steel)
- Desktop (Wood, 2 spliced panels)
- Control Panel with LED Display
- Power Adapter
- Assembly Tools (e.g., L-wrench)
- Instruction Manual
- Wire Collector
- Headphone Hooks (set of 2)



Image: Overview of Sweetcrispy Electric Standing Desk components, showing the frame, two-piece desktop, control panel, and included accessories like headphone hooks and cable management.

Assembly Instructions

The desktop is provided in two pieces for easier handling and assembly. Follow these steps carefully:

1. Unpack all components and verify against the package contents list.
2. Assemble the desk frame according to the included diagrams. Ensure all connections are secure and tightened.
3. Attach the two desktop panels. The seamless splicing design ensures a sturdy and stable surface.
4. Mount the control panel to the underside of the desk in the designated location.
5. Install the wire collector and headphone hooks as desired for cable management and accessory storage.
6. Connect the power adapter to the control box and then to a standard electrical outlet.

Note:
Some assembly steps may require a Phillips screwdriver or drill (not included) in addition to the provided L-wrench. Exercise caution to avoid stripping screws or damaging the wood desktop during installation.



Image: Diagram illustrating the assembly process of the Sweetcrispy Electric Standing Desk, highlighting the frame structure and desktop attachment.

Operating Instructions

Power On/Off

Connect the power cord to a wall outlet. The LED display on the control panel will illuminate, indicating the desk is powered on and ready for use.

Adjusting Height

- Press and hold the **Up (▲)** or **Down (▼)** arrow buttons to smoothly adjust the desk height.
- Release the button when the desired height is reached. The current height will be shown on the LED display.
- The desk operates quietly (under 50 dB) during adjustment, minimizing disruption.

Memory Presets

The desk features 3 memory presets for quick and convenient height adjustments:

1. Adjust the desk to your desired height using the Up/Down buttons.
2. Press the **"S"** button (Set).
3. Within 3 seconds, press one of the numbered buttons (**1, 2, or 3**) to save the current height to that preset.
4. To recall a saved height, simply press the corresponding numbered button (**1, 2, or 3**). The desk will automatically move to the stored height.



Image: Close-up of the Sweetcrispy Electric Standing Desk's multi-function control panel, showing the LED display, up/down arrows, and three memory preset buttons for height storage.

Anti-Collision Feature

The desk is equipped with an anti-collision system. If the desk encounters an obstacle during height adjustment (either moving up or down), it will automatically stop and reverse slightly to prevent damage to the desk or the obstruction.



Image: Illustration of the desk's anti-collision technology, showing the desk stopping and retracting upon encountering an obstacle like a cabinet.

Maintenance

- Wipe the desk surface with a dry cloth for cleaning. Avoid using abrasive cleaners or harsh chemicals that could damage the finish.
- Regularly check all screws and bolts to ensure they remain tight. Re-tighten if necessary to maintain stability.
- Keep the motor and electrical components free from dust and moisture to ensure proper function and longevity.

Troubleshooting

Problem	Possible Cause	Solution
Desk does not move	Power cord disconnected or power outage.	Ensure the power cord is securely plugged into the desk and a working electrical outlet. Check the circuit breaker.
Desk moves unevenly or only one side moves	Motor or frame assembly issue, or drive shaft misalignment.	Check all frame connections and ensure the drive shaft is properly engaged between the legs. Refer to assembly instructions. If the problem persists, contact customer support.
Desk stops during adjustment	Anti-collision feature activated.	Remove any obstacles in the desk's path (above or below).
LED display shows an error code	System fault or temporary malfunction.	Unplug the desk from the power outlet for 10 seconds, then plug it back in. If the error persists, contact customer support.

Specifications

- **Brand:** Sweetcrispy
- **Model Number:** A-SWELT48WT
- **Dimensions (D x W x H):** 23.6"D x 48"W x 28.7"-46.5"H

- **Minimum Height:** 28.7 inches
- **Maximum Height:** 46.5 inches
- **Weight Capacity:** 176 lbs (80 kg)
- **Desktop Material:** Wood
- **Base Material:** Stainless Steel
- **Color:** White
- **Motor Noise Level:** <50 dB
- **Special Features:** Adjustable Height, Electric, Ergonomic, 3 Memory Presets, Anti-Collision Technology, Cable Management Hole, Headphone Hooks.



Image: Diagram showing the product dimensions (48" W x 23.6" D) and height adjustment range (28.7" to 46.5"), along with features like cable management holes and headphone hooks.

Warranty and Support

This Sweetcrispy Electric Standing Desk comes with a limited warranty. For specific warranty details, please refer to the

documentation included in your package or contact Sweetcrispy customer support directly.

For technical assistance, inquiries about missing parts, or warranty claims, please visit the official Sweetcrispy website or contact their customer service department using the information provided with your purchase.

Manufacturer: Sweetcrispy

UPC: 720314560587

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FJRW8FVW

More documents and user manuals: **https://manuals.plus/**