Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

OUKITEL WP210

OUKITEL WP210 Rugged Smartphone User Manual

Model: WP210

1. Introduction

Thank you for choosing the OUKITEL WP210 Rugged Smartphone. This device is designed for durability and high performance, featuring a robust build, advanced camera system, long-lasting battery, and the latest Android operating system. This manual provides essential information on how to set up, operate, maintain, and troubleshoot your device to ensure optimal performance and longevity.

2. Package Contents

Please check the contents of your package. If any items are missing or damaged, contact your retailer.



Image: OUKITEL WP210 package contents including the smartphone, charger, cable, and accessories.

- OUKITEL WP210 Rugged Smartphone
- 45W Power Adapter
- USB-C Data Cable
- Protective Case (Pre-installed or included)
- User Manual
- Warranty Card
- SIM Ejector Tool

3. Device Layout

Familiarize yourself with the physical components of your OUKITEL WP210.



Image: Side view of the OUKITEL WP210, showing the power button, volume buttons, and SIM tray slot.



Image: Rear view of the OUKITEL WP210, highlighting the circular camera module with multiple lenses and the OUKITEL branding.

- **Front:** 6.7-inch FHD+ AMOLED Display, 32MP Front Camera, Earpiece.
- **Rear:** 108MP Main Camera, 2MP Macro Camera, 0.3MP Depth Camera, LED Flash.
- **Right Side:** Power Button (with integrated Fingerprint Sensor), Volume Up/Down Buttons.
- **Left Side:** SIM/SD Card Tray.
- **Bottom:** USB-C Port, Microphone, Speaker.

4. Setup

4.1. Installing SIM Cards and MicroSD Card

Your OUKITEL WP210 supports dual Nano-SIM cards and a MicroSD card for expandable storage.

1. Locate the SIM card tray on the left side of the device.
2. Insert the SIM ejector tool into the small hole on the tray and push gently until the tray pops out.
3. Place your Nano-SIM cards into the designated slots (SIM1, SIM2) with the gold contacts facing down.

4. If using a MicroSD card, place it into the dedicated MicroSD slot.
5. Carefully push the tray back into the phone until it is flush with the side.



Image: Close-up of the SIM card tray with two SIM cards and a MicroSD card being inserted.

4.2. Initial Power On and Setup

1. Press and hold the Power button on the right side of the phone until the OUKITEL logo appears.
2. Follow the on-screen instructions to select your language, connect to Wi-Fi, set up your Google account, and configure security features like fingerprint and face unlock.

4.3. Charging the Device

Before first use, it is recommended to fully charge your device.

1. Connect the USB-C cable to the charging port at the bottom of the phone.
2. Connect the other end of the USB-C cable to the 45W power adapter.
3. Plug the power adapter into a wall outlet.

4. The charging indicator will appear on the screen.



Image: Illustration of the OUKITEL WP210 being charged with the 45W fast charger, highlighting the 8800mAh battery capacity.

5. Operating Instructions

5.1. Basic Navigation

Your OUKITEL WP210 runs on Android 15, offering an intuitive user experience.

- **Home Screen:** Swipe left or right to access different home screens.
- **App Drawer:** Swipe up from the bottom of the screen to access all installed applications.
- **Notifications & Quick Settings:** Swipe down from the top of the screen to view notifications and access quick settings toggles.
- **Back, Home, Recent Apps:** Use the navigation gestures or buttons at the bottom of the screen.

5.2. Fingerprint and Face Unlock

For enhanced security and convenience, set up fingerprint and face recognition.



Image: A finger touching the side-mounted fingerprint sensor on the OUKITEL WP210 for unlocking.

- Go to **Settings > Security > Fingerprint Unlock** to register your fingerprints.
- Go to **Settings > Security > Face Unlock** to register your face.

5.3. Camera Usage

Your OUKITEL WP210 features a powerful triple camera system.



Image: Detailed view of the OUKITEL WP210's 108MP main camera, 32MP front camera, and 2MP macro camera, with example photos.

- Open the **Camera** app from your home screen or app drawer.
- Switch between modes like Photo, Video, Portrait, Macro, etc.
- Tap the shutter button to take a photo or start/stop video recording.
- Use the zoom controls on the screen to adjust magnification.

5.4. Connectivity

- **Wi-Fi:** Go to **Settings > Network & internet > Wi-Fi** to connect to available networks. Supports Wi-Fi 6 for faster speeds.
- **Bluetooth:** Go to **Settings > Connected devices > Bluetooth** to pair with Bluetooth accessories.
- **NFC:** For contactless payments and data transfer, enable NFC in **Settings > Connected devices > Connection preferences > NFC**.
- **5G:** Your device supports 5G cellular networks for high-speed data. Ensure your SIM card and plan support 5G.
- **GPS:** The phone supports GPS, GLONASS, BeiDou, and Galileo for accurate navigation.

5.5. Battery Management

The 8800mAh battery provides extended usage time.

- **Battery Saver:** Enable Battery Saver mode in **Settings > Battery** to extend battery life when needed.
- **OTG Reverse Charging:** Your device can act as a power bank to charge other devices. Connect the other device using an OTG cable to the USB-C port.

5.6. Rugged Features

The OUKITEL WP210 is built to withstand harsh environments.



Image: The OUKITEL WP210 being splashed with water, demonstrating its IP68 waterproof rating.



Image: The OUKITEL WP210 placed in a dusty, rocky environment, showcasing its IP69K dustproof capabilities.

- **IP68 & IP69K:** Certified for water and dust resistance. Can be submerged in water up to 1.5 meters for 30 minutes. Resistant to high-pressure water jets and dust ingress.
- **MIL-STD-810H:** Military-grade durability for drops, shocks, and extreme temperatures.

6. Maintenance

6.1. Cleaning Your Device

- Turn off your device before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or a screen cleaner.

- Avoid using harsh chemicals, abrasive cleaners, or compressed air.
- Ensure all ports are dry before charging or connecting accessories.

6.2. Care for Ruggedness

- While rugged, avoid intentionally dropping or subjecting the device to extreme impacts.
- Ensure the SIM tray is fully closed to maintain water and dust resistance.
- After exposure to water, especially saltwater, rinse the device with fresh water and dry thoroughly before charging.
- Do not expose the device to extreme temperatures outside its operating range for prolonged periods.

7. Troubleshooting

If you encounter issues with your OUKITEL WP210, try the following solutions:

- **Device Not Turning On:** Ensure the battery is charged. Connect to the charger for at least 15 minutes, then try powering on again.
- **Screen Frozen:** Press and hold the Power button for about 10-15 seconds to force a restart.
- **Poor Network Signal:** Check if your SIM card is properly inserted. Try moving to an area with better network coverage.
- **Battery Draining Quickly:** Close unused apps, reduce screen brightness, disable Wi-Fi/Bluetooth/GPS when not in use, or enable Battery Saver mode.
- **Apps Crashing:** Clear the cache and data of the problematic app (Settings > Apps > [App Name] > Storage > Clear Cache/Data). If the issue persists, uninstall and reinstall the app.
- **Device Overheating:** Avoid using the phone while charging, especially during heavy tasks like gaming. Close background apps. If overheating persists, contact support.
- **Water Damage Concerns:** If you suspect water has entered the device despite its rating, power it off immediately and do not attempt to charge it. Allow it to dry completely in a well-ventilated area for several days before attempting to power it on.

8. Specifications

Brand	OUKITEL
Model	WP210
Operating System	Android 15
Processor	MediaTek Dimensity 8200, Octa-Core (up to 3.1 GHz)
RAM	36 GB (12 GB Physical + 24 GB Virtual Expansion)
Storage	512 GB ROM
Display	6.7-inch FHD+ AMOLED, 1080 x 2400, 120Hz Refresh Rate, Corning Gorilla Glass 5
Rear Camera	108 MP Main, 2 MP Macro, 0.3 MP Depth
Front Camera	32 MP
Battery	8800 mAh, 45W Fast Charging
Connectivity	5G, Wi-Fi 6, Bluetooth, NFC, GPS (GPS, GLONASS, BeiDou, Galileo)

SIM Card	Dual Nano-SIM
Durability	IP68, IP69K, MIL-STD-810H
Biometrics	Side-mounted Fingerprint Sensor, Face Unlock
Dimensions	16.4 x 7.8 x 1.4 cm (approx.)
Weight	311 g (approx.)

9. Warranty and Support

OUKITEL provides comprehensive customer support for your WP210 smartphone.



Image: OUKITEL after-sales service details, including warranty and support options.

- **30-Day Money-Back Guarantee:** Enjoy a 30-day period for free returns and refunds.
- **2-Year Repair Warranty:** Your device is covered by a 2-year warranty for repairs against manufacturing defects.
- **24/7 Customer Service:** Online assistance is available around the clock for any queries or issues you may have.

For further assistance, please refer to the warranty card included in your package or visit the official OUKITEL website.

© 2026 OUKITEL. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FJXYPS3K

More documents and user manuals: **https://manuals.plus/**