MERACH MR-S19B1-US-A

MERACH Recumbent Exercise Bike User Manual

Brand: MERACH | **Model:** MR-S19B1-US-A

1. Introduction

This manual provides essential information for the safe and effective use of your MERACH Recumbent Exercise Bike. Designed for home use, this high-end recumbent bike offers a low-impact exercise solution, ideal for rehabilitation, seniors, and general fitness. It features magnetic resistance, smart Bluetooth connectivity, and an ergonomic design for comfort and stability.



Figure 1.1: MERACH Recumbent Exercise Bike. This image shows the full recumbent bike with its ergonomic seat, handlebars, and digital display, highlighting its compact design suitable for home environments.

The MERACH Recumbent Exercise Bike is engineered to provide a comfortable and effective workout experience, particularly beneficial for users seeking joint-safe exercise. Its robust construction supports users up to 330 lbs, ensuring stability and durability.

2. Product Features

- **Therapist-Approved Recovery Hub:** Features a waterfall-edge cushion and ventilated mesh backrest to reduce hip/knee pressure. Non-slip front handles provide stability. Lever-adjustable seating accommodates users from 5'2" to 5'10".

- **Fitness Ecosystem:** Integrates with the MERACH App for scenic routes, real-time Apple Watch/Google Fit syncing, and compatibility with Zwift, Kinomap, and FantomFite.
- **Durable Construction:** Built with aircraft aluminum, tested for over 5,000 hours, supporting up to 330 lbs. Features a patented low-impact drive system.
- **User-Friendly Controls:** Intuitive 8-gear car-style shifting for instant intensity changes. Large LCD monitor for progress tracking.
- **Pre-assembled Design:** 85% pre-assembled for quick setup. Includes front transport wheels for easy relocation.



Figure 2.1: Key Ergonomic Features. This image highlights the customizable seat with 8 levels for different leg lengths, the ergonomic and breathable backrest, and the heart rate handles for performance measurement and easier on/off.

---

3. Setup and Assembly

Your MERACH Recumbent Exercise Bike arrives 85% pre-assembled, significantly reducing setup time. The package includes all necessary tools for assembly.

3.1 Unpacking and Preparation

1. Carefully open the packaging and remove all components. The main body of the bike is heavy; it is recommended to unpack near the intended location or with assistance.
2. Verify all parts are present against the included parts list.
3. Place the main frame on a stable, level surface.



Figure 3.1: Pre-assembled Components. This image displays the main pre-assembled body of the bike along with the few remaining components that require attachment, such as the seat, handlebars, and display unit.

3.2 Assembly Steps

Follow the detailed instructions in the included assembly guide. Key steps include:

- Attach the front and rear stabilizers to the main frame.
- Install the pedals, ensuring the left and right pedals are correctly identified (L and R markings).
- Connect the seat rail to the main body.*Note: A small screw located under the seat in front may need to be removed temporarily to align the rail with the holes for the two long bolts. Secure the rail, then reinsert this screw.*
- Mount the seat and backrest onto the seat rail.
- Attach the handlebar post and the console/display unit. Connect any necessary cables.

For visual assistance, refer to the official assembly video guides available on the MERACH support website or product page.

3.3 Relocation

The bike is equipped with front transport wheels. To move the bike, lift the rear of the unit by the tail carry handle until it rests on the front wheels, then carefully roll it to the desired location.




Figure 3.2: Console and Mobility Features. This image shows the LCD monitor, the integrated tablet holder, and highlights the built-in

transport wheels for easy movement.

4. Operating Instructions

4.1 Powering On and Display Functions

The bike's console is battery-powered. It will activate automatically when you begin pedaling or press any button. The LCD monitor displays key workout data:

- **TIME:** Duration of your workout.
- **SPEED:** Current cycling speed.
- **DIST:** Distance covered during the current workout.
- **CAL:** Estimated calories burned.
- **ODO:** Total accumulated distance (odometer).
- **PULSE:** Heart rate detected via the heart rate handles.

Use the "MODE" button to cycle through display modes. "RESET" clears current workout data. "SET" is used for setting target values (e.g., time, distance).



Figure 4.1: HD Monitor and Tablet Holder. This image shows a close-up of the bike's LCD display, indicating various metrics like time, speed, distance, calories, odometer, and pulse. Below the display, a tablet holder is visible, designed to secure a mobile device during workouts.

4.2 Adjusting Resistance

The MERACH Recumbent Bike features an 8-level car-style gear lever for resistance adjustment. This allows for quick and intuitive changes to your workout intensity.

- To increase resistance, push the lever forward towards higher numbers.
- To decrease resistance, pull the lever backward towards lower numbers.
- Start with a lower resistance level and gradually increase as your fitness improves.



Figure 4.2: Car-Style Resistance Adjustment. This image illustrates the gear-lever mechanism for adjusting the bike's resistance, showing a hand operating the lever with numbered settings from 1 to 8.

4.3 Seat Adjustment

The ergonomic seat is adjustable to 8 positions to accommodate various leg lengths and user heights (5'2" to 5'10").

- Locate the yellow lever beneath the seat.
- Pull the lever to unlock the seat position.
- Slide the seat forward or backward to your desired position.
- Release the lever to lock the seat in place. Ensure it is securely locked before use.



Figure 4.3: Embrace Ultimate Comfort - Seat Adjustment. This image provides a detailed view of the seat adjustment mechanism, showing

the lever and the numbered positions for customizing seat depth.

4.4 App Connectivity (Bluetooth)

The MERACH Recumbent Bike can connect to the MERACH App and other compatible fitness applications via Bluetooth for an enhanced workout experience.

1. Download the MERACH App from your device's app store.
2. Ensure Bluetooth is enabled on your smartphone or tablet.
3. Open the MERACH App and follow the on-screen instructions to pair with your bike.
4. Once connected, you can access scenic routes, track real-time data, and sync with Apple Health or Google Fit. The bike is also compatible with Zwift, Kinomap, and FantomFite.




Figure 4.4: App Integration for Enhanced Workouts. This image shows a tablet displaying the MERACH app interface with virtual scenic routes and real-time workout data, demonstrating how the bike integrates with digital fitness platforms.

5. Care and Maintenance

Regular maintenance ensures the longevity and optimal performance of your MERACH Recumbent Exercise Bike.

- **Cleaning:** Wipe down the bike with a soft, damp cloth after each use to remove sweat and dust. Avoid abrasive cleaners or solvents.
- **Inspections:** Periodically check all bolts and nuts to ensure they are tight. Tighten any loose fasteners.
- **Pedals and Straps:** Ensure pedal straps are in good condition and adjust them as needed for secure foot placement.
- **Storage:** Store the bike in a dry, cool place away from direct sunlight and extreme temperatures.
- **Battery Replacement:** If the console display becomes dim or unresponsive, replace the batteries (type and location typically specified in the full assembly manual).

6. Troubleshooting

If you encounter issues with your MERACH Recumbent Exercise Bike, refer to the following common troubleshooting tips:

- **No Display on Console:**
  - Ensure batteries are correctly installed and not depleted. Replace if necessary.
  - Check all cable connections to the console.
- **Resistance Not Changing:**
  - Verify the resistance lever is moving freely and engaging the internal mechanism.
  - Ensure no obstructions are preventing the resistance system from operating.
- **Unusual Noises During Operation:**
  - Check that all bolts and nuts are securely tightened.
  - Ensure the bike is on a level surface.
  - The double belt drive system is designed for quiet operation; persistent noise may indicate an issue requiring professional inspection.
- **Bluetooth Connectivity Issues:**
  - Ensure Bluetooth is enabled on your device and the bike's console is active.
  - Try restarting both your device and the bike.
  - Ensure no other devices are currently paired with the bike.

If problems persist, please contact MERACH customer support for assistance.

7. Specifications

Feature	Specification
Model Name	MR-S19B1-US-A
Brand	MERACH
Maximum Weight Recommendation	330 Pounds
Number of Resistance Levels	8

Feature	Specification
Power Source	Battery Powered
Item Dimensions (LxWxH)	48.03 x 23.62 x 46.46 inches
Item Weight	96 Pounds
Material	Alloy Steel
Color	Black

8. Warranty and Support

MERACH is committed to providing high-quality products and excellent customer service.

8.1 Warranty Information

Your MERACH Recumbent Exercise Bike comes with a**1-year coverage** from the date of purchase. Additionally, a**30-day trial period** is offered for your peace of mind. This warranty covers manufacturing defects and ensures the product meets its specified performance standards under normal use.

8.2 Customer Support

For any questions, concerns, or technical assistance, please contact MERACH customer support. Our experts are available 24/7 to provide customized support.

Please refer to the contact information provided on the MERACH official website or the product packaging for the most current support channels (phone, email, or chat).

© 2025 MERACH. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question