Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Gisam CYJ-JH

Gisam CYJ-JH Electric Cordless Leaf Blower User Manual

1. Important Safety Instructions

Read all instructions carefully before operating the Gisam CYJ-JH Electric Cordless Leaf Blower. Failure to follow these instructions may result in electric shock, fire, and/or serious injury.

General Safety

- **Work Area Safety:** Keep the work area clean and well-lit. Cluttered or dark areas invite accidents.
- **Electrical Safety:** Do not expose power tools to rain or wet conditions. Water entering a power tool will increase the risk of electric shock.
- **Personal Safety:** Always wear eye protection, hearing protection, and appropriate clothing. Do not overreach. Maintain proper footing and balance at all times.
- **Tool Use and Care:** Do not force the power tool. Use the correct power tool for your application. Disconnect the battery pack from the power tool before making any adjustments, changing accessories, or storing power tools.
- **Battery Pack Use and Care:** Recharge only with the charger specified by the manufacturer. Do not use a battery pack or appliance that is damaged or modified.
- **Service:** Have your power tool serviced by a qualified repair person using only identical replacement parts.

Specific Blower Safety

- Never point the blower nozzle at people or pets.
- Keep all bystanders, children, and pets at least 15 meters (50 feet) away from the operating area.
- Do not operate the blower in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust.
- Always ensure the lock button is engaged when carrying the blower to prevent accidental starts.
- Use only Gisam recommended accessories and replacement parts.

2. Product Overview and Components

Familiarize yourself with the parts of your Gisam CYJ-JH Electric Cordless Leaf Blower before assembly and operation.



Figure 2.1: Labeled components of the Gisam CYJ-JH Leaf Blower, including the display screen, ON/OFF button, battery pack, rotary adjustment button, extension tube, trigger, gear adjustment button, and various nozzles.

Key Components:

- **Main Unit:** Houses the brushless motor, handle, and control panel.
- **Battery Pack (2x 6.0Ah):** Provides power to the blower.
- **Charger:** For recharging the battery packs.
- **Extension Tube:** Extends the reach of the blower.
- **Nozzles:**
  - **Round Nozzle:** For general blowing tasks.
  - **Bend Nozzle:** For reaching into gaps and corners.
  - **Flat Nozzle:** For sweeping leaves without damaging turf.
- **Control Panel:** Includes ON/OFF switch, display screen, and speed adjustment buttons.
- **Rotary Adjustment Button:** Allows 180° rotation of the handle for different operating modes.

3. Setup and Assembly

Follow these steps to assemble your leaf blower and prepare it for use.

3.1 Attaching the Extension Tube

1. Align the extension tube with the air outlet on the main blower unit.
2. Push the tube firmly onto the outlet until it clicks into place, ensuring a secure connection.

3.2 Attaching a Nozzle

1. Select the desired nozzle (Round, Bend, or Flat) for your task.
2. Align the nozzle with the end of the extension tube.
3. Push and twist the nozzle onto the extension tube until it is securely attached.



Figure 3.1: Illustration of the three different nozzles (Round, Bend, Flat) and their typical applications.

3.3 Installing and Charging the Battery

1. Ensure the battery pack is fully charged before first use.
2. To charge, connect the charger to a power outlet and insert the battery pack into the charger. The indicator light on the charger will show charging status.

3. Once fully charged (approximately 1 hour), remove the battery from the charger.
4. To install, slide the charged battery pack into the battery slot on the blower handle until it clicks securely into place.
5. To remove, press the battery release button and slide the battery pack out.



Figure 3.2: The two 6.0Ah lithium-ion batteries and the fast charger, highlighting protection features.

4. Operating Instructions

Learn how to effectively use your Gisam CYJ-JH Leaf Blower for various cleaning tasks.

4.1 Powering On/Off

1. Ensure the battery is securely installed.
2. Press the ON/OFF button on the control panel to start the blower. The display screen will illuminate.
3. To turn off, press the ON/OFF button again.

4.2 Adjusting Speed

The blower features 3 adjustable speed settings (150/200/250+ MPH) for different tasks.

1. With the blower on, press the gear adjustment button (often integrated with the trigger or a separate button) to cycle through the speed settings.
2. The display screen will indicate the current speed level.
3. Use lower speeds for delicate tasks like dusting cars, medium for light leaves, and high for heavy debris.



Figure 4.1: The control panel with the 3-speed adjustment feature, indicating different intensity levels.

4.3 Switching Operating Modes (180° Rotation)

The 180° rotatable handle allows for versatile use as a handheld or ground-level blower.

1. To change the handle position, press the rotary adjustment button.
2. Rotate the handle to the desired position (0° for ground-level use, 180° for handheld use).
3. Release the button to lock the handle in place.



Figure 4.2: Visual guide for switching between handheld and ground-level blowing modes using the 180° rotary adjustment.

4.4 General Operation Tips

- Start blowing debris from the outer edges of the area and work inwards.
- Use a sweeping motion to gather leaves and debris into piles.
- Avoid blowing debris towards people, animals, or open windows.
- For optimal battery life, avoid continuous use at maximum speed unless necessary.

5. Maintenance

Regular maintenance ensures the longevity and optimal performance of your leaf blower.

5.1 Cleaning the Blower

1. Always remove the battery pack before cleaning.
2. Wipe the exterior of the blower with a clean, damp cloth. Do not use strong detergents or solvents.
3. Clear any debris from the air intake vents and the nozzle opening to ensure proper airflow.
4. Ensure all parts are dry before re-installing the battery or storing the tool.

5.2 Battery Care and Storage

- Store battery packs in a cool, dry place away from direct sunlight and extreme temperatures.
- Do not store battery packs in a discharged state for extended periods. Recharge them periodically if not in use.
- Avoid exposing batteries to water or moisture.
- If the blower will not be used for a long time, remove the battery pack.

6. Troubleshooting

Refer to this section for solutions to common issues you might encounter.

Problem	Possible Cause	Solution
Blower does not start	Battery not installed correctly Battery discharged ON/OFF button not pressed firmly	Ensure battery is clicked into place Charge the battery pack Press the ON/OFF button firmly
Low airflow/power	Battery low Nozzle or tube obstructed Incorrect speed setting	Recharge battery Clear any debris from nozzle/tube Increase speed setting
Blower stops unexpectedly	Battery overheated or discharged Tool overloaded Operating in extreme cold	Allow battery to cool down or recharge Reduce load on the tool Avoid operating in very cold temperatures; if it shuts off, bring indoors to warm up before restarting.
Handle does not rotate	Rotary adjustment button not pressed Mechanism obstructed	Ensure button is fully depressed Check for debris around the rotation mechanism

7. Specifications

Technical details for the Gisam CYJ-JH Electric Cordless Leaf Blower.

- **Model:** CYJ-JH
- **Brand:** Gisam
- **Motor Type:** Brushless
- **Motor Power:** 3000W
- **Motor Speed:** 900,000 RPM (No Load)
- **Airflow Volume:** 850 CFM (1444 m^3/h)
- **Air Speed:** 150/200/250+ MPH (3-Speed Adjustment)
- **Battery Type:** Lithium-Ion
- **Battery Capacity:** 2 x 6.0Ah (21V)
- **Charging Time:** Approximately 1 hour per battery

- **Runtime:** Up to 3 hours (depending on speed setting)
- **Weight:** 3.5 lbs (approx. 1.59 kg) - main unit without battery
- **Product Dimensions:** 10 x 10 x 10 cm (L x W x H)
- **Material:** Plastic
- **Special Features:** 180° Rotatable Handle, 2-in-1 Handheld/Ground Mode, 3 Nozzles

8. Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or contact Gisam customer service directly.

- **Customer Service:** Please visit the official Gisam website or refer to your product packaging for contact details.
- **Online Resources:** Check the Gisam website for FAQs, additional guides, and product registration.

© 2025 Gisam. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FK5H2R4Y

More documents and user manuals: **https://manuals.plus/**