Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

wanbbaoaa D405

wanbbaoaa MP3 Player with Bluetooth 5.2 (Model D405) User Manual

Model: D405 | Brand: wanbbaoaa

Introduction What's in the Box Setup Operating Instructions Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

Thank you for purchasing the wanbbaoaa MP3 Player with Bluetooth 5.2, Model D405. This portable music player is designed to provide high-quality audio playback, along with additional features such as FM radio, voice recording, video and photo viewing, and e-book reading. This manual will guide you through the features and functions of your new device.



Image 1.1: The wanbbaoaa MP3 Player D405 in black, showcasing its compact design.

2. What's in the Box

Please check the package contents to ensure all items are present:

- 1 x wanbbaoaa MP3 Player (Model D405)
- 1 x 32GB Micro SD Card
- 1 x USB Cable
- 1 x Stereo Earphone
- 1 x User Manual (this document)

3. Setup

3.1. Charging the Device

Before first use, fully charge the MP3 player. Connect the included USB cable to the player's charging port and the other end to a USB power adapter (not included) or a computer's USB port. The battery indicator on the screen will show charging status.

3.2. Inserting the Micro SD Card

The device comes with a pre-installed 32GB Micro SD card. If you need to replace or upgrade it (up to 128GB), gently insert the Micro SD card into the designated slot until it clicks into place. Ensure the card is inserted correctly to avoid damage.

3.3. Transferring Music and Other Files

To transfer files from your computer to the MP3 player:

1. Connect the MP3 player to your computer using the provided USB cable.
2. The player will appear as a removable disk drive on your computer.
3. Drag and drop your music, video, photo, or e-book files into the appropriate folders on the player's storage or the Micro SD card.
4. Once files are transferred, safely eject the removable disk from your computer before disconnecting the USB cable.



Image 3.1: Illustrates connecting the MP3 player to a laptop for transferring music, photos, and video files.

4. Operating Instructions

4.1. Basic Navigation

The MP3 player features a simple button interface for navigation:

- **MENU Button:** Press to access the main menu or go back to the previous screen.
- **Play/Pause Button:** Press to play or pause media.
- **Next/Fast Forward Button:** Press to skip to the next track or fast forward during playback.
- **Previous/Rewind Button:** Press to go to the previous track or rewind during playback.
- **VOL (Volume) Buttons:** Use to adjust the volume level.



Image 4.1: The MP3 player displaying its multi-functional capabilities, including e-book reading, video playback, and voice recording.

4.2. Music Playback (HiFi Lossless Sound)

Navigate to the "Music" option from the main menu. Select a song or album to begin playback. The player supports various audio formats including MP3, WMA, FLAC, APE, OGG, WAV, MP4, and AAC-LC, providing high-fidelity lossless sound.



Image 4.2: The MP3 player screen showing various supported audio formats like MP3, FLAC, WAV, WMA, OGG, APE, AAC-LC, and MP4 for high-fidelity sound.

4.3. Bluetooth 5.2 Pairing

To connect to Bluetooth headphones or speakers:

1. From the main menu, select "Bluetooth".
2. Ensure your Bluetooth device is in pairing mode.
3. The MP3 player will scan for available devices. Select your device from the list to pair.
4. Once paired, audio will stream wirelessly to your connected device.



Image 4.3: Diagram illustrating the MP3 player's Bluetooth 5.2 connectivity with both a Bluetooth speaker and Bluetooth earphones.

4.4. FM Radio

To use the FM radio function:

1. Connect the wired earphones (included) to the player. The earphones act as an antenna for the FM radio.
2. From the main menu, select "FM Radio".
3. Use the navigation buttons to scan for stations or manually tune to a frequency (87.5-108MHz).



Image 4.4: The MP3 player screen showing various FM radio frequencies, indicating its FM radio support.

4.5. Voice Recorder

To record audio:

1. From the main menu, select "Recorder" or "Voice Recorder".
2. Press the Play/Pause button to start recording.
3. Press it again to pause, and the MENU button to stop and save the recording.

4.6. Video and Photo Viewer

The player supports viewing photos and playing videos (AVI format). Navigate to the "Video" or "Photo" option from the main menu to browse your media files.



Image 4.5: The MP3 player screen showing a collage of images and video frames, indicating its photo and video playback capabilities.

4.7. E-Book Reader

To read e-books, transfer compatible text files to the player. Select "E-Book" from the main menu and choose your desired file. The 1.8-inch eye-care screen is designed for comfortable reading.

4.8. Alarm Clock

Access the "Alarm" function from the main menu to set alarms. You can configure the time and alarm sound.

5. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the device. Avoid liquid cleaners or abrasive materials.

- **Storage:** Store the MP3 player in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in use for extended periods. The player offers approximately 15 hours of battery life on a full charge.
- **Water Exposure:** This device is not waterproof. Avoid exposure to water or high humidity.

6. Troubleshooting

6.1. Device Does Not Turn On

- Ensure the device is fully charged. Connect it to a power source and wait a few minutes before attempting to turn it on.
- If the device is unresponsive, try performing a reset (refer to the device's specific reset procedure, if available, or hold the power button for an extended period).

6.2. Computer Does Not Recognize the Device

- Ensure the USB cable is securely connected to both the MP3 player and the computer.
- Try a different USB port on your computer.
- Try a different USB cable.
- Restart your computer and reconnect the device.
- Ensure the MP3 player is powered on when connected to the computer.

6.3. Music Files Do Not Play

- Verify that the music files are in a supported format (MP3, WMA, FLAC, APE, OGG, WAV, MP4, AAC-LC).
- Ensure the files have been transferred correctly to the device's storage or Micro SD card.
- Check the volume level.
- If using Bluetooth, ensure the Bluetooth device is properly paired and connected.

6.4. Bluetooth Connection Issues

- Ensure both the MP3 player and the Bluetooth receiving device are charged and within range.
- Make sure the Bluetooth device is in pairing mode.
- Try unpairing and re-pairing the devices.
- Restart both the MP3 player and the Bluetooth device.

7. Specifications

Brand	wanbbaoaa
Model Name	D405

Special Features	Bluetooth, FM Radio, Voice Recorder
Connectivity Technology	Bluetooth
Memory Storage Capacity	32 GB (expandable to 128GB with Micro SD)
Color	Black
Screen Size	1.8 Inches
Compatible Devices	Headphones, Bluetooth Speakers
Media Type	Micro SD
Supported Standards	MP3, WMA, OGG, APE, FLAC, WAV, AAC-LC, MP4 (Video)
Battery Average Life	15 Hours
Item Weight	3.6 Ounces

8. Warranty & Support

8.1. Product Warranty

This wanbbaoaa MP3 Player (Model D405) is covered by a **12-month warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.
Additionally, a **30-day return policy** is available for eligible purchases.

8.2. Customer Support

For any questions, technical assistance, or warranty claims, please contact wanbbaoaa customer support through the retailer's platform or the official brand website. Please have your purchase details and product model number (D405) ready when contacting support.

© 2026 wanbbaoaa. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FKGW42TK

More documents and user manuals: **https://manuals.plus/**