MERACH W50

MERACH W50 Walking Pad Treadmill User Manual

Model: W50 | Brand: MERACH

1. Important Safety Information

Please read this entire manual carefully before assembling or operating your MERACH W50 Walking Pad Treadmill. Keep this manual for future reference.

- Ensure the treadmill is placed on a flat, stable surface.
- Keep children and pets away from the treadmill during operation.
- The maximum user weight capacity for this treadmill is **400 lbs**. Do not exceed this limit.
- Always wear appropriate athletic footwear when using the treadmill.
- Do not operate the treadmill if it is damaged or malfunctioning.
- Unplug the treadmill from the power outlet when not in use or before cleaning/maintenance.
- Maintain a clear space of at least 2 feet behind and 1 foot on each side of the treadmill.

2. Product Overview

The MERACH W50 Walking Pad Treadmill is designed for home use, offering a robust and quiet exercise experience with advanced features.

Key Features:

- **Heavy-Duty Support:** Industrial-grade steel frame and a 16.5" x 41.3" professional running belt, supporting up to 400 lbs.
- **Powerful & Quiet Motor:** Equipped with a 3.5 HP brushless motor, operating at an ultra-low noise level of 25 dB, capable of 10-hour nonstop operation.
- **12% Auto-Incline:** Features remote-controlled automatic incline adjustments from 0% to 12% for varied workout intensity.
- **Multi-Zone Cushioning:** A 6-layer shock-absorbing non-slip belt and professional cushioning frame reduce joint pressure by up to 30%.

- **Compact & Portable:** Anti-fold design with industrial-grade transport wheels for easy mobility and storage.

Components:

Familiarize yourself with the main components of your walking pad treadmill.



Figure 2.1: The MERACH W50 Walking Pad Treadmill, showcasing its compact design and the 12% auto-incline feature. The LED display is visible at the front.



Figure 2.2: Illustration of the treadmill's robust construction, highlighting its 400 lbs weight capacity and reinforced frame for rock-solid stability during use.



Figure 2.3: Detailed view of the 3.5 HP brushless motor, emphasizing its quiet operation (25 dB) and extended runtime capabilities, ensuring consistent performance.



Figure 2.4: Visual representation of the 12% auto-incline feature, demonstrating how it can enhance calorie burning efficiency and simulate uphill walking.



Figure 2.5: Close-up of the 16.5-inch wide running belt, illustrating the spacious and comfortable surface for natural walking or running without leg strain.



Figure 2.6: Key operational components including the eye-friendly LED display, magnetic remote control, cooling vent design, and comfortable leather handles.



Figure 2.7: Diagram illustrating the 6-layer shock-absorbing belt system, designed to provide soft, silent, and slip-free operation while protecting joints.

3. Setup Instructions

1. **Unboxing:** Carefully remove the treadmill from its packaging. Retain all packaging materials for potential future transport or returns.
2. **Placement:** Choose a flat, stable surface for the treadmill. Ensure there is adequate clear space around the unit as specified in the safety information.
3. **Unfolding (if applicable):** The MERACH W50 features an anti-fold design, meaning it is largely pre-assembled. Simply position it as desired.
4. **Power Connection:** Locate the power cord and plug it into a grounded electrical outlet. Ensure the power switch on the treadmill (if present) is in the OFF position before plugging in.
5. **Initial Inspection:** Before first use, inspect the running belt for any damage or misalignment. Ensure all components are securely in place.

4. Operating Instructions

4.1 Powering On/Off

- To power on, ensure the treadmill is plugged in and flip the main power switch (usually located near the power cord inlet) to the ON position. The LED display will illuminate.
- To power off, flip the main power switch to the OFF position and unplug the unit from the wall outlet.

4.2 Using the Remote Control

The MERACH W50 is controlled via a handheld magnetic remote. Ensure the remote has working batteries.

- **Start/Stop:** Press the **START/STOP** button to begin or end your workout.
- **Speed Adjustment:** Use the **+** and **-** buttons to increase or decrease the walking speed. The speed range is from 0.5 MPH up to 4.0 MPH.
- **Incline Adjustment:** Use the **INCLINE +** and **INCLINE -** buttons to adjust the incline level. The incline can be set from 0% to 12%.
- **Mode/Display:** Some remotes may have a button to cycle through display modes (Time, Distance, Calories, Speed).

4.3 Understanding the LED Display

The integrated LED display provides real-time workout data:

- **SPEED:** Current walking speed in miles per hour (MPH).
- **TIME:** Duration of your workout session.
- **DIST:** Distance covered during your workout.
- **CAL:** Estimated calories burned.

5. Maintenance

Regular maintenance ensures the longevity and optimal performance of your MERACH W50 Walking Pad Treadmill.

- **Cleaning:**
  - Wipe down the treadmill frame and display with a soft, damp cloth after each use to remove sweat and dust.
  - Do not use abrasive cleaners or solvents, as they may damage the finish.
  - Periodically vacuum underneath the treadmill to prevent dust buildup from affecting motor performance.
- **Belt Lubrication:**
  The running belt requires periodic lubrication to reduce friction and extend its lifespan. The frequency depends on usage:
  - Light use (less than 3 hours/week): Lubricate every 5-6 months.
  - Moderate use (3-5 hours/week): Lubricate every 3-4 months.
  - Heavy use (more than 5 hours/week): Lubricate every 1-2 months.

  To lubricate, lift the edge of the running belt and apply a small amount of 100% silicone lubricant (not included) to the center of the deck. Run the treadmill at a slow speed (e.g., 1 MPH) for 5 minutes to distribute the lubricant evenly.
- **Belt Tension and Alignment:**
  If the belt feels loose or slips during use, or if it drifts to one side, it may need adjustment. Refer to the specific instructions provided with your treadmill for adjusting belt tension and alignment screws, typically located at the rear of the unit.

6. Troubleshooting

If you encounter issues with your MERACH W50 Walking Pad Treadmill, try the following solutions before contacting

customer support.

Problem	Possible Cause	Solution
Treadmill does not power on.	Not plugged in; power switch off; circuit breaker tripped.	Ensure power cord is securely plugged into a grounded outlet. Check if the main power switch is ON. Reset the household circuit breaker if necessary.
Running belt slips or hesitates.	Belt too loose; insufficient lubrication.	Adjust belt tension (refer to maintenance section). Apply silicone lubricant to the running deck.
Unusual noise during operation.	Loose components; belt rubbing; motor issue.	Check and tighten any visible loose screws. Ensure the belt is centered and not rubbing against the frame. If noise persists, contact customer support.
Remote control not responding.	Dead batteries; remote out of range.	Replace batteries in the remote control. Ensure you are within effective range of the treadmill's receiver.

7. Specifications

Attribute	Value
Brand	MERACH
Model	W50
Color	Black
Product Dimensions (L x W x H)	50.2"D x 22.2"W x 6.1"H
Item Weight	69.2 Pounds
Material	Alloy Steel
Maximum Speed	4 Miles per Hour
Special Feature	Auto Incline
Maximum Horsepower	3.5 Horsepower
Maximum Incline Percentage	12%
Weight Capacity	400 lbs
Running Belt Dimensions	16.5" x 41.3"

8. Warranty and Support

For warranty information or technical support, please contact MERACH customer service. Keep your purchase receipt as proof of purchase.

You can typically find contact information on the MERACH official website or through the retailer where you purchased the product.

For general inquiries, you may visit the MERACH Store on Amazon.

© 2024 MERACH. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question