Furmax B0FM3CT6YN

Furmax 7-Drawer Wood Dresser Instruction Manual

Model: B0FM3CT6YN
Brand: Furmax

1. Introduction

Thank you for choosing the Furmax 7-Drawer Wood Dresser. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.

This versatile dresser is designed to provide ample storage and can also serve as a TV stand for televisions up to 65 inches. Its robust construction and smooth-gliding drawers ensure durability and ease of use.

2. Safety Information

- **Anti-Tipping Device:** It is crucial to install the included anti-tipping device to prevent serious injury from furniture tip-over. Always secure the dresser to a wall using the provided hardware.
- **Weight Limits:** Do not exceed the maximum weight capacity for the dresser top (250 lbs) and individual drawers (22 lbs). Overloading can compromise stability and cause damage.
- **Assembly:** Assemble the dresser on a soft, clean surface to prevent scratches. Ensure all screws and fasteners are tightened securely before use. Periodically check and re-tighten all connections.
- **Children:** Keep children away from the assembly area. Do not allow children to climb on or play with the dresser, especially when drawers are open.
- **Placement:** Place the dresser on a level surface to ensure stability. Avoid placing it near heat sources or in direct sunlight to prevent material degradation.

Figure 2.1: Anti-Tipping Device Installation. This diagram illustrates the correct installation of the anti-tipping device to secure the dresser to the wall, preventing accidental tip-overs. It also shows the danger of not installing the device.

3. Package Contents

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Dresser Panels (Top, Sides, Back, Base)
- Drawer Fronts, Sides, and Bottoms (for 7 drawers)
- Drawer Slides (for 7 drawers)
- Handles/Knobs (14 pieces)
- Assembly Hardware (screws, dowels, cam locks, etc.)
- Anti-Tipping Device Kit
- Instruction Manual

4. Assembly Instructions

Follow these steps carefully to assemble your Furmax 7-Drawer Wood Dresser. It is recommended to have two people for assembly.

1. **Prepare the Area:** Clear a spacious, clean, and soft area for assembly to prevent damage to the dresser components.
2. **Identify Parts:** Lay out all parts and hardware. Compare them with the package contents list and diagrams in the separate assembly guide (if provided).
3. **Assemble the Main Frame:** Connect the side panels to the top and bottom panels using the provided hardware. Ensure all connections are snug.
4. **Install Drawer Slides:** Attach the drawer slides to the interior of the dresser frame according to the markings. Ensure they are level and aligned.
5. **Assemble Drawers:** Construct each of the 7 drawers by attaching the front, side, and back panels to the drawer bottom. Install the corresponding drawer slides onto each drawer.
6. **Insert Drawers:** Carefully slide the assembled drawers into the dresser frame. Test each drawer for smooth operation.
7. **Attach Handles:** Secure the metal handles/knobs to the front of each drawer.
8. **Install Anti-Tipping Device:** Position the dresser in its desired location. Secure the anti-tipping device to the back of the dresser and then to a wall stud using the provided hardware. Refer to Figure 2.1 for guidance.

5. Operating Instructions

Your Furmax dresser is designed for practical and efficient storage.

- **Drawer Usage:** The dresser features large and small drawers. The large drawers are suitable for items like blankets and pillows, while the smaller drawers can hold remote controls, stationery, and other small items. The smooth-gliding slides ensure effortless opening and closing.
- **TV Stand Functionality:** The sturdy top surface can accommodate a TV up to 65 inches. Ensure the TV's base fits within the dresser's dimensions and does not exceed the top weight capacity of 250 lbs.
- **Organization:** Utilize the varied drawer sizes to organize your belongings efficiently, keeping your living space tidy.

Figure 5.1: Smooth Sliding Drawers and Metal Handles. This image demonstrates the smooth operation of the drawers and the design of the metal handles, along with the waterproof and easy-to-clean surface.

Figure 5.2: Drawer Capacity and Organization. This image illustrates the diverse range of items that can be stored within the dresser's spacious drawers, from clothing to books and personal accessories.

6. Maintenance and Care

Proper care will extend the life and appearance of your dresser.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, as they can damage the finish. The surface is designed to be waterproof and easy to clean.
- **Spills:** Promptly wipe up any spills to prevent staining or water damage.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten as necessary to maintain structural integrity.
- **Drawer Slides:** If drawers become stiff, a small amount of silicone lubricant can be applied to the slides.
- **Avoid Overloading:** Do not overload drawers or the top surface beyond their specified weight limits.

7. Troubleshooting

If you encounter issues with your dresser, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Drawers stick or do not slide smoothly.	Misaligned drawer slides, loose hardware, or obstruction.	Check that drawer slides are correctly installed and aligned. Ensure all screws on the slides and drawer boxes are tight. Remove any obstructions. Apply silicone lubricant if needed.
Dresser feels wobbly or unstable.	Loose assembly hardware or anti-tipping device not installed.	Ensure all assembly screws are fully tightened. Verify that the dresser is on a level surface. Install the anti-tipping device securely to a wall stud.
Parts are missing or damaged upon arrival.	Shipping damage or packaging error.	Do not proceed with assembly. Contact Furmax customer support immediately for replacement parts.

8. Specifications

- **Model:** B0FM3CT6YN
- **Brand:** Furmax
- **Dimensions (D x W x H):** 15.7" x 52" x 30.8"
- **Item Weight:** 92.59 Pounds
- **Material Type:** Wood
- **Finish Type:** Painted
- **Number of Drawers:** 7
- **Dresser Top Weight Capacity:** 250 lbs
- **Individual Drawer Weight Capacity:** 22 lbs
- **Mounting Type:** Floor Mount (with wall anchor for anti-tipping)

- **Required Assembly:** Yes
- **Color:** Brown

Figure 8.1: Product Dimensions and Weight Capacities. This image provides a visual representation of the dresser's overall dimensions and the weight limits for both the top surface and individual drawers.

Figure 8.2: Detailed Features of the Chest of Drawers. This image showcases specific design elements such as the

thickened table board, circular handles, silent smooth slide rails, and the sturdy tipping base.

9. Warranty and Support

Furmax is committed to providing high-quality products and customer satisfaction. Your dresser comes with a standard manufacturer's warranty covering defects in materials and workmanship under normal use.

If you encounter any issues during assembly or use, or if you have questions regarding your product, please do not hesitate to contact our customer support team. We are dedicated to assisting you patiently and effectively.

Contact Information:
Please refer to the contact details provided on your purchase receipt or the Furmax official website for the most current support options.

© 2026 Furmax. All rights reserved.