Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VEVOR PSL-18

VEVOR 18-Inch Electric Pizza Oven (Model PSL-18) User Manual

Model: **PSL-18**

Important Safety Instructions

To ensure safe operation and prevent injury or damage, please read all instructions thoroughly before using this appliance. Keep this manual for future reference.

- **Read All Instructions:** Familiarize yourself with the appliance's features and operation before use.
- **Hot Surfaces:** The oven surfaces become extremely hot during operation. Always use oven mitts or heat-resistant gloves when handling hot parts or opening the oven door. Do not touch hot surfaces directly.
- **Electrical Safety:** To protect against electrical shock, do not immerse the power cords, plugs, or the appliance itself in water or any other liquid.
- **Children and Supervision:** Close supervision is necessary when the appliance is used by or near children or individuals with reduced physical, sensory, or mental capabilities.
- **Unplug When Not in Use:** Always unplug the oven from the outlet when not in use and before cleaning. Allow it to cool completely before attaching or removing parts.
- **Damaged Appliance:** Do not operate any appliance with a damaged cord or plug, or if the appliance malfunctions or has been damaged in any manner. Contact customer support for assistance.
- **Accessories:** The use of accessory attachments not recommended by the appliance manufacturer may cause injuries or damage.
- **Indoor Use Only:** This appliance is designed for indoor use only. Do not use outdoors.
- **Cord Placement:** Do not let the power cord hang over the edge of a table or counter, or touch hot surfaces.
- **Heat Sources:** Do not place the oven on or near a hot gas or electric burner, or in a heated oven.
- **Moving Hot Appliance:** Exercise extreme caution when moving an appliance containing hot oil or other hot liquids.
- **Proper Connection:** Always attach the plug to the appliance first, then plug the cord into the wall outlet. To disconnect, turn any control to "off", then remove the plug from the wall outlet.
- **Intended Use:** Do not use the appliance for purposes other than its intended use as a pizza oven.
- **Stable Surface:** Ensure the oven is placed on a stable, heat-resistant, non-flammable surface.
- **Ventilation:** Adequate ventilation is required around the oven during operation. Maintain at least 4 inches of clearance from walls and other objects.
- **Power Cords:** This appliance is equipped with two power cords. Ensure they are plugged into separate, appropriately rated electrical circuits to avoid overloading.

Product Overview

The VEVOR 18-Inch Electric Pizza Oven, Model PSL-18, is a 1740W countertop appliance designed for baking pizzas and other foods. It features precise temperature and time controls, dual heating tubes, and a built-in thermometer for consistent results, making it suitable for both home and commercial use.

Key Features

- **18-Inch Large Capacity:** Accommodates one 18-inch pizza or two 9-inch pizzas simultaneously, ideal for various serving needs.
- **Dual Heating Tubes:** Equipped with 1740W power and top and bottom heating elements for 360° uniform baking and rapid heat distribution.
- **Temperature Control:** Adjustable baking temperature from 77–752°F (25–400°C) for precise cooking.
- **Timer Function:** Integrated timer can be set for up to 60 minutes, providing convenience and preventing overcooking.
- **Real-Time Monitoring:** A built-in thermometer displays the current internal temperature, offering full visibility during the baking process.
- **Durable Construction:** Constructed from high-quality stainless steel, ensuring long-lasting use and a sleek, easy-to-clean cooking space.
- **Versatile Use:** Beyond pizzas, this oven can be used for baking pretzels, potatoes, bread, cakes, pies, pastries, and chicken wings.

What's in the Box

- 1 x VEVOR Electric Pizza Oven
- 1 x Pizza Stone
- 1 x User Manual



A front view of the VEVOR 18-Inch Electric Pizza Oven, showing its stainless steel exterior and control panel on the right side.

Setup

Unpacking

Carefully remove the pizza oven and all included accessories from the packaging. Inspect the appliance for any signs of damage. Retain the original packaging for future transport or storage.

Placement

- Place the oven on a stable, level, heat-resistant, and non-flammable surface.
- Ensure adequate clearance (at least 4 inches) around all sides of the oven for proper ventilation. Do not block any ventilation openings.
- Do not place the oven near flammable materials, curtains, or other heat sources.

Initial Cleaning

Before the first use, wipe down the interior and exterior surfaces of the oven with a damp cloth. Ensure all parts are completely dry

before plugging in the appliance. The included pizza stone can be wiped clean; do not wash it with soap or immerse it in water, as it can absorb moisture.

Power Connection

This appliance is designed with two separate power cords to distribute the electrical load. Plug each power cord into a dedicated, grounded electrical outlet. Ensure the outlets meet the voltage and current requirements specified in the 'Specifications' section to prevent circuit overload.



The VEVOR Electric Pizza Oven is shown on a kitchen countertop, demonstrating typical placement for use.

Operating Instructions

Controls Overview



A detailed view of the oven's control panel, featuring a temperature gauge, temperature control knob, timer knob, power switch, and light switch.

- **Power Switch:** Located on the right side of the control panel. Flip to 'ON' to power the oven. An indicator light will illuminate when the oven is active.
- **Timer Knob:** The upper knob. Rotate to set the desired cooking time, up to 60 minutes. The oven will automatically turn off when the timer expires.
- **Temperature Control Knob:** The lower knob. Rotate to adjust the temperature from 77°F (25°C) to 752°F (400°C).
- **Temperature Gauge:** Displays the real-time internal temperature of the oven, allowing you to monitor heating progress.
- **Light Switch:** Activates the internal oven light for better visibility of the cooking process.

Preheating the Oven

1. Ensure the oven is plugged into appropriate power outlets.
2. Flip the Power Switch to 'ON'. The indicator light will turn on.

3. Set the Temperature Control Knob to the desired baking temperature for your food.
4. Allow the oven to preheat for approximately 20-30 minutes, or until the temperature gauge reaches the set temperature. Preheating is crucial for optimal cooking results.

Baking Pizza

1. Once the oven is preheated, carefully pull out the front door and sliding rack using the handle.
2. Place the pizza (on the pizza stone or directly on the rack, depending on your preference and pizza type) onto the sliding rack.
3. Gently slide the rack and door back into the oven until fully closed.
4. Set the Timer Knob to the recommended cooking time for your pizza.
5. Monitor the pizza through the viewing window. The internal light can be turned on using the Light Switch for better visibility.
6. When cooking is complete, the timer will alert you, and the oven will power off.
7. Carefully pull out the sliding rack and remove the cooked pizza using appropriate utensils (e.g., a pizza peel).
8. Close the oven door.



A person is shown carefully placing an uncooked pizza onto the sliding rack of the VEVOR Electric Pizza Oven, demonstrating the loading process.

General Cooking Tips

- For best results, always preheat the oven to the desired temperature before placing food inside.
- The dual heating tubes ensure even cooking from both top and bottom. Adjust temperature as needed for desired crust crispness.
- The removable crumb tray underneath the main rack helps catch drips and crumbs, making cleanup easier.

Maintenance

Cleaning

1. Always unplug the oven from the power outlets and allow it to cool completely before cleaning.
2. Wipe the exterior of the oven with a damp cloth and a mild detergent. Do not use abrasive cleaners, steel wool, or scouring pads, as these can scratch the stainless steel surface.
3. The interior can be wiped with a damp cloth. For stubborn stains, a non-abrasive oven cleaner designed for stainless steel may be used, following the product's instructions carefully.
4. The removable crumb tray can be pulled out and washed with warm, soapy water. Ensure it is completely dry before reinserting it into the oven.
5. The pizza stone should be scraped clean of any food residue. Do not use soap or immerse the stone in water, as it can absorb moisture and potentially crack when heated.



A person demonstrates how to remove the stainless steel crumb tray from the bottom of the oven for cleaning.

Storage

Store the oven in a cool, dry place when not in use. Ensure it is clean and completely dry before storage to prevent rust or damage.

TROUBLESHOOTING

Common Issues and Solutions

Problem	Possible Cause	Solution
Oven does not turn on	Not plugged in / Power switch off	Ensure both power cords are securely plugged into separate, grounded outlets and the power switch is in the 'ON' position.
Oven not heating to desired temperature	Insufficient preheating time / Incorrect temperature setting	Allow adequate preheating time (20-30 minutes). Verify the temperature control knob is set correctly.
Uneven cooking	Food placement / Oven not fully preheated	Ensure food is centered on the rack. Always allow the oven to fully preheat before cooking.
Circuit breaker trips	Overloaded circuit	Ensure the two power cords are plugged into separate electrical circuits to prevent overloading.

If problems persist after attempting these solutions, please contact VEVOR customer support for further assistance.

Specifications

Feature	Detail
Brand	VEVOR
Model Number	PSL-18
Power	1740W
Control Method	Knob Control (Timer, Temperature)
Temperature Range	77–752°F (25–400°C)
Net Weight	55.12 lbs (25 kg)
Product Dimensions (L x W x H)	27.17"D x 23.31"W x 11.89"H (690 x 592 x 302 mm)
Material	Stainless Steel
Capacity	18-inch pizza (or 2x9", 3x6" pizzas)
Included Components	Pizza Oven, Pizza Stone, User Manual



A technical diagram illustrating the length, width, and height of the VEVOR Electric Pizza Oven in both inches and millimeters.

Warranty and Support

Warranty Information

This VEVOR product comes with a standard manufacturer's warranty. Please refer to the warranty card included in your packaging or visit the official VEVOR website for detailed terms and conditions regarding coverage and duration.

Customer Support

For technical assistance, troubleshooting, parts replacement, or any other inquiries, please contact VEVOR customer support. Contact details can typically be found in the included user manual or on the VEVOR official website.
Online resources and frequently asked questions (FAQs) may also be available at www.vevor.com.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FM812S5C

More documents and user manuals: **https://manuals.plus/**