Manuals+
Q & A | Deep Search | Upload

JVD Alarm

JVD Carabay Digital Alarm Clock with Wireless Bluetooth Speaker User Manual

Model: Alarm

Introduction

The JVD Carabay Digital Alarm Clock with Wireless Bluetooth Speaker is a versatile 2-in-1 device designed to provide timekeeping, audio entertainment, and convenient charging. This manual provides detailed instructions for setting up and operating your device, ensuring optimal performance and user experience.

Package Contents

Please check the package for the following items:

- JVD Carabay Digital Alarm Clock with Wireless Bluetooth Speaker
- Power Adapter
- User Manual (this document)
- *Note: Specific cables for AUX or USB-C charging are not included unless specified on the product packaging.*

Product Overview

Familiarize yourself with the components of your JVD Carabay device.

Figure 1: Front and top view of the JVD Carabay clock with key features labeled, including the wireless charging pad, large LED display, Bluetooth speaker, and control buttons.

Figure 2: Rear view of the JVD Carabay, highlighting the power input, AUX port, and USB-C charging port for external devices.

Key Features:

- **Digital Display:** Clear LED display with 4 levels of adjustable light dimming.
- **Wireless Charging Pad:** 10W wireless charging for compatible devices.
- **Bluetooth Speaker:** High-definition Bluetooth speaker for audio playback.
- **FM Radio:** Built-in FM radio tuner.
- **USB-C Charging Port:** For charging a second mobile device.
- **AUX Input:** For wired audio connection.
- **TF Card Functionality:** For playing music from a memory card.
- **Hotel Mode:** One-off alarm setting that auto-resets.

Setup

1. Power Connection:

1. Connect the provided power adapter to the DC input port on the back of the JVD Carabay.
2. Plug the adapter into a standard wall outlet. The display will illuminate.

2. Initial Time Setting:

Upon initial power-up, the clock may display a default time. Refer to the "Operating Instructions" section for detailed steps on setting the correct time.

Operating Instructions

Time and Alarm Setting

Use the control buttons on the front panel to adjust time and alarm settings.

- **Setting Time:** Press and hold the **SET** button. Use the **<<** and **>>** buttons to adjust hours and minutes. Press **SET** again to confirm.
- **Setting Alarm:** Press the **ALARM** button. Use the **<<** and **>>** buttons to set the desired alarm time. Press **ALARM** again to confirm.
- **Activating/Deactivating Alarm:** Press the **ALARM** button briefly to toggle the alarm on or off. An alarm icon will appear on the display when active.
- **Snooze Function:** When the alarm sounds, press the **SNOOZE/DIMMER** button to activate snooze. The alarm will sound again after a set interval.
- **Hotel Mode One-Off Alarm:** This feature automatically resets the alarm after it sounds, preventing it from sounding again for the next guest. This is ideal for hospitality settings.

Your browser does not support the video tag.

Video: Demonstration of the Hotel Mode One-Off Alarm feature, showing how the alarm automatically resets after activation, suitable for guest accommodations.

Bluetooth Pairing

Connect your mobile device wirelessly to play audio through the JVD Carabay speaker.

1. Press the **MODE** button until "BT" appears on the display, indicating Bluetooth mode.
2. On your mobile device, enable Bluetooth and search for available devices.
3. Select "JVD CARABAY CLOCK" from the list to pair.

4. Once paired, you can stream audio from your device.

FM Radio Operation

Listen to your favorite FM radio stations.

1. Press the **MODE** button until "FM" appears on the display.
2. Press and hold the **<<** or **>>** buttons to auto-scan for stations.
3. Briefly press **<<** or **>>** to manually tune to the next/previous station.

Adjustable Light Dimming

Adjust the brightness of the digital display to your preference.

- Press the **SNOOZE/DIMMER** button repeatedly to cycle through 4 levels of display brightness.
- The display can be dimmed for comfortable viewing in various lighting conditions.

Wireless Charging

Charge compatible devices wirelessly using the top charging pad.

1. Place your Qi-compatible smartphone or device on the wireless charging pad located on top of the JVD Carabay.
2. Ensure the device is centered on the charging pad for optimal charging.
3. A charging indicator (if available on your device) will confirm charging has begun.

Figure 3: Wireless charging in progress, with a smartphone placed on the top surface of the JVD Carabay clock.

USB-C Charging

Charge a second device via the USB-C port on the back.

1. Connect a USB-C charging cable (not included) to the USB-C port on the rear of the JVD Carabay.
2. Connect the other end of the cable to your mobile device.
3. Charging will begin automatically.

AUX Input and TF Card

For alternative audio playback options.

- **AUX Input:** Connect an audio device using a 3.5mm AUX cable (not included) to the AUX port on the back. Press the **MODE** button to select AUX mode.
- **TF Card:** Insert a TF (MicroSD) card with audio files into the designated slot (refer to product diagram or physical device for exact location). Press the **MODE** button to select TF card mode.

Maintenance

Proper care ensures the longevity of your JVD Carabay device.

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Placement:** Place the device on a stable, flat surface away from direct sunlight, heat sources, and moisture.
- **Ventilation:** Ensure adequate ventilation around the device to prevent overheating.

Troubleshooting

Problem	Solution
Device does not power on.	Ensure the power adapter is securely connected to both the device and a working power outlet.
Bluetooth device cannot pair.	Make sure the JVD Carabay is in Bluetooth mode ("BT" on display) and within range. Forget previous pairings on your mobile device and try again.
Wireless charging is not working.	Ensure your device is Qi-compatible and properly centered on the charging pad. Remove any thick cases that might interfere with charging.
FM radio reception is poor.	Adjust the device's position to improve signal. Ensure no large metal objects are nearby.
Alarm does not sound.	Verify the alarm is set and activated (alarm icon visible). Check the alarm volume setting.

Specifications

Feature	Detail
Brand	JVD
Model Number	Alarm
Display Type	Digital
Special Features	Auto Dimmable, Bluetooth, Charging Station, Wireless Charging
Product Dimensions	15.2W x 8.4H Centimeters
Power Source	Corded Electric
Connectivity Technology	Bluetooth, AUX, TF Card
Item Weight	700 Grams
Frame Material	Plastic
Indoor/Outdoor Usage	Indoor, Outdoor

Warranty and Support

The JVD Carabay Digital Alarm Clock comes with a **Limited Warranty**. For warranty claims or technical support, please contact the manufacturer, JVD, or your retailer.
Manufacturer: JVD
For further assistance, please refer to the contact information provided with your purchase or visit the official JVD website.