ZOWEETEK S611

ZOWEETEK S611 Voice Amplifier with Wireless Lavalier Microphone User Manual

Model: S611 | Brand: ZOWEETEK

Introduction

The ZOWEETEK S611 Voice Amplifier is designed to provide clear and powerful voice amplification, making it an ideal tool for teachers, public speakers, yoga instructors, and anyone needing to project their voice effectively. This portable system includes a voice amplifier and a wireless lavalier microphone, ensuring your message is heard without strain or mechanical sound.
The amplifier is engineered to deliver a true original sound, preventing the mechanized audio quality often associated with amplification devices. Its lightweight and compact design allows for comfortable wear and easy portability, suitable for various indoor and outdoor settings.

Image: The ZOWEETEK S611 Voice Amplifier emphasizing its true original sound quality without mechanical interference.

Components Overview

Your ZOWEETEK S611 Voice Amplifier package includes the following items:

- ZOWEETEK S611 Voice Amplifier
- Wireless Lavalier Microphone
- USB-C Charging Cable (for both devices)
- Power Adapter
- Adjustable Waistband/Strap
- User Manual

Image: All components included in the ZOWEETEK S611 Voice Amplifier package.

Setup

Charging the Devices

Both the voice amplifier and the wireless microphone are equipped with rechargeable batteries. Use the provided USB-C charging cable and power adapter to charge both units simultaneously.

- **Voice Amplifier:** Provides 8-12 hours of working time on a full charge. Charging time is approximately 3-5 hours.
- **Wireless Microphone:** Provides 4-6 hours of working time on a full charge. Charging time is approximately 2-3 hours.

Image: Battery life and charging duration for the voice amplifier and wireless microphone.

Pairing the Wireless Microphone

To ensure proper operation, the wireless microphone must be paired with the voice amplifier.

1. Turn on both the voice amplifier and the wireless microphone.
2. On the voice amplifier, press and hold the 'M' key for 3 seconds.
3. On the wireless microphone, press and hold the wireless signal key for 3 seconds.
4. The blue indicator light on the microphone will stop flashing, indicating successful pairing.

Image: Instructions for pairing the wireless microphone with the amplifier.

Operating Instructions

Wearing the Microphone and Amplifier

The wireless microphone offers versatility in how it can be worn or held:

- **Lavalier Style:** The microphone can be clipped onto clothing, such as a lapel or collar, for hands-free operation.
- **Handheld:** The microphone can also be held directly for speaking.

The voice amplifier can be worn around the neck using the provided strap or clipped to clothing using its integrated clip.

Image: Demonstrating handheld and lavalier microphone usage.

Adjusting Volume

The voice amplifier features controls to adjust the output volume. Ensure the volume is set to an appropriate level for your environment to prevent feedback and ensure clarity.

Music Playback

The ZOWEETEK S611 supports music playback from various sources:

- **TF (Micro SD) Card:** Insert a TF card with audio files into the designated slot.
- **USB Flash Drive:** Insert a USB flash drive with audio files into the USB port.

You can repeat single tunes, loop all music, and switch between songs using the controls on the amplifier.

Image: Overview of the amplifier's features, including music playback options.

Important Usage Notes

To ensure optimal performance and prevent audio feedback:

- Do not place the wireless microphone directly in front of the voice amplifier.
- Avoid positioning the microphone too close to the amplifier, as this can cause unwanted noise or feedback.

Image: Guidance on microphone placement to prevent feedback.

Maintenance

To maintain the longevity and performance of your ZOWEETEK S611 Voice Amplifier:

- Keep the devices clean by wiping them with a soft, dry cloth.
- Avoid exposing the devices to extreme temperatures, moisture, or direct sunlight.
- Store the amplifier and microphone in a cool, dry place when not in use.
- Do not attempt to disassemble or repair the devices yourself, as this may void the warranty.

Troubleshooting

Microphone Has No Sound

If the wireless microphone is not producing sound, follow these steps:

1. Ensure both the voice amplifier and the wireless microphone are powered on.
2. Verify that the microphone is properly paired with the amplifier. Refer to the "Pairing the Wireless Microphone" section in Setup.
3. Check the volume levels on both the microphone and the amplifier to ensure they are not muted or set too low.
4. Ensure the microphone is within the effective operating range of the amplifier.
5. Confirm that both devices have sufficient battery charge.

Audio Feedback/Noise

If you experience whistling or static noise:

- Increase the distance between the microphone and the amplifier.
- Reduce the volume level of the amplifier.
- Ensure the microphone is not pointing directly at the amplifier.

Specifications

Feature	Detail
Model Number	S611
Power Source	Battery Powered
Connector Type	Power, USB
Number of Channels	1
Audio Input	Wireless Microphone, Line-Level (TF/Micro SD card, USB flash drive)
Item Weight	13.1 ounces
Package Dimensions	7.24 x 5.63 x 2.2 inches
Batteries	1 Lithium Ion battery required (included)
Battery Type	Lithium Ion
Connectivity Technology	USB
Color	Black
Compatible Devices	Wireless Microphone, USB Flash Drive, TF (Micro SD) Card
Mounting Type	Portable

Image: Physical dimensions of the voice amplifier and microphone.

Warranty and Support

For warranty information and customer support, please refer to the contact details provided in the product packaging or visit the official ZOWEETEK website. Keep your purchase receipt for any warranty claims.