Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Sweetcrispy AH-NFJ2Y02-23GD

Sweetcrispy 23-Inch Portable Space Heater User Manual

Model: AH-NFJ2Y02-23GD

Important Safety Instructions

WARNING: To reduce the risk of fire, electric shock, or injury, observe the following:

- Read all instructions before using this heater.
- Keep combustible materials—such as furniture, pillows, bedding, paper, clothing, and curtains—at least 3 feet (0.9 m) away from the front of the heater, and clear of the sides, top, and rear.
- Do not place towels or other objects on the heater.
- Do not operate any heater with a damaged cord or plug, or after the heater malfunctions, has been dropped or damaged in any manner.
- Do not use outdoors.
- This heater is not intended for use in bathrooms, laundry areas, and similar indoor locations. Never locate heater where it may fall into a bathtub or other water container.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- To disconnect heater, turn controls to OFF, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable vapors or liquids are used or stored.
- Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
- This heater is for indoor use only.

Setup Instructions

Follow these steps to assemble the base of your Sweetcrispy Space Heater:

1. Carefully remove all components from the packaging.
2. Locate the two base pieces and the main heater unit.
3. Align the two base pieces and connect them around the bottom of the heater unit. Ensure the cable passes through the designated

opening in the base.

4. Secure the base to the heater unit using the provided fastening nut. Turn the nut clockwise until it is tight and the base is stable.
5. Place the heater on a firm, level surface, ensuring it is at least 3 feet (0.9 m) away from any walls or combustible materials.



Image: Sweetcrispy Space Heater with its base attached, ready for use.

Operating Instructions

Your Sweetcrispy Space Heater can be operated using the touch control panel on the top of the unit or the included remote control.

Control Panel Overview



Image: Close-up of the Sweetcrispy Space Heater's top control panel, showing various function icons.

- **Power Button:** Press to turn the heater ON or OFF.
- **Mode Button:** Cycle through heating modes (e.g., High, Low, ECO).
- **Temperature Adjustment (+/-):** Increase or decrease the desired temperature (50°F to 95°F).
- **Oscillation Button:** Activate or deactivate the 70° oscillation feature for wider heat distribution.
- **Timer Button:** Set the automatic shut-off timer for up to 12 hours.
- **Light Mode Button:** Cycle through 7 different ambient light modes for the fireplace effect.
- **Child Lock Button:** Press and hold for 3-5 seconds to activate or deactivate the child lock feature, preventing accidental changes to settings.

Remote Control Operation

The remote control provides convenient access to all heater functions. Ensure the remote is pointed towards the top of the heater for optimal response.



Image: The remote control for the Sweetcrispy Space Heater, showing various function buttons.

- The remote control mirrors the functions available on the unit's touch panel.
- Insert the required batteries (CR2025/2032, typically included) into the remote before first use.

Special Features

- **7 Soothing Light Modes:** Customize the ambiance with various colors for the fireplace effect.
- **70° Oscillation:** Distributes warmth evenly across the room.
- **12-Hour Timer:** Program the heater to turn off automatically.
- **Adjustable Thermostat:** Maintain your desired room temperature between 50°F and 95°F.
- **ECO Mode:** Optimizes energy consumption by adjusting heating power based on the set temperature.

Maintenance

Regular maintenance ensures optimal performance and longevity of your heater.

- **Cleaning:** Always unplug the heater before cleaning. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or solvents.

- **Dust Removal:** Use a vacuum cleaner with a brush attachment to remove dust from the air intake and exhaust grilles.
- **Storage:** When not in use, store the heater in a cool, dry place.



Image: Rear view of the Sweetcrispy Space Heater, highlighting the air intake grille for cleaning.

Troubleshooting

If you encounter issues with your heater, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Heater does not turn on.	No power, power switch off, tip-over switch activated.	Ensure the heater is plugged into a working outlet. Check if the power button is pressed. If the heater was tipped, place it upright; it should resume operation or display an error code (e.g., "E3") and count down before turning off.
Heater blows cold air.	Temperature setting too low, ECO mode active.	Increase the desired temperature setting. If in ECO mode, the heater may cycle between heating and fan-only operation to maintain temperature.

Problem	Possible Cause	Solution
Remote control not working.	Dead batteries, remote not pointed correctly.	Replace the remote control batteries (CR2025/2032). Ensure the remote is pointed directly at the control panel on the top of the heater.
Heater makes unusual noises.	Dust accumulation, internal component issue.	Unplug the heater and clean the air grilles. If the noise persists, discontinue use and contact customer support.

Specifications

- **Brand:** Sweetcrispy
- **Model Number:** AH-NFJ2Y02-23GD
- **Power:** 1500W
- **Voltage:** 120 Volts
- **Amperage:** 12.5 Amps
- **Product Dimensions:** 24.5"D x 6.3"W x 7.5"H
- **Item Weight:** 5.3 Pounds
- **Color:** Gold
- **Form Factor:** Tower
- **Indoor/Outdoor Usage:** Indoor
- **Recommended Uses:** Home, Office
- **Mounting Type:** Floor Mount
- **Special Features:** Adjustable Speed (3 speeds), Adjustable Temperature (50°F-95°F), Child Lock, 70° Oscillation, Overheat Protection, 7 Light Modes, 12-Hour Timer.
- **Fuel Type:** Electric
- **Assembly Required:** No (minimal base attachment)
- **Batteries Required:** No (for main unit), Yes (for remote - CR2025/2032)

Warranty Information

For detailed warranty information, please refer to the documentation included with your product or visit the official Sweetcrispy website. Keep your purchase receipt as proof of purchase for any warranty claims.

Customer Support

If you have any questions, require assistance, or need to report an issue with your Sweetcrispy Space Heater, please contact Sweetcrispy customer service through their official website or the contact information provided in your product packaging.

© 2026 Sweetcrispy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FPGG1FCF

More documents and user manuals: **https://manuals.plus/**