Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Sweetcrispy GDZ-2BC-47IN

Sweetcrispy 48 Inch Computer Desk User Manual

Model: GDZ-2BC-47IN

1. Important Safety Information

Please read and understand all instructions before assembly and use. Keep this manual for future reference.

- This desk is designed to support a maximum weight of**200 lbs (90.7 kg)** on the main tabletop. The small base plate has a maximum load capacity of **66 lbs (30 kg)**. Do not exceed these limits to prevent damage or injury.
- Ensure the desk is assembled correctly and placed on a flat, stable surface to maintain stability and prevent wobbling.
- Keep small parts and packaging materials away from children to avoid choking hazards.
- Regularly check all fasteners to ensure they remain tight. Retighten as necessary.
- Avoid placing hot items directly on the desk surface without protection.

For any questions or concerns regarding safety or assembly, please contact Sweetcrispy customer support.

2. Product Overview

The Sweetcrispy 48 Inch Computer Desk is designed for home office, study, or gaming environments. It features a durable MDF tabletop, a sturdy metal frame with X-shaped reinforcement for enhanced stability, and two adjustable position fabric drawers for flexible storage. Integrated side hooks provide convenient hanging space for headphones or bags.



Figure 2.1: Assembled Sweetcrispy 48 Inch Computer Desk, showcasing its design and functionality in a typical setup.

3. Package Contents

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer service.



Figure 3.1: Illustrated parts kit for the Sweetcrispy Computer Desk. Refer to the included manual for specific part identifiers and quantities.

The package typically includes:

- Tabletop (Premium MDF Board)
- Metal Frame Components (Legs, Support Bars)
- X-shaped Reinforcement Bars
- Fabric Drawers (2 units)
- Side Hooks (2 units)
- Assembly Hardware (screws, bolts, Allen wrench)
- Instruction Manual

4. Specifications

Detailed specifications for the Sweetcrispy 48 Inch Computer Desk:

Feature	Detail
Brand	Sweetcrispy
Model Number	GDZ-2BC-47IN
Product Dimensions (L x W x H)	47.24" x 19.69" x 29.57" (120cm x 50cm x 75cm)
Item Weight	26.92 Pounds (12.21 kg)
Material	Premium MDF Board (Top), Metal (Frame)
Color	Rustic Wood (Top), Black (Frame)
Maximum Load Capacity (Tabletop)	200 lbs (90.7 kg)
Maximum Load Capacity (Small Base Plate)	66 lbs (30 kg)
Drawer Load Capacity (Each)	22 lbs (10 kg)

Feature	Detail
Special Features	Scratch Resistant, X-Shaped Reinforcement, Adjustable Position Drawers, Side Hooks
Assembly Required	Yes
Included Components	Desk, Assembly Tools



Figure 4.1: Size information and load capacities for the desk and its components.

5. Setup and Assembly Instructions

Assembly of the Sweetcrispy Computer Desk is designed to be straightforward. All necessary parts and tools are included. Follow the step-by-step instructions provided in the separate assembly manual for detailed guidance.

Key Assembly Features:

- **X-Shaped Reinforcement:** The desk features an X-shaped frame at the rear for enhanced stability. Ensure these bars are securely fastened during assembly to prevent wobbling.
- **Adjustable Drawer Position:** The fabric drawers can be installed on either the left or right side of the desk, depending on your preference and workspace layout. This flexibility allows for customization.



Figure 5.1: Detail of the X-shaped reinforced structure, providing stability.



Figure 5.2: The flexible drawer setup allows installation on either side.

6. Operating Instructions and Features

Once assembled, the Sweetcrispy Computer Desk is ready for use. Its design incorporates several features to enhance your workspace.

Key Features:

- **Adjustable Position Drawers:** The two fabric drawers can be positioned on either the left or right side of the desk. This allows you to customize your storage based on your needs and the layout of your room. Simply remove and re-attach the drawer unit to the desired side during assembly or re-assembly. Each drawer can hold up to 22 lbs.
- **Handy Side Hooks:** Two side hooks are integrated into the desk frame. These are ideal for hanging headphones, bags, or other accessories, helping to keep your desktop clear and organized.



Figure 6.1: Side hooks provide convenient storage for headphones or bags.

7. Maintenance and Care

Proper care will ensure the longevity and appearance of your Sweetcrispy Computer Desk.

- **Cleaning:** Wipe the desk surface and metal frame with a clean, damp cloth. For stubborn marks, a mild soap solution can be used, followed by wiping with a dry cloth. Avoid harsh chemicals or abrasive cleaners, as these can damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining or damage to the MDF board. The tabletop is designed to be waterproof, but prolonged exposure to liquids should be avoided.
- **Protection:** Use coasters for drinks and protective pads under hot items or sharp objects to prevent scratches and heat damage.
- **Fasteners:** Periodically check all screws and bolts to ensure they are tight. Retighten as needed to maintain the desk's structural integrity and stability.



Figure 7.1: Features such as premium MDF board, side hooks, and sturdy metal frame contribute to durability and ease of maintenance.

8. Troubleshooting

If you encounter any issues with your Sweetcrispy Computer Desk, refer to the following common solutions:

- **Desk is Wobbly:**
  - Ensure all screws and bolts are fully tightened, especially those connecting the X-shaped reinforcement bars.
  - Verify the desk is placed on a level surface. If not, consider using furniture pads or shims to stabilize.
- **Missing Parts:**
  - Carefully check all packaging materials. Small parts can sometimes be overlooked.
  - Refer to the parts list in your assembly manual. If parts are genuinely missing, contact Sweetcrispy customer support with your purchase details.
- **Drawers Not Sliding Smoothly:**

- Ensure the fabric drawers are correctly inserted into their designated slots.
- Check for any obstructions within the drawer slots.

If these steps do not resolve the issue, please contact Sweetcrispy customer support for further assistance.

9. Warranty and Support

For information regarding the product warranty, please refer to the documentation included with your purchase or contact the retailer from whom the product was purchased. Warranty terms and conditions may vary.

For technical support, assembly assistance, or to report missing/damaged parts, please contact Sweetcrispy customer service. Have your model number (GDZ-2BC-47IN) and purchase information ready when contacting support.

You may also visit the official Sweetcrispy store on Amazon for additional product information and support resources: Sweetcrispy Amazon Store

© 2023 Sweetcrispy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FPWNPKXW

More documents and user manuals: **https://manuals.plus/**