Manuals+
Q & A | Deep Search | Upload

XMSJSIY USB Type-C 23-Key Numeric Keypad

XMSJSIY USB Type-C 23-Key Numeric Keypad Instruction Manual

Model: USB Type-C 23-Key Numeric Keypad
Brand: XMSJSIY

1. Introduction

This manual provides instructions for the proper setup, operation, and maintenance of your XMSJSIY USB Type-C 23-Key Numeric Keypad. Please read this guide thoroughly before using the device to ensure optimal performance and longevity.

2. Product Overview

The XMSJSIY USB Type-C 23-Key Numeric Keypad is designed to enhance data entry efficiency for professionals and everyday users. It features a compact design with a comfortable tactile feel and minimal key noise, suitable for various work environments.

Key Features:

- **23-Key Layout:** Includes essential numeric keys and dedicated shortcut keys for Tab, Home, Email, and Calculator.
- **Ergonomic Design:** Features a 15-degree tilt to reduce wrist strain and promote comfortable typing.
- **Durable Construction:** High-quality ABS keys provide precise operation and excellent resistance.
- **Quiet Operation:** Designed for minimal key noise, ideal for quiet workspaces.
- **Anti-slip Pads:** Ensures stability on your desk surface.

Package Contents:

- XMSJSIY USB Type-C 23-Key Numeric Keypad
- USB Cable

Image: Detailed view of the numeric keypad, highlighting clear characters, responsive keys, and the indicator light for user-friendliness.

Image: The 15-degree ergonomic design of the keypad, showing its comfortable and compact profile.

3. Setup

The XMSJSIY USB Type-C Numeric Keypad offers plug-and-play functionality, requiring no additional software or drivers for most operating systems.

Connecting the Keypad:

1. Locate an available USB Type-C port on your computer (laptop, PC, desktop, Chromebook, or tablet).

2. Connect the USB Type-C cable from the keypad to the USB Type-C port on your device.
3. The keypad should be automatically recognized by your operating system and ready for use.

Compatibility:

This numeric keypad is compatible with a wide range of devices and operating systems, including:

- Windows PCs and Laptops
- macOS (Apple) Laptops and Desktops
- Android Tablets and Devices
- Chromebooks

Image: The keypad connected via its USB Type-C port to a laptop, illustrating its plug-and-play nature and portable form factor.

Image: Visual representation of the keypad's compatibility with different operating systems and device types, including Windows, Mac, iOS, and Android.

4. Operating Instructions

Once connected, the numeric keypad functions like a standard numeric section of a full-sized keyboard. It also includes several dedicated shortcut keys for increased productivity.

Standard Numeric Input:

Use the number keys (0-9) and arithmetic operators (+, -, *, /) for numerical data entry. The 'Num Lock' key toggles the numeric function of the keys. When Num Lock is off, some keys may function as navigation keys (Home, End, PgUp, PgDn, arrow keys).

Shortcut Key Functions:

- **Home Key:** Opens your default web browser.
- **Tab Key:** Performs the 'Tab' function, moving the cursor to the next field or element.
- **Email Key:** Opens your default email client.
- **Calculator Key:** Launches the system's calculator application.
- **Backspace/Delete:** Functions as standard backspace and delete keys.
- **Page Up/Page Down/Arrow Keys:** Provide navigation functionality when Num Lock is off.

Image: A labeled diagram of the 23-key layout, indicating the positions and functions of the One-Tap Home, Tab, Mail address, and One-Click Calculator keys.

Image: User interacting with the numeric keypad, highlighting its role in improving productivity with its 23-key layout and integrated arrow keys.

5. Maintenance

To ensure the longevity and proper functioning of your numeric keypad, follow these simple maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the keypad. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid excessive moisture.
- **Avoid Liquids:** Do not spill liquids directly onto the keypad. If a spill occurs, disconnect it immediately and allow it to dry completely before reconnecting.
- **Storage:** When not in use, store the keypad in a clean, dry place away from direct sunlight and extreme temperatures.
- **Handle with Care:** Avoid dropping the keypad or subjecting it to strong impacts, as this can damage internal components.

6. Troubleshooting

If you encounter issues with your XMSJSIY numeric keypad, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Keypad not recognized / Not working	Loose connection, faulty USB port, driver issue (rare)	Ensure the USB Type-C cable is securely connected to both the keypad and your computer. Try connecting the keypad to a different USB Type-C port on your computer. Test the keypad on another computer to rule out a device-specific issue. Restart your computer.
Keys are not typing numbers (typing navigation instead)	Num Lock is off	Press the 'Num Lock' key on the keypad to activate numeric input. The indicator light should turn on.
Specific keys not responding	Debris under key, physical damage	Gently clean around the affected key to remove any debris. If the issue persists, contact customer support.

7. Specifications

Image: Product dimensions, illustrating the compact size of the keypad.

Feature	Detail
Brand	XMSJSIY
Model	USB Type-C 23-Key Numeric Keypad
Compatible Devices	Laptop, PC, Desktop, Chromebook, Tablet

Feature	Detail
Connectivity Technology	USB-C (Wired)
Key Layout	23 Keys (Numeric, Tab, Home, Email, Calculator, etc.)
Special Features	Ergonomic 15-degree tilt, Shortcut Keys, Plug-and-Play
Material	ABS
Included Components	USB Cable
Power Source	Corded Electric (via USB-C)
Dimensions (L x W x H)	14.68 x 8.99 x 0.99 cm (approx. 5.78 x 3.54 x 0.39 inches)
Weight	59 g (approx. 2.08 oz)

8. Warranty and Support

For warranty information or technical support, please refer to the product packaging or contact the retailer from whom you purchased the XMSJSIY USB Type-C 23-Key Numeric Keypad. Keep your purchase receipt as proof of purchase.