Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GARAID VAC104

GARAID 4-in-1 Cordless Handheld Vacuum Cleaner

Model: VAC104
Brand: GARAID

Introduction

This manual provides detailed instructions for the safe and efficient use of your GARAID 4-in-1 Cordless Handheld Vacuum Cleaner. This versatile device combines four functions: vacuuming, blowing, inflating, and vacuum sealing, making it suitable for various cleaning and household tasks. Please read this manual thoroughly before first use and retain it for future reference.



Image: The GARAID 4-in-1 Handheld Vacuum Cleaner.



Image: The GARAID 4-in-1 Handheld Vacuum Cleaner demonstrating its multiple functionalities.

Product Overview and Components

Familiarize yourself with the components included in your package:



Image: All components included in the product package.

- **Main Unit:** The core device for all functions.
- **USB Charging Cable:** For recharging the device.
- **User Manual:** This instruction guide.
- **Long Suction Nozzle:** For reaching tight spaces during vacuuming.
- **Angled Brush:** Attaches to the long suction nozzle for cleaning irregular surfaces.
- **Short Suction Nozzle:** General purpose vacuuming.
- **Floor Brush:** For larger surface vacuuming.
- **Long Blowing Nozzle:** For focused airflow in blower mode.
- **Short Blowing Nozzle:** For general blowing tasks.
- **Wide Blowing Nozzle:** For broader airflow in blower mode.
- **Round Brush:** Attaches to the long blowing nozzle for dusting.
- **Vacuum Extraction Nozzle:** For use with vacuum storage bags.
- **HEPA Filters (x2):** High-efficiency particulate air filters.

Setup

Before using the device, ensure it is fully charged. Refer to the "Charging" section for details.

Assembling for Vacuuming:

1. **Install the Dust Bin:** Align the dust bin with the main unit and twist clockwise until it locks securely.
2. **Attach the Nozzle:** Select the appropriate suction nozzle (long, short, or floor brush) and attach it to the dust bin opening. For the angled brush, attach it to the long suction nozzle first.
3. **Power On:** Press the power button to start vacuuming. Press again to switch between power levels.

Assembling for Blowing/Inflating/Vacuum Sealing:

1. **Remove the Dust Bin:** Twist the dust bin counter-clockwise to remove it.
2. **Attach the Blower/Inflator Nozzle:** Select the appropriate nozzle (long, short, wide blowing nozzle for blowing; vacuum extraction nozzle for vacuum sealing; specific inflator nozzles for inflation) and attach it to the air outlet of the main unit. For the round brush, attach it to the long blowing nozzle first.
3. **Power On:** Press the power button to start the function. Press again to switch between power levels.



Image: Assembly steps for vacuum and blower modes.

Operating Instructions

Your GARAID 4-in-1 device offers two power levels for both suction and blowing functions.

Power On/Off and Speed Selection:

- Press the power button once to turn on the device at the lower power level.
- Press the power button a second time to switch to the higher power level.
- Press the power button a third time to turn off the device.

Vacuuming Function:

Use the vacuum function for cleaning dust, crumbs, pet hair, and small debris from various surfaces.



Image: Vacuuming debris from a car interior.

- **25000Pa Suction:** Provides strong suction for approximately 15 minutes.
- **15000Pa Suction:** Provides standard suction for approximately 25 minutes.
- Attach the appropriate suction nozzle for the task. The long suction nozzle is ideal for crevices, the floor brush for flat surfaces, and the angled brush for irregular areas like car vents.



Image: Vacuuming crumbs from a sofa.

Blowing Function (Air Duster):

The blowing function is effective for removing dust from keyboards, electronics, or drying wet surfaces.



Image: Using the device in blower mode to clear dust.

- **150,000 RPM Blowing:** Provides strong airflow for approximately 15 minutes.
- **80,000 RPM Blowing:** Provides standard airflow for approximately 25 minutes.
- Attach the appropriate blowing nozzle. The long blowing nozzle is good for focused air, and the round brush can be used for gentle dusting.



Image: Using the blower to clean a keyboard.

Inflating Function:

Use the device to inflate small items like air mattresses, swimming rings, or inflatable toys.



Image: Inflating an air mattress.

- Attach the appropriate inflator nozzle to the air outlet.
- Insert the nozzle into the item to be inflated.
- Press the power button to start inflation.

Vacuum Sealing Function:

This function allows you to remove air from vacuum storage bags, saving space for clothing or other items.



Image: Vacuum sealing a storage bag.

- Attach the vacuum extraction nozzle to the air outlet.
- Place the nozzle over the air valve of your vacuum storage bag.
- Press the power button to begin extracting air.

Charging

The GARAID 4-in-1 vacuum cleaner is equipped with a 6000mAh battery and charges via a Type-C USB cable.



Image: Charging the device via Type-C USB.

- **Battery Capacity:** 6000mAh.
- **Charging Time:** Approximately 3-3.5 hours for a full charge.
- **Charging Indicator:** The LED indicator will show red during charging and turn green when fully charged.
- **Charging Methods:** Use the provided USB-C cable with a power adapter, power bank, computer, or car charger.
- Ensure the device is turned off during charging.

Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your device.

Emptying the Dust Bin:

1. Ensure the device is turned off.
2. Hold the main unit and twist the dust bin counter-clockwise to detach it.
3. Empty the contents of the dust bin into a waste receptacle.

Cleaning the HEPA Filter:

The HEPA filter is washable and reusable. Clean it regularly to maintain suction efficiency.



Image: Steps for cleaning the HEPA filter.

1. After emptying the dust bin, gently twist and pull out the HEPA filter.
2. Rinse the HEPA filter under running water until clean.
3. Allow the filter to air dry completely before reinserting it into the dust bin. Do not use the device with a wet filter.
4. Reassemble the filter and dust bin onto the main unit.

Troubleshooting

If you encounter issues, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Charge the device fully.
Low suction/blowing power.	Dust bin is full. HEPA filter is clogged. Nozzle is blocked.	Empty the dust bin. Clean or replace the HEPA filter. Check and clear any blockages in the nozzle or main unit.
Device stops unexpectedly.	Battery is low. Overheating protection activated.	Recharge the device. Turn off the device and allow it to cool down for 30 minutes before resuming use.
Charging indicator not working.	Charging cable or adapter faulty. Charging port dirty.	Try a different USB-C cable and power adapter. Clean the charging port gently.

If the problem persists after trying these solutions, please contact customer support.

Specifications

Key technical specifications for the GARAID 4-in-1 Cordless Handheld Vacuum Cleaner:



Image: Internal components and airflow diagram.

- **Model Name:** 668
- **Model Number:** VAC104
- **Brand:** GARAID
- **Power Source:** Battery Powered (Cordless)
- **Motor:** 120W Brushless Motor
- **Suction Power:** 25000Pa (High), 15000Pa (Standard)
- **Blowing Power:** 150,000 RPM (High), 80,000 RPM (Standard)
- **Battery Life:** Up to 25 minutes (Standard mode)
- **Battery Capacity:** 6000mAh
- **Charging Time:** 3-3.5 hours
- **Filter Type:** Washable HEPA Filter
- **Control Method:** Button
- **Dimensions (LxWxH):** 25L x 21.5W x 6.3H cm
- **Recommended Surfaces:** All floor types, car interiors, upholstery, electronics.
- **Special Features:** High power, Compact, HEPA filtration, Rechargeable, Dry and Wet use.

Warranty and Support

Your GARAID 4-in-1 Cordless Handheld Vacuum Cleaner comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions, including the warranty period and coverage details. For technical support, troubleshooting assistance, or warranty claims, please contact GARAID customer service through the contact information provided on your warranty card or the official GARAID website. When contacting support, please have your model number (VAC104) and purchase details ready.

© 2026 GARAID. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FS6WHJ6G

More documents and user manuals: **https://manuals.plus/**