Manuals+
Q & A | Deep Search | Upload

GKTZ P210

GKTZ Kids Instant Print Camera P210 User Manual

Model: P210

1. Introduction

This manual provides detailed instructions for the safe and effective use of your GKTZ Kids Instant Print Camera P210. Designed for children aged 3-12, this digital camera allows for instant black and white photo printing and color digital storage. Please read this manual thoroughly before operating the camera and keep it for future reference.

Image: The GKTZ Kids Instant Print Camera P210, a compact purple digital camera designed for children.

2. Package Contents

Verify that all items listed below are included in your package:

- 1 x GKTZ Kids Instant Print Camera P210
- 3 x Rolls of Photo Paper
- 1 x 32GB SD Card
- 1 x Type-C USB Cable
- 1 x Lanyard
- 1 x Sticker Set
- 1 x User Manual (this document)

Image: All components included in the GKTZ Kids Instant Print Camera P210 package.

3. Camera Overview

Familiarize yourself with the camera's physical features and controls.

Image: Front view of the camera with icons indicating its various functions.

Key Features:

- **2.4-inch IPS Eye-Care Screen:** For comfortable viewing.
- **Rotating Lens:** Allows for easy switching between front and rear camera modes.
- **Instant Print Function:** Prints black and white photos directly from the camera.
- **1080P HD Video Recording:** Captures high-definition video.
- **32GB SD Card Support:** For storing color digital photos and videos.
- **Creative Filters & Photo Frames:** Enhance photos with fun effects.
- **Games:** Includes built-in puzzle games for entertainment.
- **Type-C Charging:** Modern and convenient charging port.
- **Lanyard Slot:** For attaching the included safety strap.

4. Setup

4.1. Installing Photo Paper

1. Locate the paper slot on the side of the camera.
2. Gently open the paper slot cover.
3. Insert a roll of thermal photo paper, ensuring it is correctly oriented with the printing side facing the print head.
4. Pull a small length of paper out of the slot.
5. Close the paper slot cover securely.

Image: Step-by-step guide for replacing the thermal printing paper roll.

4.2. Inserting the SD Card

- Locate the SD card slot, typically on the side of the camera.
- Insert the provided 32GB SD card into the slot until it clicks into place. Ensure the card is inserted in the correct orientation.
- To remove, gently push the SD card inward until it springs out.

4.3. Charging the Camera

- Connect the Type-C USB cable to the camera's charging port.
- Connect the other end of the USB cable to a compatible USB power adapter (not included) or a computer's USB port.
- The charging indicator light will illuminate during charging and turn off when fully charged.
- A full charge typically takes approximately 3 hours.

5. Operating Instructions

5.1. Power On/Off

- To power on, press and hold the power button for a few seconds until the screen illuminates.
- To power off, press and hold the power button again until the screen turns off. The camera also features an auto shut-off function to conserve battery.

5.2. Taking Photos

1. Turn on the camera.

2. Use the navigation buttons to select the photo mode.
3. Frame your shot using the 2.4-inch IPS screen. You can rotate the lens to switch between front and rear views for selfies or regular photos.
4. Press the shutter button to capture the image.
5. If instant print mode is enabled, the photo will print automatically in black and white. A color digital copy will be saved to the SD card.
6. The camera supports 16x digital zoom. Use the zoom buttons to adjust.
7. **Continuous Shooting:** Select this option in the menu to take multiple photos in quick succession.

Image: Continuous shooting feature, showing printed black and white output and digital color storage.

5.3. Recording Videos

1. Turn on the camera.
2. Use the navigation buttons to select the video recording mode.
3. Press the shutter button to start recording. A red "REC" indicator will appear on the screen.
4. Press the shutter button again to stop recording.
5. Videos are saved in 1080P HD resolution to the SD card.

Image: Demonstrating 1080P HD video recording and 16x digital zoom.

Your browser does not support the video tag.

Video: An overview of the GKTZ Kids Instant Print Camera's features and operation.

5.4. Using Filters and Photo Frames

- In photo mode, navigate through the menu to find the "Filters" or "Frames" options.
- Select from the available 6 creative filters and 18 photo frames to add fun effects to your pictures.
- Preview the effect on the screen before taking the photo.

Image: Examples of creative filters and photo frames for enhancing pictures.

5.5. Playback Mode

- From the main menu, select "Playback" to view saved photos and videos.
- Use the navigation buttons to scroll through your media.
- You can choose to print previously taken photos from this mode if instant print was not enabled at the time of capture.

5.6. Games

- The camera includes built-in puzzle games. Select the "Games" option from the main menu to access them.
- Use the navigation buttons to control gameplay.

Your browser does not support the video tag.

Video: Demonstration of the GKTZ Digital Instant Print Camera for Kids, showcasing its various functions.

6. Maintenance

6.1. Cleaning the Camera

- Ensure the camera is powered off before cleaning.
- Use a soft, dry cloth to wipe the camera body.
- For the lens and screen, use a microfiber cleaning cloth specifically designed for optics. Do not use abrasive cleaners or solvents.

6.2. Paper Replacement

- When the paper runs out, follow the instructions in section 4.1 to install a new roll.
- Only use compatible thermal paper rolls for optimal printing quality.

6.3. SD Card Management

- Regularly transfer photos and videos from the SD card to a computer or other storage device to prevent data loss and free up space.
- Format the SD card periodically within the camera's settings to maintain performance. (*Note: Formatting will erase all data on the card. Back up important files first.*)

7. Troubleshooting

Problem	Possible Solution
Camera does not power on.	Ensure the battery is charged. Connect the camera to a power source using the USB-C cable.
Photos are not printing.	Check if there is photo paper installed correctly. Ensure instant print mode is enabled in settings.
Poor print quality.	Ensure the thermal paper is correctly installed and is not old or damaged. Clean the print head if necessary (refer to maintenance section).
Cannot save photos/videos.	Check if the SD card is inserted correctly and has sufficient free space. The SD card may need to be formatted.
Camera freezes or becomes unresponsive.	Press and hold the power button for 10-15 seconds to force a restart. If the issue persists, contact customer support.

8. Specifications

Feature	Detail
Model Number	P210
Product Dimensions	4.33 x 3.94 x 1.97 inches
Item Weight	6.1 ounces (0.38 Pounds)
Screen Size	2.4-inch IPS Eye-Care Screen
Video Resolution	1080P HD
Zoom	16x Digital Zoom
Storage	32GB SD Card (included)
Battery	1 Lithium Ion battery (included), 2000mAh capacity
Charging Port	Type-C USB
Print Type	Thermal (Black and White)
Special Features	Auto Exposure, Rotating Lens, Time-lapse, MP3 Playback, Puzzle Games

9. Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official GKTZ website. Keep your proof of purchase for any warranty claims.

© 2026 GKTZ. All rights reserved.