Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GKTZ P200

GKTZ Kids Instant Print Camera P200 User Manual

Model: P200

Introduction

Thank you for choosing the GKTZ Kids Instant Print Camera P200. This digital camera is designed for children aged 3-12, offering instant black and white photo printing, 1080P video recording, and various creative features. This manual provides essential information for safe and effective use of your camera. Please read it thoroughly before operation.

Package Contents

Please verify that all items listed below are included in your package:

- 1 x Printing Camera
- 3 x Rolls Photo Paper
- 1 x 32GB SD Card
- 1 x Type-C USB Cable
- 1 x Lanyard
- 1 x Sticker Set
- 1 x User Manual (this document)



Image: Contents of the GKTZ Kids Instant Print Camera package.

Setup

1. Charging the Camera

Before first use, fully charge the camera. Connect the provided Type-C USB cable to the camera's charging port and the other end to a compatible USB power adapter (not included) or computer USB port. The charging indicator will illuminate during charging and turn off when fully charged. A full charge typically takes approximately 4 hours.



Image: Location of the Type-C USB charging port on the camera.

2. Inserting the SD Card

The camera comes with a 32GB SD card. Locate the SD card slot on the side of the camera. Gently insert the SD card with the metal contacts facing down until it clicks into place. To remove, push the card in again until it springs out.

▶ **Watch video online**
Kids Instant Print Camera

Video: Demonstrating how to insert the SD card into the camera. This video shows the camera being unboxed and the SD card being inserted into the slot on the side.

3. Loading Photo Paper

Open the paper compartment cover on the camera. Insert a roll of thermal photo paper with the printing side facing the lens. Close the cover securely, ensuring a small portion of the paper extends from the slot.



Image: Illustrates the process of loading thermal paper into the camera.

Operating Instructions

1. Power On/Off

Press and hold the power button for a few seconds to turn the camera on or off. The 2.4-inch IPS eye-care screen will light up.

2. Taking Photos

1. Turn on the camera.
2. Frame your shot using the LCD screen.
3. Press the shutter button to capture the image.
4. The camera will instantly print a black and white version of the photo. A color copy is saved to the SD card.

▶ **Watch video online**
Toddler Digital Camera

Video: A user demonstrating taking a photo and the instant print feature of the camera. The video shows the camera screen, the shutter button being pressed, and the black and white photo emerging from the top slot.

3. Recording Videos

Switch to video mode (refer to on-screen icons). Press the shutter button to start recording 1080P HD video. Press again to stop. Videos are saved to the SD card.

4. Using Filters and Frames

The camera includes 6 creative filters and 18 frames. Navigate through the menu options using the directional buttons to select your desired filter or frame before taking a photo or recording a video.



Image: Examples of creative frames available on the camera.



Image: Examples of color filters available on the camera.

5. Self-Timer and Burst Mode

Access these features through the camera's menu. The self-timer allows for delayed photo capture (e.g., 2s, 5s, 10s), while burst mode takes multiple photos in quick succession.



Image: Demonstrates the self-timer function for group photos.

Maintenance

1. Cleaning the Camera

Use a soft, dry cloth to clean the camera body and screen. Do not use liquid cleaners or abrasive materials. Keep the lens free from dust and fingerprints for clear images.

2. Replacing Photo Paper

When the camera runs out of paper, open the paper compartment and replace the empty roll with a new one, ensuring correct orientation as described in the "Loading Photo Paper" section.

3. Battery Care

To prolong battery life, avoid fully discharging the camera frequently. Charge the camera regularly, even if not in use for extended periods. Do not expose the camera to extreme temperatures.

Troubleshooting

Problem	Possible Cause	Solution
Camera does not turn on.	Low battery.	Charge the camera fully using the provided USB cable.
Photos are not printing.	No photo paper, paper incorrectly loaded, or print function disabled.	Check if paper is loaded correctly and sufficient. Ensure print function is enabled in settings.
Poor print quality.	Low battery, dirty print head, or low-quality paper.	Ensure camera is charged. Gently clean the print head. Use recommended thermal paper.
Cannot save photos/videos.	SD card full, incorrectly inserted, or corrupted.	Check SD card insertion. Delete unnecessary files or replace the SD card. Format the SD card if necessary (this will erase all data).

Problem	Possible Cause	Solution
Camera freezes or malfunctions.	Software glitch.	Press the reset button (if available, usually a small pinhole) or hold the power button for 10 seconds to force a restart.

Specifications

- **Brand:** GKTZ
- **Model Name:** Instant Print Camera for Kids (P200)
- **Screen Size:** 2.4 Inches IPS Eye-Care Screen
- **Effective Still Resolution:** 1920 MP
- **Video Capture Resolution:** 1080p (AVI format)
- **Special Features:** Auto Exposure, Self-Timer, Burst Mode, 6 Filters, 18 Frames
- **Film Color:** Black and White (for instant prints)
- **Included Storage:** 32GB SD Card
- **Battery Average Life:** Approximately 4 Hours
- **Item Weight:** 0.43 Pounds
- **Item Dimensions (L x W x H):** 3.43 x 3.83 x 2.09 inches
- **Power Source:** Type-C USB Cable

Warranty and Support

Warranty Information

GKTZ provides a 24-month warranty replacement service for this toddler digital instant camera. If you encounter any quality issues, we will offer a free replacement within 24 months from the date of purchase.

Customer Support

Our customer support team is available 24/7 to help resolve any issues quickly. For assistance, please refer to the contact information provided on the product packaging or the official GKTZ website.

© 2026 GKTZ. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FSVQP6G4

More documents and user manuals: **https://manuals.plus/**