Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Garvee NEWSNOWBLOWER

Garvee 20" Electric Snow Blower Corded - Instruction Manual

Model: NEWSNOWBLOWER

Information | Setup | Operation | Safety | Maintenance | Troubleshooting | Specifications | Warranty & Support

1. Introduction

This manual provides essential instructions for the safe assembly, operation, and maintenance of your Garvee 20" Electric Snow Blower. Please read this manual thoroughly before using the product and retain it for future reference. Proper use and care will ensure optimal performance and extend the life of your snow blower.
The Garvee 20" Electric Snow Blower is designed for clearing snow from walkways, driveways, porches, and decks. It features a 15-amp brushless motor, a 20-inch clearing width, and a 180-degree rotating chute.

2. Safety Information

WARNING: Read all safety warnings and instructions before operating this snow blower. Failure to follow the warnings and instructions may result in electric shock, fire, and/or serious injury.

- Always wear appropriate personal protective equipment, including safety glasses and sturdy footwear.
- Keep children, pets, and bystanders away from the operating area.
- Inspect the area to be cleared for foreign objects that could be thrown by the auger.
- Do not operate the snow blower on slopes that are too steep.
- Ensure the extension cord is suitable for outdoor use and rated for the snow blower's power requirements. Keep the cord clear of the auger and discharge chute.
- Never place hands or feet near rotating parts or the discharge opening.
- Disconnect power before performing any maintenance or clearing clogs.
- Operate only in daylight or good artificial light. The integrated LED lights assist visibility in low-light conditions.

3. Setup and Assembly

Follow these steps to assemble your Garvee Electric Snow Blower:

1. **Attach the Lower Handle:** Secure the lower handle to the main unit using the provided knobs. Ensure it is firmly in place.
2. **Attach the Upper Handle:** Connect the upper handle to the lower handle, aligning the holes and securing with the remaining knobs.
3. **Install the Discharge Chute:** Place the discharge chute onto the snow blower's outlet. Secure it with the provided screws, ensuring a tight fit to prevent snow leakage.
4. **Connect the Chute Control Rod:** Attach the chute control rod to the chute and the handle assembly. This allows for 180-degree directional adjustment of the snow discharge.
5. **Secure Cables:** Use the provided cable clips to secure all electrical cables along the handle frame, keeping them tidy and away from moving parts.
6. **Connect Power Cord:** Connect your outdoor-rated extension cord to the snow blower's power inlet. Ensure the connection is secure and the cord is routed safely to avoid entanglement during operation.



Image: The Garvee snow blower showing its 180-degree adjustable chute for directing snow.

▶ **Watch video online**
SOYUS 40V 20-Inch Snow Blower Cordless

Video: This video demonstrates the assembly process for a similar electric snow blower, including handle and chute installation. Note: This video is for a SOYUS brand snow blower and is cordless, but the assembly steps are generally applicable to corded models.

4. Operating Instructions

Before starting, ensure all assembly steps are complete and the power cord is securely connected to a suitable outdoor extension cord and power outlet.

1. **Starting the Snow Blower:** Press the safety button, then squeeze the operating bar. The motor will start. Release the safety button while keeping the operating bar squeezed to continue operation.
2. **Clearing Snow:** Push the snow blower forward into the snow. The 15-amp brushless motor is designed to clear a 20-inch path and depths up to 12 inches.
3. **Adjusting Snow Discharge:** Use the 180-degree adjustable chute to direct the snow away from cleared areas, buildings, and people.
4. **Using LED Lights:** Activate the dual integrated LED lights for improved visibility during early morning or evening snow removal.
5. **Stopping the Snow Blower:** Release the operating bar to stop the motor.



Image: A person using the Garvee Electric Snow Blower to clear a snowy driveway, demonstrating its clearing capability.

▶ **Watch video online**
Garvee 20 Inch Snow Blower

Video: This video shows the Garvee 20 Inch Snow Blower in action, demonstrating its snow-clearing performance.

5. Maintenance

Regular maintenance ensures the longevity and efficient operation of your snow blower.

- **Cleaning:** After each use, disconnect the power cord and clean any snow or debris from the auger, chute, and housing. Use a plastic or wooden tool to clear clogs, never your hands.
- **Inspection:** Periodically inspect the auger blades for wear or damage. Check all fasteners for tightness.
- **Cord Care:** Inspect the power cord and extension cord for any cuts, fraying, or damage. Replace damaged cords immediately.
- **Storage:** Store the snow blower in a dry, covered area away from direct sunlight and moisture. Ensure the power cord is neatly coiled and secured.

6. Troubleshooting

Problem	Possible Cause	Solution
Snow blower does not start.	Power cord not connected; operating bar not engaged; circuit breaker tripped.	Ensure power cord is securely plugged in. Engage the operating bar fully. Check and reset the circuit breaker if necessary.
Snow is not being thrown effectively.	Discharge chute clogged; auger blades worn; snow is too wet/heavy.	Disconnect power and clear the chute with a tool. Inspect and replace worn auger blades. Take smaller passes with wet snow.
Excessive vibration during operation.	Loose fasteners; damaged auger blade; foreign object in auger housing.	Disconnect power and check all fasteners. Inspect auger for damage or obstructions.

7. Specifications

- **Brand:** Garvee
- **Model Number:** NEWSNOWBLOWER
- **Power Source:** Corded Electric (AC)
- **Motor:** 15-amp Brushless Motor
- **Clearing Width:** 20 Inches
- **Ideal Snow Depth:** Up to 12 Inches
- **Throwing Distance:** Up to 25 Feet
- **Product Dimensions:** 40.5"D x 14.5"W x 16.5"H
- **Item Weight:** 28.2 Pounds
- **Chute Rotation:** 180 Degrees
- **Features:** Dual LED Lights, Ergonomic Grip, All-Terrain Wheels
- **UPC:** 199809050573



Image: The Garvee snow blower highlighting its 20-inch clearing width and 12-inch maximum clearing depth.



Image: The Garvee snow blower demonstrating its capability to throw snow up to 25 feet.

8. Warranty and Support

Your Garvee Electric Snow Blower is backed by a**2-year limited warranty**. This warranty covers defects in materials and workmanship under normal use. For warranty claims or technical support, please contact Garvee customer service.

For more information or to visit the official store, please visit the**Garvee Store**.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FVL1T7L1

More documents and user manuals: **https://manuals.plus/**