Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Sweetcrispy AM-LLJ2B01-1D5SR

Sweetcrispy Food Processor Blender Combo

MODEL: AM-LLJ2B01-1D5SR

1. Introduction

Thank you for choosing the Sweetcrispy Food Processor Blender Combo. This versatile appliance is designed to simplify your food preparation tasks, offering multiple functions including chopping, slicing, shredding, kneading, whisking, and blending. Please read this manual thoroughly before first use to ensure safe and optimal operation.



Image 1.1: The Sweetcrispy Food Processor Blender Combo with its main components.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before operating the appliance.
- Ensure the appliance is securely locked before operation. The safety interlock system prevents operation if the bowl and lid are not correctly assembled.
- Keep hands and utensils away from moving blades or discs while processing food to prevent severe personal injury.
- Always unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Do not immerse the motor base in water or other liquids. The power cord and base are water-resistant, but not waterproof.
- Do not use the appliance for anything other than its intended use.
- Exercise extreme caution when handling sharp blades and discs. Store them out of reach of children.

- This appliance is equipped with overheat protection. If the motor overheats, it will automatically shut off. Allow it to cool down before resuming use.
- Do not pour items with excessively high temperatures directly into the glass jar.



Image 2.1: The secure locking mechanism and non-slip suction cups on the base ensure stable and safe operation.

3. Product Components

Your Sweetcrispy Food Processor Blender Combo includes the following parts:

- Motor Base with Control Dial
- 1.5L ABS Food Processor Bowl
- Food Processor Lid with Feed Tube
- Pusher (for feed tube)
- 1.5L Glass Blender Jar with Lid
- Knife Blade (for chopping/mincing)
- Dough Knife (for kneading)

- Slicing Disc
- Shredding Disc
- Egg White Plate (for whisking)
- Drive Shaft
- Measuring Cup



Image 3.1: Overview of all included accessories and main units.

4. Setup and Assembly

Before first use, wash all removable parts in warm soapy water, rinse thoroughly, and dry. Wipe the motor base with a damp cloth.

4.1. Assembling the Food Processor

1. Place the motor base on a clean, dry, and stable surface.
2. Attach the drive shaft onto the motor base.

3. Carefully place the desired blade (Knife Blade, Dough Knife, Slicing Disc, Shredding Disc, or Egg White Plate) onto the drive shaft.
4. Place the 1.5L ABS food processor bowl onto the motor base, aligning the handle with the locking mechanism. Turn clockwise until it clicks into place.
5. Add ingredients to the bowl.
6. Place the food processor lid onto the bowl, aligning the tab on the lid with the handle. Turn clockwise until it clicks into place. The safety interlock will engage.
7. Ensure the pusher is in the feed tube if using for continuous processing.

4.2. Assembling the Blender

1. Place the motor base on a clean, dry, and stable surface.
2. Ensure the blade assembly is securely attached to the bottom of the 1.5L glass blender jar.
3. Add ingredients to the blender jar.
4. Securely place the blender lid onto the jar.
5. Place the assembled blender jar onto the motor base, aligning it correctly. Turn clockwise until it clicks into place. The safety interlock will engage.



Image 4.1: The interchangeable food processor bowl and blender jar.

5. Operating Instructions

The appliance features a control dial with three settings: '0' (Off), '1' (Low Speed), '2' (High Speed), and 'P' (Pulse).

5.1. Speed Control

- **'0' (Off):** The appliance is off. Always return the dial to '0' before plugging in or unplugging, and before assembling or disassembling parts.
- **'1' (Low Speed):** Use for processing delicate foods, mixing, or when less power is required.
- **'2' (High Speed):** Use for tougher ingredients, grinding, or when maximum power is needed.
- **'P' (Pulse):** Provides short bursts of power at maximum speed. Turn the dial to 'P' and hold for desired duration, then release to return to '0'. Ideal for controlled chopping, blending, or for breaking down larger pieces.



Image 5.1: The control dial for precise speed and pulse control.

5.2. Using the Food Processor

After assembling the food processor with the desired blade and ingredients (refer to Section 4.1):

- Plug in the appliance.
- Turn the control dial to '1' or '2' for continuous processing, or to 'P' for pulse action.
- For slicing or shredding, feed ingredients through the feed tube using the pusher. Do not force ingredients.
- When finished, turn the dial to '0' and unplug the appliance before disassembling.



Image 5.2: Using the food processor for slicing vegetables.

5.3. Using the Blender

After assembling the blender jar with ingredients (refer to Section 4.2):

- Plug in the appliance.
- Turn the control dial to '1' or '2' for continuous blending, or to 'P' for pulse action.
- Do not overfill the blender jar.
- When finished, turn the dial to '0' and unplug the appliance before disassembling.



Image 5.3: The blender jar prepared for smoothie blending.

5.4. Multi-Function Attachments

The Sweetcrispy Food Processor Blender Combo comes with various attachments for different tasks:

- **Knife Blade:** Ideal for chopping vegetables, mincing meat (up to 300g in 10s), and pureeing.
- **Dough Knife:** Designed for kneading dough (e.g., 300g flour + 200g water in 30s).
- **Slicing Disc:** For uniform slicing of vegetables like cucumbers and carrots (up to 500g in 1 minute).
- **Shredding Disc:** For shredding vegetables and cheese.
- **Egg White Plate:** For whisking egg whites (e.g., 100g in 1 minute).
- **Blender Jug:** For blending liquids, making smoothies (e.g., 600g carrot + 900ml water in 3 minutes), and mixing.



Image 5.4: Examples of various functions using different attachments.

▶ **Watch video online**
Sweetcrispy Food Processor Blender

Video 5.5: An overview of the Sweetcrispy Food Processor Blender's features and operation.

6. Maintenance and Cleaning

Proper cleaning and maintenance will extend the life of your appliance.

- Always unplug the appliance before cleaning.
- Most removable parts, including the food processor bowl, blender jar, blades, and discs, are dishwasher safe.
- For manual cleaning, rinse blades with soapy water using a soft brush. Exercise caution when handling sharp edges.
- Wipe the motor base with a damp cloth. Do not immerse the motor base in water.
- If plastic components develop stains over time, a small amount of vegetable oil can help restore their appearance.
- Ensure all parts are completely dry before reassembling or storing.

7. Troubleshooting

If you encounter issues with your Sweetcrispy Food Processor Blender Combo, refer to the following common problems and solutions:

- **Appliance does not turn on:**
  - Ensure the power cord is securely plugged into a working outlet.
  - Verify that the food processor bowl/lid or blender jar is correctly assembled and locked into place. The safety interlock prevents operation if not properly secured.
  - Check if the control dial is set to '1', '2', or 'P' (Pulse).
  - If the appliance recently stopped during use, the overheat protection might have activated. Unplug and allow the motor to cool down for at least 30 minutes before attempting to use again.
- **Motor runs but ingredients are not processing:**
  - Ensure the correct blade or disc is properly installed on the drive shaft.
  - Check if the ingredients are too large or too dense for the selected speed. Cut larger ingredients into smaller pieces.
  - Do not overload the bowl or jar. Reduce the quantity of ingredients.
- **Lid is stuck or difficult to remove:**
  - Ensure the appliance is turned off and unplugged.
  - Gently twist the lid counter-clockwise to unlock. Avoid excessive force.

If the problem persists after following these steps, please contact customer support.

8. Specifications

Feature	Specification
Brand	Sweetcrispy
Model Number	AM-LLJ2B01-1D5SR
Wattage	300 watts
Voltage	120V~60Hz
Food Processor Bowl Capacity	1500ml (ABS)
Blender Jar Capacity	1.5L (Glass)
Product Dimensions	7.87"D x 14.57"W x 13.19"H
Item Weight	8.71 Pounds
Special Features	Adjustable Speed Control, Removable Parts, Safety Lock, Overheat Protection, Non-slip Base



Image 8.1: The powerful 300W motor designed for efficient processing.

9. Warranty and Support

For warranty information or technical support, please refer to the warranty card included with your product or contact Sweetcrispy customer service. Keep your purchase receipt as proof of purchase for any warranty claims.

For further assistance, please visit the official Sweetcrispy website or contact their customer support channels.

© 2025 Sweetcrispy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FVX74D7G

More documents and user manuals: **https://manuals.plus/**