Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LEXIBOOK RL977FZLXB

Lexibook Disney Frozen Projector Alarm Clock RL977FZLXB User Manual

Model: RL977FZLXB

1. Introduction

This manual provides comprehensive instructions for the safe and effective use of your Lexibook Disney Frozen Projector Alarm Clock, Model RL977FZLXB. Please read this manual thoroughly before operating the device and retain it for future reference.

2. Product Overview

The Lexibook Disney Frozen Projector Alarm Clock features an LCD display, an alarm with snooze function, and a projector that displays images of Olaf in various colors. It also includes a night light with a timer function.

2.1 Components and Controls

- **LCD Display:** Shows current time and alarm status.
- **Time Button:** Used to set the current time.
- **Alarm Button:** Used to set the alarm time.
- **Hour Button:** Adjusts the hour during time or alarm setting.
- **Min Button:** Adjusts the minute during time or alarm setting.
- **On/Off Button (Light Bulb Icon):** Activates and deactivates the night light/projector.
- **Snooze Button:** Temporarily silences the alarm.
- **Projector Lens:** Projects images onto a surface.



Image 2.1: Front view of the alarm clock, highlighting the LCD screen and the 'Time', 'Alarm', 'Hour', 'Min', and 'On/Off' buttons.

3. Setup

3.1 Battery Installation

1. Locate the battery compartment cover on the underside of the alarm clock.
2. Using a small screwdriver, carefully open the battery compartment.
3. Insert 3 new LR03/AAA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Replace the battery compartment cover and secure it with the screw.

Note: Batteries are not included with the product. Always use new batteries of the specified type. Do not mix old and new batteries or different types of batteries.

4. Operating Instructions

4.1 Setting the Current Time

1. Press and hold the **Time** button until the hour display begins to flash.
2. Press the **Hour** button repeatedly to adjust the hour.
3. Press the **Min** button repeatedly to adjust the minutes.
4. Press the **Time** button again to confirm and save the current time.

4.2 Setting the Alarm

1. Press and hold the **Alarm** button until the alarm hour display begins to flash.
2. Press the **Hour** button repeatedly to adjust the alarm hour.
3. Press the **Min** button repeatedly to adjust the alarm minutes.
4. Press the **Alarm** button again to confirm and activate the alarm. An alarm icon will appear on the LCD display.

4.3 Using the Snooze Function

When the alarm sounds, press the **Snooze** button. The alarm will temporarily stop and sound again after a few minutes (typically 9 minutes). To turn off the alarm completely, press the **Alarm** button.

4.4 Night Light and Projector Function

The alarm clock features a projector that displays images of Olaf on your ceiling or wall. The projection can be displayed in three different colors.

1. Press the **On/Off (Light Bulb Icon)** button once to activate the night light and projector. The projection will appear in a default color.
2. Press the **On/Off** button repeatedly to cycle through the three available projection colors (e.g., blue, red, orange).
3. To turn off the night light and projector, press the **On/Off** button until the light is extinguished.



Image 4.1: The alarm clock projecting a blue image of Olaf.



Image 4.2: The alarm clock projecting a red image of Olaf.



Image 4.3: The alarm clock projecting an orange image of Olaf.

4.5 Night Light Timer Function

The night light and projector can be set to automatically turn off after a specified duration (5, 15, or 30 minutes).

1. While the night light/projector is active, press and hold the **On/Off (Light Bulb Icon)** button.
2. The display will show the current timer setting (e.g., "5 min").
3. Press the **On/Off** button repeatedly to cycle through the timer options: 5 minutes, 15 minutes, 30 minutes, or Off.
4. Release the **On/Off** button to select the desired timer setting. The night light/projector will automatically turn off after the selected duration.



Image 4.4: The alarm clock functioning as a night light while a child sleeps.



Image 4.5: The alarm clock on a bedside table as a child wakes up.

5. Maintenance

5.1 Cleaning

To clean the alarm clock, use a soft, dry cloth. Do not use abrasive cleaners or solvents, as these may damage the surface. Keep the projector lens clean for optimal projection clarity.

5.2 Battery Replacement

When the display dims or the functions become erratic, it is time to replace the batteries. Follow the steps in Section 3.1 for battery installation.

6. Troubleshooting

- **Clock not turning on / Display is blank:**
  Ensure batteries are correctly installed and are not depleted. Replace with new batteries if necessary.

- **Projection is blurry:**
  Ensure the projector lens is clean and free from dust or smudges. Adjust the distance of the clock from the projection surface for optimal focus.
- **Alarm not sounding:**
  Verify that the alarm time is set correctly and the alarm icon is visible on the LCD display. Check battery levels.
- **Buttons are unresponsive:**
  Remove and reinsert the batteries to reset the device. If the issue persists, replace the batteries.

7. Specifications

Model Number	RL977FZLXB
Brand	LEXIBOOK
Dimensions	11.8 x 11 x 9.1 cm
Weight	140 g
Power Source	3 x LR03/AAA batteries (not included)
Material	Plastic
Display Type	Digital LCD

8. Safety Information

WARNING: CHOKING HAZARD - Small Parts. Not for children under 3 years. This product contains small parts that may pose a choking hazard. Adult supervision is recommended.

Do not expose the device to extreme temperatures, direct sunlight, or moisture. Do not attempt to disassemble or modify the device, as this will void the warranty and may cause damage or injury.

9. Warranty and Support

For warranty information or technical support, please refer to the warranty card included with your purchase or visit the official Lexibook website. Contact details for customer service can typically be found on the product packaging or the manufacturer's website.

© 2025 LEXIBOOK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FVXXNN27

More documents and user manuals: **https://manuals.plus/**