Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Genérico R40S Ultra

Genérico R40S Ultra Retro Handheld Game Console User Manual

Model: R40S Ultra

Introduction

Thank you for purchasing the Genérico R40S Ultra Retro Handheld Game Console. This device is designed to provide a portable gaming experience with a vast library of pre-installed retro games. Featuring a 3.5-inch HD screen, high-performance CPU, and 256GB of storage, it supports over 30 emulators for smooth, lag-free gameplay. This manual will guide you through the setup, operation, maintenance, and troubleshooting of your console.



Image: The Genérico R40S Ultra console, its charging cable, and a black carrying case.

Product Overview

The R40S Ultra console features a compact and ergonomic design, making it comfortable for extended play sessions. Familiarize yourself with the console's layout and components.

Front View



Image: Front view of the Genérico R40S Ultra console, highlighting the 3.5-inch screen, D-pad, A/B/X/Y action buttons, dual analog joysticks, and Select/Start/FN buttons.

Side and Rear Views



Image: Rear and side view of the console, illustrating the L1, L2, R1, R2 shoulder buttons for enhanced control.



Image: Side view of the console, displaying various ports and volume controls.

Dimensions



Image: A diagram detailing the physical dimensions of the Genérico R40S Ultra console.

Setup

1. Charging the Console

Before first use, fully charge the console. Connect the included USB charging cable to the console's charging port and a compatible USB power adapter (not included). The charging indicator light will typically show charging status and turn off or change color when fully charged.

2. Inserting the TF Card

The console comes with a pre-configured 256GB TF card. Ensure it is properly inserted into the designated TF card slot before powering on the device. The card contains all the pre-installed games and system software.

3. Powering On/Off

- **To Power On:** Press and hold the Power button for a few seconds until the screen illuminates.
- **To Power Off:** Press and hold the Power button until a power-off menu appears on the screen, then select 'Power

Off'. Alternatively, a quick press might put it into sleep mode.

Operating Instructions

1. Navigating the Menu

Use the D-pad or the left analog joystick to navigate through the main menu options. The 'A' button typically confirms selections, and the 'B' button usually acts as a back or cancel function.

2. Selecting and Launching Games

- From the main menu, select the desired emulator or game category.
- Browse the list of games using the D-pad or joystick.
- Press the 'A' button to launch a selected game.

3. In-Game Controls

Controls vary by game and emulator. Generally, the D-pad and action buttons (A, B, X, Y) are used for primary gameplay. The analog joysticks provide 3D movement where supported. The L1/L2/R1/R2 shoulder buttons offer additional functions.

4. Saving and Loading Game States

Most emulators allow for 'save states' which capture your exact progress at any point. Refer to the specific emulator's menu (often accessed via the 'FN' button or a combination of buttons) for options to save and load states.

5. Adjusting Volume

Use the dedicated volume buttons on the side of the console to increase or decrease the audio output.

6. Exiting Games

To exit a game and return to the emulator or main menu, typically press the 'FN' button or a combination of 'Select' and 'Start' buttons simultaneously. Consult the emulator's specific instructions if this does not work.

Maintenance

1. Cleaning the Console

Use a soft, dry cloth to clean the console's exterior. For stubborn smudges, a slightly damp cloth can be used, followed by a dry cloth. Avoid using harsh chemicals or abrasive materials, as these can damage the screen or casing.

2. Battery Care

- To prolong battery life, avoid fully discharging the battery frequently.
- Charge the console regularly, even if not in use for extended periods.
- Do not expose the console to extreme temperatures, as this can degrade battery performance.

3. Software Updates

Periodically check the manufacturer's official website or community forums for any available firmware updates. Updates can improve performance, add features, or fix bugs. Follow update instructions carefully to avoid damaging the device.

Troubleshooting

Problem	Possible Cause	Solution
Console does not power on.	Low battery; system crash.	Ensure the console is fully charged. If charged, try performing a hard reset by holding the power button for 10-15 seconds.
Short battery life.	Battery degradation; high screen brightness; background processes.	Reduce screen brightness. Close any unnecessary background applications. Ensure the console is fully charged before use. If the issue persists, the battery may need replacement.
Buttons not responding (e.g., 'Y' button).	Physical damage; software glitch.	Restart the console. If the issue persists, inspect the button for physical obstruction. If it's a new issue, contact support.
Games not loading or performing poorly (e.g., 3D PSP games).	Corrupted game files; emulator limitations; insufficient system resources.	Ensure game files are not corrupted. Some emulators or games, especially those with complex 3D graphics, may exceed the console's processing capabilities. Try different emulator settings if available.
Memory card issues (e.g., less usable space than advertised).	System files occupy space; formatting differences.	The operating system and pre-installed software will occupy a portion of the memory card's advertised capacity. This is normal. If you suspect significant discrepancy, verify the card's actual capacity using a computer.

Specifications

Feature	Detail
Model Number	HI-R40S Ultra / HIM-R40S
Dimensions	13 x 2 x 8 cm (5.12 x 0.79 x 3.15 inches)
Weight	180 Grams
Screen Type	LCD
Screen Size	3.5 Inches
Storage Capacity	256 GB (TF Card included)
Battery Type	Lithium-ion Polymer
Number of Players	1
Controller Type	Tactile (Buttons, Joysticks)
Material	Acrylonitrile Butadiene Styrene (ABS)
Included Components	1× R40S Ultra Console, 1× Charging Cable, 1x Black Case

Warranty and Support

Warranty Information

This product typically includes a standard return policy. For specific details regarding your purchase, please refer to the retailer's return policy, which may offer a 30-day free return period. Extended warranty options may also be available from third-party providers like Assurant for 2, 3, or 4 years.

Customer Support

For technical assistance, troubleshooting not covered in this manual, or warranty claims, please contact the seller or manufacturer through the platform where you purchased the product. Keep your purchase receipt or order number handy for faster service.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question