Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

InBrave wagon

InBrave Collapsible Wagon Cart Instruction Manual

Model: Wagon

1. Introduction

This manual provides essential information for the safe and efficient use of your InBrave Collapsible Wagon Cart. Designed for versatility and ease of transport, this wagon is suitable for various activities including shopping, beach trips, camping, and gardening. Please read these instructions carefully before initial use and retain for future reference.

2. Safety Information

- **Maximum Load Capacity:** Do not exceed the maximum load capacity of 380 lbs (172 kg). Overloading can cause damage to the wagon and may lead to injury.
- **Proper Use:** This wagon is designed for transporting goods. It is not intended for carrying children or pets.
- **Stability:** Always ensure the wagon is stable before loading or unloading items. Distribute weight evenly to prevent tipping.
- **Handle Safety:** Ensure the handle is securely locked in position during use. Avoid sudden movements that could cause the handle to disengage.
- **Terrain:** While designed for all-terrain use, exercise caution on uneven, steep, or slippery surfaces.
- **Folding/Unfolding:** Keep hands and fingers clear of moving parts during folding and unfolding to prevent pinching.

3. Package Contents

Verify that all components are present upon unpacking:

- InBrave Collapsible Wagon Cart (pre-assembled frame and fabric)
- Removable Bottom Support Pad
- User Manual

4. Setup Instructions

The InBrave Collapsible Wagon Cart comes largely pre-assembled, requiring minimal setup.

4.1 Unfolding the Wagon

1. Place the folded wagon on a flat, stable surface.
2. Gently pull the sides of the wagon outwards until the frame fully expands.
3. Press down firmly on the center of the wagon's base until it locks into place.
4. Insert the removable bottom support pad into the base of the wagon for added stability.



Figure 4.1: The wagon unfolds in seconds for quick setup. Ensure the base is fully extended and locked.

5. Operating Instructions

5.1 Loading the Wagon

The wagon offers a spacious 120L capacity and can hold up to 380 lbs. Distribute items evenly to maintain balance and prevent strain on the frame.

5.2 Adjusting the Handle

The ergonomic handle is adjustable from 30.3 inches to 35 inches in height and features a 90-degree rotation for comfortable pulling. To adjust, locate the handle switch (often a button or lever near the handle base), press it, and extend or retract the handle to your desired length. Release the switch to lock it in place. The handle also has an auto-return function.



Figure 5.1: The handle can be adjusted for height and rotated for optimal comfort. Note the integrated cup holders.

5.3 Maneuvering

Equipped with reinforced off-road tires and 360-degree swivel front wheels, the wagon provides smooth maneuverability across various surfaces including sand, gravel, mud, and grass.



Figure 5.2: All-terrain wheels ensure smooth movement on diverse surfaces.

5.4 Folding for Storage

1. Remove all contents from the wagon.
2. Remove the bottom support pad.
3. Locate the pull tab in the center of the wagon's base. Pull upwards on this tab to initiate the folding mechanism.
4. Gently push the sides of the wagon inwards until it is fully collapsed.
5. Secure the folded wagon with the integrated strap to prevent it from unfolding during transport or storage. The strap should be attached to either side frame, not the bottom thicker frame.



Figure 5.3: The wagon folds compactly for easy storage.

6. Maintenance

6.1 Cleaning

The 600D Oxford fabric is tear-resistant and machine-washable. To clean, remove the fabric from the frame (if detachable) and wash according to fabric care instructions. For minor spills, wipe with a damp cloth and mild soap. Allow to air dry completely before reassembling or storing.

6.2 Storage

Store the folded wagon in a dry place, away from direct sunlight and extreme temperatures, to prolong its lifespan.

7. Troubleshooting

- **Difficulty Folding:** If the wagon is difficult to fold, ensure the bottom support pad is removed and the central pull tab is fully engaged. Sometimes, the mechanism may be stiff during initial uses; gentle but firm pressure may be required.

- **Wheels Not Rolling Smoothly:** Check for debris (e.g., gravel, sand) caught in the wheel mechanisms. Clean the wheels and axles regularly. Ensure the wheels are properly aligned.
- **Handle Not Locking:** Verify that the handle switch is fully released after adjusting the handle height. If the handle still does not lock, inspect the locking mechanism for any obstructions or damage.

8. Specifications

Feature	Detail
Product Dimensions (Unfolded)	26.4"D x 17.7"W x 30.3"H
Folded Dimensions	7.5"L x 17.7"W x 30.3"H
Weight	10.4 lbs
Load Capacity	380 lbs
Volume Capacity	120 Liters
Material	Carbon Steel Frame & 600D Oxford Fabric
Handle Adjustment	30.3"-35" Height, 90° Rotation, Auto-Return
Wheels	Reinforced All-Terrain, 360° Swivel Front Wheels



Figure 8.1: Detailed product dimensions for both unfolded and folded states.

9. Warranty and Support

For warranty information or technical support, please refer to the product packaging or contact InBrave customer service through the retailer where the product was purchased. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FYDZQWPJ

More documents and user manuals: **https://manuals.plus/**